

manuals.plus /

› [Sportneer](#) /

› [Sportneer Stadium Seat with Back Support \(Model Y21-80600-31\) - Instruction Manual](#)

Sportneer Y21-80600-31

Sportneer Stadium Seat with Back Support (Model Y21-80600-31)

Instruction Manual

1. PRODUCT OVERVIEW

The Sportneer Stadium Seat with Back Support is designed to provide comfort and convenience during various events. It features a robust steel frame, a 2.5-inch high-density foam cushion, and a 16-inch high backrest. The seat offers 6 adjustable recline positions and includes padded armrests for enhanced comfort. Integrated storage solutions such as cup holders and pockets are also provided.



Figure 1: Front view of the Sportneer Stadium Seat.

2. KEY FEATURES

- **Thickened & Soft Cushion:** Features a 2.5-inch high-density foam cushion and a 16-inch high backrest for comfort and support.
- **Adjustable Armrests:** Padded armrests on both sides for added comfort.
- **6 Adjustable Recline Positions:** Allows for customization of the backrest angle from fully upright to completely flat.
- **Convenient Storage:** Includes 2 cup holders, a spacious side pocket, and a zippered back pocket for personal items.
- **Portable & Easy to Set Up:** Designed for quick installation and portability with shoulder straps and a side handle.
- **Secure Design:** Equipped with a quick-release buckle to secure the seat to bleachers and an anti-slip bottom.

3. SETUP AND ADJUSTMENT

3.1 Unfolding the Seat

The stadium seat arrives in a folded, flat position for easy transport. To unfold:

1. Place the folded seat on a flat, stable surface.
2. Gently lift the backrest portion of the seat. It will click into the first upright position.
3. Ensure the seat is stable before use.

3.2 Adjusting Recline Positions

The seat offers 6 recline positions for personalized comfort. To adjust the backrest angle:

1. Push the backrest forward past the 90-degree upright position until it releases from its current lock.
2. Return the backrest to the desired angle. It will click into place at each of the 6 available positions.
3. To return the seat to a flat position for storage, push the backrest forward past 90 degrees and then lay it flat.

6 RECLINE POSITIONS

Adjust to your perfect comfort



Figure 2: Illustration of the 6 recline positions and adjustment method.

3.3 Securing the Seat to Bleachers

To prevent the seat from slipping or falling, use the integrated safety buckle:

1. Position the stadium seat on the bleacher or bench.
2. Locate the quick-release buckle strap at the bottom of the seat.
3. Wrap the strap around the bleacher and secure the buckle. Tighten the strap for a snug fit.
4. The anti-slip bottom also provides additional stability.

Sportneer



WAYS FOR SECURE

Sturdy Backrest for Reliable Support & Back Pain Relief

Figure 3: Detail of the anti-slip bottom and bottom buckle for securing the seat.

3.4 Carrying Options

The Sportneer Stadium Seat offers two convenient ways to carry it:

- **Shoulder Straps:** Use the padded shoulder straps to carry the seat like a backpack, ideal for longer distances.
- **Side Handle:** Utilize the side handle for quick and easy hand-carrying.

Sportneer



CONVENIENT TO CARRY IN 2 WAYS

Two Easy Carrying Options

Figure 4: Two ways to carry the stadium seat: backpack style and by hand.

4. STORAGE AND POCKETS

The stadium seat is equipped with multiple storage options to keep your essentials organized:

- **2 Cup Holders:** Located on the side for easy access to beverages.
- **Spacious Side Pocket:** Suitable for phones, umbrellas, or other accessories.
- **Zippered Back Pocket:** Ideal for securing keys, snacks, and other small valuables.



THOUGHTFUL DESIGN



Figure 5: Overview of the seat's storage features and design elements.

5. MAINTENANCE

To ensure the longevity of your Sportneer Stadium Seat, follow these care instructions:

- **Spot Clean:** For minor spills or dirt, use a damp cloth and mild soap to spot clean the affected area.
- **Air Dry:** Allow the seat to air dry completely before folding and storing.
- **Avoid Harsh Chemicals:** Do not use bleach or abrasive cleaners, as these can damage the fabric and materials.
- **Proper Storage:** Store the seat in a dry, cool place when not in use to prevent mildew and material degradation.

6. SAFETY INSTRUCTIONS

Please read and adhere to the following safety guidelines:

- Always ensure the chair is stable before use on any surface.
- Do not exceed the maximum weight limit of 150 pounds.
- Be cautious when adjusting recline positions, especially in outdoor settings or on uneven surfaces.
- Keep fingers and clothing clear of moving parts during adjustment to prevent pinching.
- Do not stand on the seat.
- Supervise children when they are using or near the stadium seat.

7. SPECIFICATIONS

Feature	Detail
Brand	Sportneer
Model Name	Sportneer Stadium Seats for Bleachers
Model Number	Y21-80600-31
Color	Black
Size	Regular - 20.5"
Product Dimensions	16"D x 20.5"W x 16"H
Item Weight	6.8 pounds
Maximum Weight Recommendation	150 Pounds
Material	Alloy Steel, Polyester, PVC, Sponge
Fill Material	Foam
Reclining Position Count	6
Is Foldable	Yes
Assembly Instructions	Already assembled
Product Care Instructions	Spot Clean

8. VIDEO DEMONSTRATIONS

8.1 Sportneer Stadium Seats for Bleachers with Back and Cushion

Your browser does not support the video tag.

This video provides a general overview of the Sportneer Stadium Seat, showcasing its features and use at a baseball game.

8.2 How to Adjust Sportneer Stadium Seats with Back Support

Your browser does not support the video tag.

Learn how to adjust the backrest and armrests of your Sportneer Stadium Seat to find your preferred recline position.

8.3 Sportneer Reclining Stadium Seats for Bleachers Sports Events

Your browser does not support the video tag.

This video demonstrates the reclining functionality and portability of the Sportneer Stadium Seat for various sports events.