

Acme 26220Q

Acme Brancaster Leather Queen Platform Bed with Storage Instruction Manual

Model: 26220Q

INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and care of your Acme Brancaster Queen Platform Bed with Storage. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury. Keep all small parts away from children. Ensure all connections are secure before use. Do not exceed the weight limit of 204 pounds.

SETUP AND ASSEMBLY

Assembly is required for the Acme Brancaster Queen Platform Bed. For detailed, step-by-step instructions, please refer to the official Installation Manual PDF available at: [Installation Manual \(PDF\)](#).

General assembly involves connecting the two side panels, the headboard, and the footboard. These components are designed to lock together. Subsequently, wood panels are installed to support the mattress. A box spring is not required for this platform bed design.



Figure 1: Fully assembled Acme Brancaster Queen Platform Bed, showcasing its retro brown leather and aluminum design.

OPERATING INSTRUCTIONS

Storage Headboard

The Acme Brancaster bed features a storage headboard. To access the storage compartments, gently lift the designated panels on the headboard. The opening mechanism is designed for smooth operation. Ensure items stored within do not obstruct the closing mechanism or exceed the compartment's capacity.



Figure 2: Detail of the storage compartment within the headboard, demonstrating its functionality.

General Use

Place your mattress directly onto the provided wood slat support system. No box spring is needed. Ensure the bed is placed on a level surface to maintain stability.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your bed. Regular cleaning and attention to the materials are recommended.

- **Leather Upholstery:** For the top grain leather, dust regularly with a soft, dry cloth. For spills, blot immediately with a clean, absorbent cloth. Avoid harsh chemicals or abrasive cleaners. Use a specialized leather cleaner and conditioner periodically as recommended by leather care professionals.
- **Aluminum Frame:** Wipe the aluminum surfaces with a soft, damp cloth. Avoid using abrasive cleaners or pads that could scratch the finish. Dry thoroughly after cleaning.
- **General:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary to maintain structural integrity.

TROUBLESHOOTING

If you encounter issues with your bed, please review the following common solutions:

- **Bed feels unstable or wobbly:** Ensure all assembly bolts and screws are securely tightened. Verify that the bed is

placed on a flat, level surface.

- **Storage compartment not closing smoothly:** Check for any obstructions within the compartment or along the hinge mechanism. Ensure items are not overfilling the space.
- **Squeaking noises:** This can often be resolved by re-tightening all assembly hardware. If the issue persists, inspect the wood slats for proper placement and any signs of wear.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	26220Q
Brand	Acme
Size	Queen
Product Dimensions	97"L x 66"W x 33"H
Color	Retro Brown Top Grain Leather & Aluminum
Upholstery Fabric Type	Leather
Headboard Material	Leather
Weight Limit	204 Pounds
Item Weight	166.6 pounds
Assembly Required	Yes
Box Spring Required	No (Platform Bed)
Special Feature	Storage Headboard, Patchedwork Aluminum
Manufacturer	Acme Furniture
Country of Origin	China

WARRANTY INFORMATION

The Acme Brancaster Queen Platform Bed is covered by a**Limited Warranty**. For specific terms, conditions, and duration of the warranty, please refer to the documentation included with your purchase or contact Acme Furniture customer support.

CUSTOMER SUPPORT






For further assistance, questions regarding assembly, parts, or warranty claims, please contact Acme Furniture customer support. You can often find contact information on the manufacturer's official website or through your retailer.

Manufacturer: Acme Furniture

Brand: Acme



Related Documents - 26220Q

	<p>Руководство по эксплуатации промышленных источников питания ACME серии 800</p> <p>Подробное руководство по эксплуатации промышленных источников питания ACME серии 800. Информация по установке, настройке, управлению, протоколам связи и техническому обслуживанию.</p>
	<p>Acme Thread Data Sheets and Specifications</p> <p>Comprehensive data sheets for Acme screw threads, including dimensions, tolerances, and formulas for external and internal threads, with a focus on 29° Acme threads.</p>
	<p>ACME BH203 Bluetooth Earphones User Manual and Specifications</p> <p>Comprehensive user manual for ACME BH203 Bluetooth earphones, detailing features, technical specifications, setup, troubleshooting, and maintenance. Supports multiple languages.</p>
	<p>Acme ACME CH302 Wireless Charger 10W - Qi Fast Charging Pad</p> <p>Discover the Acme CH302 Wireless Charger, a 10W Qi-compatible charging pad. Features include a slim, compact design, anti-slip rubber, and an LED indicator for easy status checks. Includes USB Type-C cable and user manual. Ideal for convenient, cable-free charging.</p>
	<p>Acme Smart Home Hub: Centralized Control & Connectivity</p> <p>Learn about the Acme Smart Home Hub, your central point for managing smart devices. Features include voice assistant integration, app connectivity, and easy setup. Includes troubleshooting tips and warranty information.</p>



[Manuale di Riparazione Motori ACME ALN 215W/290W/330W AT 330-OHV](#)

Manuale di riparazione completo per i motori a scoppio ACME delle serie ALN 215W, 290W, 330W e AT 330-OHV. Include specifiche tecniche, procedure di smontaggio, montaggio, revisione, diagnostica e manutenzione.