

RCA RTR3260

RCA Roku Smart LED TV (32-Inch) 720p Model RTR3260 User Manual

Model: RTR3260

1. INTRODUCTION

Welcome to the user manual for your new RCA Roku Smart LED TV (Model RTR3260). This 32-inch 720p television combines high-definition viewing with the integrated Roku smart TV platform, offering access to a vast library of streaming content. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your television to ensure an optimal viewing experience.



Image: The RCA Roku Smart LED TV, a 32-inch black television with a slim design and two stand feet, viewed from an angle.

2. SAFETY INFORMATION

Please read all safety instructions before using your TV. Keep this manual for future reference.

- **Power Source:** Connect the TV only to the specified power supply.
- **Ventilation:** Ensure proper ventilation. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth.
- **Placement:** Place the TV on a stable, level surface. Avoid direct sunlight or heat sources.
- **Servicing:** Do not attempt to service the TV yourself. Refer all servicing to qualified personnel.

3. WHAT'S IN THE BOX

Carefully unpack your RCA Roku Smart LED TV and ensure all items are present:

- RCA Roku Smart LED TV (Model RTR3260)
- Remote Control
- Power Cable
- TV Stand (if not wall-mounted)
- Quick Start Guide

4. SETUP

4.1 Attaching the TV Stand

1. Place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align the stand bases with the screw holes on the bottom of the TV.
3. Secure the stand bases using the provided screws.

4.2 Initial Power-On and Roku Setup

1. Connect the power cable to the TV and a power outlet.
2. Press the power button on the TV or remote control.
3. Follow the on-screen instructions to select your language, connect to your Wi-Fi network, and activate your Roku account. An internet connection is required for Roku features.

5. OPERATING

5.1 Basic TV Functions

- **Power:** Press the **Power** button on the remote to turn the TV on or off.
- **Volume:** Use the **Volume Up/Down** buttons to adjust audio levels.
- **Input Selection:** Press the **Input** button to cycle through connected devices (HDMI, AV, etc.).
- **Home:** Press the **Home** button to return to the Roku home screen.

5.2 Roku Remote Control

The Roku remote provides intuitive navigation for the smart TV interface. It typically includes dedicated buttons for popular streaming services.

5.3 Roku Mobile App

Download the free Roku mobile app for iOS and Android devices to use your smartphone as a remote, enjoy private listening, and search with your voice or keyboard.

6. SMART FEATURES (Roku TV)

Your RCA Roku Smart LED TV offers a comprehensive smart TV experience:

- **Streaming Channels:** Access thousands of streaming channels, including Netflix, Hulu, YouTube, and many more.
- **Voice Search:** Use the Roku mobile app or a compatible voice remote to search for movies, TV shows, actors, and directors across top channels.
- **Live TV:** Connect an antenna to watch over-the-air broadcast TV. The Roku Smart Guide provides program information.

- **The Roku Channel:** Enjoy free movies, TV shows, and live TV channels.

Your browser does not support the video tag.

Video: An official introduction to RCA Roku TVs, highlighting the smart features, streaming capabilities, and ease of use.

7. CONNECTIONS

The RCA Roku Smart LED TV offers various input and output options:

- **HDMI:** 2x HDMI ports for connecting high-definition devices like Blu-ray players, game consoles, or cable boxes.
- **VGA:** For connecting a computer.
- **RF:** For connecting an antenna for over-the-air broadcasts.
- **YPBPR (Component Video):** For connecting older video devices.
- **AV AUDIO/VIDEO (Composite):** For connecting standard definition devices.
- **COAXIAL:** Digital audio output.
- **PC AUDIO:** Audio input for VGA connection.

8. MAINTENANCE

To ensure the longevity and performance of your TV:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs. Do not spray liquid directly onto the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to clean the TV cabinet.
- **Ventilation:** Keep the ventilation openings clear of dust and debris.
- **Power Cord:** Regularly check the power cord for any damage.

9. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

Problem	Solution
No Power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Check if the outlet has power.
No Picture / Black Screen	Verify the correct input source is selected. Check all cable connections to external devices. Try restarting the TV.
No Sound	Check the volume level and ensure the TV is not muted. Verify audio cable connections for external devices.
Remote Control Not Working	Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot Connect to Wi-Fi	Ensure your Wi-Fi router is on and within range. Re-enter the Wi-Fi password carefully. Try restarting your router and the TV.



10. SPECIFICATIONS





Feature	Specification
Brand	RCA
Model Number	RTR3260
Screen Size	32 Inches
Display Technology	LED
Resolution	720p
Refresh Rate	60 Hz
Aspect Ratio	16:9
Connectivity	2x HDMI, VGA, RF, YPBPR, AV AUDIO/VIDEO, COAXIAL, PC AUDIO
Product Dimensions	8"D x 28.8"W x 19.1"H
Item Weight	13 Pounds

11. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your TV or visit the official RCA website. Contact customer service for assistance with product registration, troubleshooting, or service requests.

Related Documents - RTR3260

 <p>RCA • Roku TV Instruction Manual Models: RTR3260-US • RTR3261-CA</p>	<p>RCA Roku TV Instruction Manual for RTR3260-US and RTR3261-CA</p> <p>Comprehensive instruction manual for RCA Roku TV models RTR3260-US and RTR3261-CA, covering setup, safety, connections, features, troubleshooting, and warranty information.</p>
 <p>RCA MODEL NO. RPJ135 Standard HD Projector Includes Roku® Streaming Stick® USER MANUAL</p>	<p>RCA RPJ135 Standard HD Projector with Roku Streaming Stick - User Manual</p> <p>Instruction manual for the RCA RPJ135 Standard HD Projector, including setup, operation, troubleshooting, and warranty information for the projector and integrated Roku Streaming Stick.</p>

	<p>RCA Roku TV Instruction Manual</p> <p>This instruction manual provides detailed guidance for setting up and using your RCA Roku TV, including safety precautions, connection instructions, troubleshooting tips, and warranty information.</p>
	<p>RCA Ultra HD Smart TV Safety Precautions and Getting Started Guide</p> <p>Comprehensive safety precautions, important instructions, accessories list, and getting started guide for RCA Ultra HD Smart TVs, including remote control and battery information.</p>
	<p>RCA RTR4061-CA Roku TV User Guide</p> <p>This user guide provides comprehensive instructions for the RCA RTR4061-CA Roku TV, covering safety, setup, connections, features, troubleshooting, and warranty information.</p>
	<p>RCA RPJ133-B Home Theater Projector User Manual with Roku Express+</p> <p>User manual for the RCA RPJ133-B Home Theater Projector, detailing setup, operation, connections, menu settings, specifications, and warranty. Includes integration guide for the Roku Express+ streaming device.</p>