

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SE](#) /

› **SE Tent Setup/Breakdown Kit in Mesh Draw String Bag (8 PC.) - SK058**

SE SK058

SE Tent Setup/Breakdown Kit (8 PC.)

Model: SK058

INTRODUCTION

The SE SK058 Tent Setup/Breakdown Kit is an 8-piece set designed to assist with the efficient assembly and disassembly of tents. This comprehensive kit includes essential tools for driving stakes, maintaining cleanliness, and easily removing stakes from the ground. It is suitable for various outdoor activities such as camping, hiking, and scouting, providing convenience for both novice and experienced campers.



Figure 1: All 8 components of the SE Tent Setup/Breakdown Kit, including the mesh bag, dual-head mallet, stake puller, four tent stakes, hand broom, and dustpan.

SAFETY INFORMATION

Always exercise caution when using tools. Keep hands and fingers clear of striking surfaces. Ensure stakes are driven into stable ground to prevent injury. Store all components in the mesh bag when not in use to prevent loss and protect items. Keep out of reach of children.

COMPONENTS OVERVIEW

The SK058 kit includes the following 8 pieces:

- **Dual-Head Mallet:** Used for driving tent stakes into the ground. Features two different striking surfaces.
- **Extruder (Stake Puller):** Designed to easily remove stubborn tent stakes from the ground.
- **Tent Stakes (4 pieces):** Four 10-inch long tent pegs with a flat striking head for securing tents.
- **Hand Broom:** For sweeping debris and dirt from tent floors or campsites.
- **Dustpan:** Companion to the hand broom for collecting swept debris.
- **Mesh Draw String Bag:** For convenient storage and transport of all kit components.

SETUP INSTRUCTIONS

To set up your tent using the kit's components:

1. **Position Tent:** Lay out your tent in the desired location according to its specific setup instructions.
2. **Place Stakes:** Position the tent stakes at the designated anchor points of your tent.
3. **Drive Stakes:** Use the *dual-head mallet* to firmly drive each tent stake into the ground. Strike the flat head of the stake until it is securely anchored and the tent is taut.



Figure 2: Demonstrates the proper technique for using the dual-head mallet to drive a tent stake securely into the ground.

OPERATING INSTRUCTIONS

Tent Breakdown (Stake Removal)

When it's time to pack up your tent, use the extruder to remove stakes:

1. **Attach Extruder:** Hook the end of the *extruder* (stake puller) under the head of a tent stake.

2. **Pull Stake:** Apply steady, upward pressure to the extruder handle to leverage the stake out of the ground. For very stubborn stakes, a slight wiggling motion may help.
3. **Repeat:** Continue this process for all remaining tent stakes.

Campsite Cleanliness

Maintain a clean tent and campsite using the broom and dustpan:

- Use the *hand broom* to sweep dirt, leaves, and other debris from the tent floor or immediate campsite area.
- Collect the swept debris with the *dustpan* for proper disposal.

MAINTENANCE

Proper maintenance ensures the longevity of your kit:

- **Cleaning:** After each use, wipe down the mallet, stakes, and extruder to remove any dirt or moisture. The broom and dustpan can be rinsed with water if necessary and allowed to air dry completely.
- **Storage:** Ensure all components are clean and dry before storing them in the mesh draw string bag. Store the kit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect all components for signs of wear or damage. Replace any damaged parts to ensure safe and effective use.






Figure 3: The complete SE Tent Setup/Breakdown Kit neatly stored within its mesh draw string bag, ready for transport or storage.

TROUBLESHOOTING

- Stakes Difficult to Drive:** If the ground is very hard, try to find a slightly softer spot. Ensure you are striking the stake head squarely with the mallet.
- Stakes Difficult to Remove:** Use the extruder as directed. If a stake is particularly stubborn, try wiggling it slightly while pulling, or rotate it a quarter turn before pulling.
- Kit Components Dirty:** Refer to the "Maintenance" section for cleaning instructions.

SPECIFICATIONS

Brand	SE
Model Number	SK058
Number of Pieces	8
Item Weight	Approximately 2.05 pounds (0.93 kg)
Product Dimensions	4.5 x 11.75 x 3 inches (11.43 x 29.85 x 7.62 cm)

UPC	706569060577
Included Components	Dual-head mallet, Extruder, 4 Tent Stakes, Hand Broom, Dustpan, Mesh Draw String Bag

WARRANTY AND SUPPORT

Specific warranty information for the SE SK058 Tent Setup/Breakdown Kit is not provided in this manual. For details regarding warranty coverage, returns, or product support, please refer to the original purchase documentation or contact the seller directly.

You may also visit the official SE brand store for additional information and support [SE Brand Store on Amazon](#).

© 2024 SE. All rights reserved.

Manual Version: 1.0