

[Manuals.plus](#) /

› [RECCAZR](#) /

› RECCAZR SP2040 Computer Speakers User Manual

RECCAZR SP2040

RECCAZR SP2040 Computer Speakers User Manual

MODEL: SP2040

Product Overview

The RECCAZR SP2040 Surround Computer Speakers are designed to deliver rich and strong stereo sound for various devices. Featuring built-in four loudspeaker diaphragms and a subwoofer, these multimedia speakers enhance your audio experience for music, movies, and games. Their compact design and USB power make them suitable for desktop, laptop, and portable use.



Image: Front view of the RECCAZR SP2040 Computer Speakers, showcasing their compact design and blue accents.

Key Features:

- **Rich and Strong Stereo Sound:** Built-in four loudspeaker diaphragms and subwoofer multimedia speakers provide clear, powerful audio.
- **Compact Design:** Small size allows for easy placement on desks and portability for on-the-go use.
- **One-Finger Control:** Convenient in-line control for power and volume adjustments.
- **Multiple Device Compatibility:** Compatible with PCs, laptops, desktops, notebooks, Kindle Fire, smartphones, tablets, MP3, MP4 players, and more.
- **Plug and Play:** USB powered with a 3.5mm audio input, requiring no additional drivers for operation.

Setup Guide

1. Unpacking

Carefully remove all components from the packaging. Ensure you have both speakers, the integrated USB power cable, and the 3.5mm audio input cable.



Image: The two RECCAZR SP2040 speakers with their connected cables, ready for setup.

2. Connections

1. **Power Connection:** Plug the USB cable into an available USB port on your computer, laptop, or a 5V/0.5A max USB wall adapter.
2. **Audio Connection:** Insert the 3.5mm audio jack into the audio output port of your device (e.g., computer, smartphone, tablet).
3. **Speaker Placement:** Position the two speakers on either side of your device for optimal stereo sound.

63 inch

Wire length




Image: RECCAZR SP2040 speakers connected to a laptop via USB and 3.5mm audio jack, illustrating the plug-and-play setup.

Note: Ensure both the USB cable and the 3.5mm audio cable are connected for proper functionality.

Operation

1. Power On/Off and Volume Control

- The speakers are powered on automatically when the USB cable is connected to a power source.
- Use the in-line control knob to adjust the volume. Turn clockwise to increase volume, counter-clockwise to decrease.



Image: Close-up of the in-line volume controller, showing the knob for easy audio adjustment.

2. LED Lighting Control

The speakers feature dynamic LED lighting. If your model includes an in-line remote with LED controls, use the designated buttons to:

- Turn LED lights on or off.
- Cycle through different color modes or static colors.

Your browser does not support the video tag.

Video: A seller demonstrating the RECCAZR SP2040 speakers, highlighting their compact size, RGB lighting effects, and the in-line volume control. The video shows the speakers changing colors and the user adjusting the sound.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store speakers in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid bending or twisting cables excessively to prevent damage.

Troubleshooting

Issue	Possible Solution
No sound	Ensure both USB power and 3.5mm audio cables are securely connected. Check the volume level on both the in-line controller and your connected device. Verify that the correct audio output device is selected on your computer/laptop.
Distorted sound	Lower the volume on both the speakers and your device. Ensure audio cables are not damaged or loosely connected. Test with a different audio source to rule out source issues.
LED lights not working	Ensure the USB power cable is connected. If your model has an LED on/off button on the in-line remote, press it to activate the lights.

Technical Specifications

Feature	Detail
Model Name	SP2040
Speaker Type	Computer, Subwoofer, Surround Sound
Connectivity Technology	USB
Power Source	USB POWERED
Speaker Maximum Output Power	6 Watts
Audio Output Mode	Stereo, Surround
Speaker Size	2.5 Inches
Subwoofer Diameter	52 Millimeters
Impedance	4 Ohm
Product Dimensions	3.35"D x 3.74"W x 5.71"H
Item Weight	1.32 Pounds
Included Components	Computer Speakers

Important Safety Information

Please keep away from children. Supporting 5V 0.5A maximum. Do not expose the device to water or excessive moisture. Avoid disassembling the speakers, as this may void the warranty and pose a safety risk.

Warranty and Support

The RECCAZR SP2040 speakers come with a Limited Warranty. For specific warranty terms and conditions, please refer to the product packaging or contact RECCAZR customer support.

For any questions, technical assistance, or support inquiries, please visit the official RECCAZR website or contact their customer service team. We value your feedback and are committed to providing assistance.



Image: Graphic indicating 24 hours, 365 days customer support from the RECCAZR Service Team.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question