

Blackweb BWA17HO003

Blackweb BWA17HO003 Gaming Mouse User Manual

Model: BWA17HO003

INTRODUCTION

This manual provides instructions for the setup, operation, maintenance, and troubleshooting of your Blackweb BWA17HO003 Gaming Mouse. This mouse is designed for an enhanced gaming experience, featuring an adjustable optical sensor, customizable RGB lighting, and programmable buttons.

PACKAGE CONTENTS

- Blackweb BWA17HO003 Gaming Mouse
- User Manual (this document)
- Software CD (or download instructions)

SYSTEM REQUIREMENTS

- Operating System: Windows XP or newer
- Hard Disk Space: 180 MB for software installation
- Available USB Port

SETUP

1. Connecting the Mouse

1. Locate an available USB port on your computer.
2. Plug the USB connector of the Blackweb BWA17HO003 Gaming Mouse into the USB port.
3. Your operating system will typically detect and install the necessary drivers automatically.



Figure 1: Blackweb BWA17HO003 Gaming Mouse connected to a computer. The image shows the mouse from a top-down perspective, highlighting its ergonomic design and the USB cable extending from the front.

2. Software Installation

For full customization options, including programmable buttons and RGB lighting effects, install the Blackweb Gaming

Mouse software.

- Insert the provided software CD into your computer's CD/DVD drive, or download the latest software from the official Blackweb support website (refer to packaging for URL).
- Follow the on-screen instructions to complete the installation.
- Once installed, launch the software to configure your mouse settings.

OPERATING INSTRUCTIONS

Basic Functions

- **Left Click:** Primary action button.
- **Right Click:** Secondary action button, typically for context menus.
- **Scroll Wheel:** Scroll up or down in documents and web pages. Can also be pressed for a middle-click function.

DPI Adjustment

The mouse features an adjustable DPI switch to change cursor sensitivity on the fly. DPI (Dots Per Inch) determines how far the cursor moves on screen relative to the physical movement of the mouse.

- Locate the DPI switch button, typically positioned behind the scroll wheel.
- Press the DPI switch button to cycle through available DPI settings (200-3200 DPI).
- The current DPI setting may be indicated by a change in the mouse's LED lighting color or pattern, depending on your software configuration.



Figure 2: Location of the DPI switch button on the Blackweb BWA17HO003 Gaming Mouse. The image highlights the button positioned centrally on the mouse body, behind the scroll wheel.

Programmable Buttons

The Blackweb BWA17HO003 Gaming Mouse includes 6 programmable buttons. These can be customized using the

Blackweb Gaming Mouse software.

1. Open the Blackweb Gaming Mouse software.
2. Navigate to the "Button Assignment" or "Macro" section.
3. Select the button you wish to program.
4. Assign a function, macro, or key combination to the selected button.
5. Save your changes. Up to 5 customized profiles can be stored.

RGB Lighting Customization

Personalize your mouse with custom colors and lighting effects (pulsing, blinking) through the Blackweb Gaming Mouse software.

1. Launch the Blackweb Gaming Mouse software.
2. Go to the "Lighting" or "RGB Effects" section.
3. Choose your desired color, effect type (e.g., static, breathing, spectrum cycling), and speed.
4. Apply the settings to your mouse.

MAINTENANCE

Cleaning the Mouse

Regular cleaning helps maintain optimal performance and extends the lifespan of your mouse.

- Disconnect the mouse from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the exterior of the mouse.
- For crevices and around buttons, use a cotton swab or compressed air to remove dust and debris.
- Avoid using harsh chemicals, abrasive cleaners, or submerging the mouse in liquid.
- Ensure the mouse is completely dry before reconnecting it to your computer.




Figure 3: Illustrative image of cleaning the Blackweb BWA17HO003 Gaming Mouse. The image shows a hand gently wiping the mouse surface with a soft cloth, emphasizing careful maintenance.

Problem	Possible Cause	Solution
Mouse not responding	Loose USB connection, faulty USB port, driver issue.	• Ensure the USB cable is securely plugged into the computer. • Try a different USB port. • Restart your computer. • Reinstall the mouse drivers or software.
Cursor movement is erratic or slow	Dirty optical sensor, incorrect DPI setting, uneven mouse pad surface.	• Clean the optical sensor on the bottom of the mouse. • Adjust the DPI setting using the DPI switch button. • Use the mouse on a clean, uniform surface or a quality mouse pad.
Programmable buttons not working	Software not installed, incorrect button assignment, software conflict.	• Ensure the Blackweb Gaming Mouse software is installed and running. • Verify button assignments within the software. • Check for software updates or reinstall the software.
RGB lighting not functioning	Software settings, power issue.	• Check RGB lighting settings in the Blackweb Gaming Mouse software. • Ensure the mouse is receiving adequate power (try a different USB port).

SPECIFICATIONS

Brand	Blackweb
Model	BWA17HO003
Movement Detection Technology	Optical
DPI Sensitivity	Adjustable from 200-3200 DPI
Number of Buttons	6 (Programmable)
Hand Orientation	Ambidextrous
Compatible Devices	Personal Computer
Operating System Compatibility	Windows XP and newer
Power Source	USB Powered

Item Weight	7.84 ounces
Special Feature	Ergonomic Design

WARRANTY AND SUPPORT

Specific warranty information for the Blackweb BWA17HO003 Gaming Mouse is typically provided with the product packaging or available on the official Blackweb website. Please refer to those resources for details regarding warranty coverage and terms.

For technical support or further assistance, please visit the Blackweb support website or contact their customer service department. Contact details are usually found on the product packaging or the official brand website.

© 2023 Blackweb. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question