



Manuals.plus /

- › Adonit /
- › Adonit Dash 3 Universal Stylus Instruction Manual (Model ADJD3B)

## Adonit ADJD3B

# Adonit Dash 3 Universal Stylus Instruction Manual

Model: ADJD3B | Brand: Adonit

## 1. INTRODUCTION

---

The Adonit Dash 3 is a universal rechargeable active fine-point digital stylus designed for use with most capacitive touchscreens, including iPhones, Android phones, iPads, tablets, and laptops. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Dash 3 stylus to ensure optimal performance.



Image 1.1: The Adonit Dash 3 Stylus in Black.

## 2. PRODUCT OVERVIEW

---

The Adonit Dash 3 offers a seamless and precise writing experience. Key features include:

- **Fine Point Tip:** The improved 1.9mm PixelPoint tip provides a precise and responsive feel, mimicking writing on paper.
- **Instant Activation:** Simply click the button once to turn on the stylus. No Bluetooth pairing is required, allowing for immediate use with any note-taking, drawing, or sketching app.
- **Integrated Carrying Clip:** A classic pen-clip design allows for secure and convenient portability.
- **Universal Compatibility:** Works with a wide range of iOS and Android capacitive touchscreens, including various models of iPhone, iPad, Samsung Galaxy, Pixel, HTC, LG, Dell, and more.
- **Rechargeable Battery:** Provides up to 14 hours of continuous use on a single charge. Recharges fully in approximately 45 minutes.

## COMPATIBILITY

Dash 3 works on iOS touchscreens and Android devices with capacitive touchscreens.



Image 2.1: Labeled diagram highlighting the design features of the Adonit Dash 3 stylus.

## 3. SETUP

### 3.1 Unboxing

Upon opening the package, ensure all components are present:

- Adonit Dash 3 Stylus
- USB Charger





Image 3.1: The Adonit Dash 3 stylus and its included USB charger.

### **3.2 Initial Charge**

Before first use, fully charge your Dash 3 stylus.

1. Connect the included USB charger to a power source (e.g., computer USB port, power bank, USB wall adapter).

2. Attach the magnetic end of the charger to the charging port at the top of the stylus.
3. The LED indicator on the stylus will show a red light during charging.
4. Once fully charged (approximately 45 minutes), the LED light will turn green.

## RECHARGABLE

Sketch with Dash 3 for up to 14 hours of continuous use - recharge in just 45 minutes.



Image 3.2: The Adonit Dash 3 stylus connected to its magnetic USB charger, plugged into a laptop.

### 3.3 Powering On/Off

To power on the Dash 3, simply click the button located at the top of the stylus. The LED light will illuminate blue. To power off, click the button again.




Image 3.3: Activating the Adonit Dash 3 stylus by pressing the power button.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Basic Usage

The Adonit Dash 3 is designed for immediate use without complex setup:

1. Ensure the stylus is powered on (blue LED).
2. Open any note-taking, drawing, or sketching application on your compatible device.
3. Begin writing, drawing, or navigating your device's interface as you would with a traditional pen or your finger.



Image 4.1: The fine 1.9mm PixelPoint tip of the Adonit Dash 3 stylus.

## 4.2 Using with Applications

The Dash 3 enhances interaction with various applications. Below are examples of its use with creative and productivity apps:

Your browser does not support the video tag.

Video 4.2.1: Demonstrating the Adonit Dash 3's precision and responsiveness while playing a game on a smartphone.

Your browser does not support the video tag.

Video 4.2.2: Showcasing the Adonit Dash 3's capabilities for sketching and capturing daily life using the Concepts App.

Your browser does not support the video tag.

Video 4.2.3: Illustrating how the Adonit Dash 3 can be used for deceptively challenging puzzles in the Brain It On game.

Your browser does not support the video tag.

Video 4.2.4: Demonstrating the Adonit Dash 3's functionality with the Post-It App for capturing and organizing notes.

Your browser does not support the video tag.

Video 4.2.5: Highlighting the precision of the Adonit Dash 3 when used with an Apple Watch for tasks like replying to messages.

## 5. CHARGING

The Dash 3 features a built-in rechargeable Lithium Polymer battery. Follow these steps to charge your stylus:

1. Locate the magnetic charging port at the top of the stylus.
2. Connect the magnetic USB charger to the stylus.
3. Plug the USB end of the charger into any standard USB power source.
4. The LED indicator will glow red while charging.
5. When charging is complete, the LED indicator will turn green.
6. A full charge takes approximately 45 minutes and provides up to 14 hours of continuous use.

## 6. COMPATIBILITY

The Adonit Dash 3 is universally compatible with most capacitive touchscreens. This includes, but is not limited to, the following devices:

- **iPads:** iPad mini 6, iPad mini 5, iPad 8, iPad 7, iPad 6, iPad 5, iPad 4, iPad 3, iPad Pro 11 & 12.9 (2018-2021)
- **iPhones:** iPhone 13, iPhone Pro, iPhone Pro Max, iPhone 12, iPhone 12 Pro Max, iPhone 12 Pro, iPhone X, iPhone XR, iPhone 8, iPhone 8 Plus, iPhone 7, iPhone 7 Plus, iPhone 6s, iPhone 6s Plus, iPhone 6, iPhone 6 Plus, iPhone 5, iPhone 5c, iPhone 5s
- **Android Devices:** Android LG G5, HTC 10, HTC Bolt, LG V20, Pixel, Samsung Galaxy S7 Edge, Pixel C, Nvidia Shield Tablet K1, Samsung Galaxy Tab, Sony Xperia Z4, and other popular Android phones and tablets.



Image 6.1: The Adonit Dash 3 stylus demonstrating compatibility with both Android and iOS tablets.

## 7. MAINTENANCE

---

Proper care will extend the life of your Adonit Dash 3 stylus:

- **Cleaning:** Use a soft, dry cloth to wipe the stylus body. Avoid abrasive cleaners or solvents.
- **Tip Care:** The PixelPoint tip is durable but can be damaged by excessive force or drops. Avoid pressing too hard on the screen.
- **Storage:** Store the stylus in a safe place when not in use, ideally clipped to a notebook or pocket, to prevent damage.
- **Charging:** Do not leave the stylus connected to the charger for extended periods after it is fully charged.

## 8. TROUBLESHOOTING

---

If you encounter issues with your Adonit Dash 3, try the following steps:

- **Stylus Not Turning On:** Ensure the stylus is fully charged. Connect it to the USB charger and wait for the green LED indicator.
- **Stylus Not Responding:** Make sure the stylus is powered on (blue LED). If it is, try turning it off and on again. Ensure your device's screen is clean and free of debris.
- **Inaccurate Input:** Check if the stylus tip is clean. Sometimes, a dirty screen or tip can affect accuracy.
- **Charging Issues:** Verify that the USB charger is securely connected to both the stylus and the power source. Try a different USB port or power adapter.
- **Intermittent Disconnection:** While the Dash 3 does not use Bluetooth, ensure there are no strong electromagnetic interferences nearby that might affect capacitive touch.

## 9. SPECIFICATIONS

---

Feature	Detail
Model Number	ADJD3B
Color	Black
Brand	Adonit
Material	Aluminum
Item Weight	12 Grams
Item Dimensions (L x W x H)	0.33 x 0.33 x 5.59 inches
Number of Batteries	1 Lithium Polymer (included)
Batteries Required?	Yes
Charging Time	45 minutes
Built-In Media	Stylus, USB Charger
Unit Count	1.0 Count
UPC	847663022440
GTIN	00847663022440

## 10. WARRANTY AND SUPPORT

---

Adonit provides a 12-month warranty for the Dash 3 stylus and its parts, ensuring quality and durability. For further assistance or warranty claims, please refer to the official Adonit support channels.

**Warranty Description:** 1 year