

manuals.plus /

- › [Ikea](#) /
- › [IKEA Vesken 4-Shelf Unit - White - Assembly and User Manual](#)

Ikea 403.078.66

IKEA Vesken 4-Shelf Unit - White - Assembly and User Manual

1. PRODUCT OVERVIEW

The IKEA Vesken 4-shelf unit is a versatile and compact storage solution designed for various spaces within your home. This white unit features four shelves, providing ample space for organizing items. Its lightweight plastic construction makes it easy to move and clean.





This image displays the fully assembled IKEA Vesken 4-shelf unit. It is white, made of plastic, and features four perforated shelves supported by four vertical posts. The unit is designed for compact storage.

2. IMPORTANT SAFETY INFORMATION

WARNING: To ensure stability, securely mount the shelf unit to the floor or wall. Do not load the shelf unit with more than 13 kilograms (28.6 lbs) to prevent any risk of tipping or collapse. Overloading can cause serious injury or damage.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact your retailer for assistance.

- 4 x Shelf panels
- 8 x Vertical posts (connecting pieces)
- 4 x Feet/Base posts
- Assembly instructions leaflet

4. ASSEMBLY INSTRUCTIONS

Before You Begin:

- Clear a spacious area for assembly.
- Inspect all parts for any damage.
- No tools are typically required for Vesken shelf assembly, as parts usually snap together.

Step-by-Step Assembly:

1. **Attach Base Posts:** Take the four feet/base posts and firmly attach them to the bottom of the first shelf panel. Ensure they click securely into place.
2. **Add First Set of Vertical Posts:** Insert the four vertical connecting posts into the top of the first shelf panel, aligning them with the holes.
3. **Place Second Shelf:** Carefully lower the second shelf panel onto the vertical posts, pressing down until it locks into position.
4. **Repeat for Remaining Shelves:** Continue adding vertical posts and shelf panels in sequence until all four shelves are assembled.
5. **Final Check:** Once assembled, gently rock the unit to ensure all connections are secure and the unit is stable.
6. **Secure to Wall/Floor (Recommended):** For added safety, especially in homes with children or pets, use appropriate wall or floor anchoring hardware (sold separately) to secure the unit. Refer to the safety warning in Section 2.

5. USAGE GUIDELINES

The Vesken 4-shelf unit is designed for indoor use to store various household items. Distribute weight evenly across the shelves. Avoid placing heavy items on the top shelves to maintain stability. This unit is suitable for bathrooms, laundry rooms, or other areas where compact storage is needed.

6. CARE AND MAINTENANCE

- **Cleaning:** Wipe clean with a soft cloth dampened with water and a mild dish detergent or soap, if necessary.
- **Drying:** Wipe dry with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or chemical solvents as they may damage the plastic surface.
- **Regular Checks:** Periodically check that all connections are still secure, especially if the unit is moved.

7. TROUBLESHOOTING

- **Unit is wobbly:** Ensure all posts are fully inserted and clicked into place. If the issue persists, check if the floor surface is even. Consider using wall anchoring hardware for increased stability.
- **Parts do not fit:** Double-check that you are using the correct parts for each step as per the assembly instructions. Apply firm, even pressure when connecting pieces.
- **Shelf sags:** Ensure the total weight on the shelf does not exceed the recommended maximum load of 13 kg. Distribute items evenly.

8. PRODUCT SPECIFICATIONS



Brand	IKEA
Model Name	Vesken
Model Number	403.078.66
Color	White
Dimensions (L x W x H)	36 x 23 x 100 cm (14.2 x 9.1 x 39.4 inches)
Weight Capacity	13 Kilograms (28.6 lbs)
Number of Shelves	4
Material	Plastic
Assembly Required	Yes

9. WARRANTY AND SUPPORT


This IKEA product is covered by a standard manufacturer's warranty. For specific warranty details, including duration and terms, please refer to the documentation provided with your purchase or visit the official IKEA website. For customer support, spare parts, or further assistance, please contact IKEA customer service directly.

Keep your proof of purchase for any warranty claims.

Related Documents - 403.078.66

	<p>IKEA DYNAN Storage Series Buying Guide</p> <p>A comprehensive guide to the IKEA DYNAN storage series, detailing its features, combinations, parts, and services. Learn how to create flexible storage solutions for bathrooms and other spaces in your home.</p>
	<p>VESKEN Shelf Unit Assembly and Safety Instructions</p> <p>Comprehensive guide for assembling the IKEA VESKEN shelf unit, including crucial safety information on preventing furniture tip-over with wall attachment instructions.</p>


KALLAX



IKEA KALLAX Shelf Unit Assembly Instructions

Comprehensive assembly guide for the IKEA KALLAX shelf unit, including safety warnings and step-by-step instructions for building and wall mounting. Ensure safe installation to prevent tip-over accidents.

KALLAX



[KALLAX Shelf Unit Assembly Instructions | IKEA](#)

Comprehensive assembly instructions and safety warnings for the IKEA KALLAX shelf unit. Learn how to safely build and secure your KALLAX storage solution to prevent tip-over accidents.


FJÄLLBO



FJÄLLBO Shelving Unit Assembly Instructions and Safety Guide

Comprehensive guide for assembling the IKEA FJÄLLBO shelving unit, including essential safety warnings about furniture tip-over and instructions for secure wall mounting. Features a parts list and step-by-step assembly process.

VARIERA



VARIERA Shelf Assembly Instructions - IKEA

Detailed assembly guide for the IKEA VARIERA shelf unit (model AA-741489-4). Follow step-by-step instructions and part details for proper construction.