

LEGO 10258

LEGO Creator Expert London Bus 10258 Instruction Manual

Model: 10258 | Brand: LEGO

INTRODUCTION

This manual provides detailed instructions for assembling and understanding the LEGO Creator Expert London Bus, model 10258. This building kit allows you to construct a highly detailed replica of the iconic double-decker London bus, featuring authentic design elements and functional components. Designed for experienced builders, this set offers a challenging and rewarding construction experience.

PRODUCT OVERVIEW

The LEGO Creator Expert London Bus 10258 is a meticulously designed model consisting of 1686 pieces. Key features include:

- **Authentic Exterior:** Bright red curved bodywork, panoramic windshield, large windows, specially designed standard-tread tires, and a destination sign.
- **Detailed Interior:** Worn-look seating, an open rear boarding deck with a hand pole, ticket bin, fire extinguisher, and a half-spiral staircase leading to the upper sightseeing deck.
- **Functional Elements:** An opening hood revealing a detailed engine, a driver's cab with a sliding door, and a removable roof and upper deck for easy access to the interior.
- **Customizable Advertising:** Reversible transit advertising posters are included as printed labels, offering a choice between a 1950s or present-day London promotion.



Image 1: The fully assembled LEGO Creator Expert London Bus 10258, showcasing its iconic red double-decker design and detailed exterior.

SETUP AND ASSEMBLY

The LEGO Creator Expert London Bus 10258 is designed for builders aged 16 and up. Assembly involves following the step-by-step instructions provided in the included building guide. It is recommended to organize the 1686 pieces before beginning construction to ensure a smooth building process.

1. **Unpack Components:** Carefully open all bags containing LEGO elements.
2. **Follow Instructions:** Refer to the detailed instruction booklet for sequential assembly steps. Each step illustrates the required pieces and their placement.
3. **Attention to Detail:** Pay close attention to the orientation of bricks and the application of stickers for the destination sign and advertising posters.
4. **Verify Connections:** Ensure all bricks are firmly pressed together to create a stable and durable model.



Image 2: An adult and child engaged in the assembly process of the LEGO London Bus, demonstrating the collaborative and engaging nature of the building experience.

OPERATING THE MODEL

Once assembled, the LEGO London Bus offers several interactive features:

- **Engine Access:** The front hood can be opened to reveal the brick-built engine details.
- **Driver's Cab:** The driver's cab features a sliding door for access.
- **Interior Access:** The roof and upper deck sections are removable, allowing for a clear view and interaction with the detailed interior, including seating and various accessories.
- **Rolling Wheels:** The bus features functional wheels, allowing it to be rolled on flat surfaces.

MAINTENANCE

To ensure the longevity and appearance of your LEGO London Bus model, follow these maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush. For deeper cleaning, use a mild soap solution and rinse with clear water. Allow pieces to air dry completely before reassembly.

Avoid harsh chemicals or abrasive materials.

- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent color fading and material degradation.
- **Handling:** Handle the model carefully to avoid accidental disassembly or damage to delicate parts.

TROUBLESHOOTING

If you encounter issues during or after assembly, consider the following:

- **Missing Pieces:** Double-check all packaging and sorting areas. If a piece is genuinely missing, contact LEGO Customer Service for replacement parts.
- **Incorrect Assembly:** Review the instruction manual carefully for the specific step where an error might have occurred. Disassemble and reassemble the affected section.
- **Loose Connections:** Ensure all bricks are fully pressed together. Sometimes a slight gap can lead to instability.

SPECIFICATIONS

Product Name	LEGO Creator Expert London Bus
Model Number	10258
Item Number	6174047
Number of Pieces	1686
Recommended Age	16 years and up
Assembled Dimensions (L x W x H)	13" (34cm) long x 5" (13cm) wide x 7" (18cm) high
Item Weight	3.96 pounds
Release Date	July 30, 2017
Manufacturer	LEGO

SAFETY INFORMATION

This product contains small parts and is not suitable for children under 3 years of age due to choking hazards. The recommended age for assembly and use is 16 years and up. Always supervise younger children if they are near the assembled model or loose pieces.

WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. If you experience any issues with missing or defective parts, please contact LEGO Customer Service directly. Information regarding warranty and support can typically be found on the official LEGO website or through the contact details provided in the product packaging.

For further assistance, visit the official LEGO website: www.lego.com/service

