Lysed Ceiling Light

Lysed E26 E27 Retro Black Industrial Light Fixture Instruction Manual

Vintage Flush Mount Ceiling Light for Porch, Hallway, Kitchen, Stairway, Farmhouse

1. Product Overview

The Lysed Retro Black Industrial Light Fixture is a semi-flush mount ceiling light designed to add a vintage and rustic aesthetic to various indoor spaces. Its compact size and durable metal construction make it suitable for hallways, laundry rooms, kitchens, and entryways. This fixture is compatible with E26/E27 base bulbs, offering versatility in lighting ambiance.



This image shows the Lysed Retro Black Industrial Light Fixture, featuring its geometric metal cage design and a visible Edison-style bulb, providing a warm glow.



This image illustrates two Lysed Industrial Light Fixtures installed along a hallway ceiling, demonstrating their aesthetic appeal and suitability for such spaces.

2. Specifications

Feature	Detail
Brand	Lysed
Model Number	Ceiling Light (US4CL001US)
Color	Black Fixture

Feature	Detail
Material	Metal
Product Dimensions (L x W x H)	5.51" x 4.92" x 6.69"
Canopy Diameter	4.75" (compatible with most 4" junction boxes)
Voltage	110 Volts
Wattage	60 watts (max)
Bulb Base	E26 / E27
Light Source Type	Halogen, Incandescent, LED (Bulb NOT Included)
Installation Type	Semi-Flush Mount
Item Weight	0.75 Pounds (12 ounces)



This diagram provides the precise dimensions of the light fixture in centimeters, aiding in planning its placement.

3. Setup

Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always turn off power at the main circuit breaker or fuse box before beginning installation. Ensure all wiring is done in accordance with national and local electrical codes. If you are unsure about installation, consult a qualified electrician.

Before You Begin


Unpack all components and inspect for any damage. Ensure all parts listed in the included installation instruction are present. Mounting screws and detailed installation instructions are provided with the product.

Required Tools (Not Included):

- Screwdriver (Phillips and/or Flathead)
- Wire Strippers
- Electrical Tape
- Ladder (if installing on ceiling)
- Drill (if needed for mounting bracket)

Installation Steps

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's location and turn it off. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** Ensure the junction box is securely mounted and ready for the fixture. The updated canopy is 4.75" in diameter, compatible with most 4" junction boxes.



This image highlights the updated canopy size of 4.75 inches, designed for compatibility with standard 4-inch junction boxes.

3. **Attach Mounting Bracket:** Secure the mounting bracket to the junction box using the provided screws.
4. **Connect Wiring:** Carefully connect the fixture's wires to the corresponding wires from the junction box (typically black to black, white to white, and ground to ground). Use wire nuts to secure connections.
5. **Mount Fixture:** Align the fixture with the mounting bracket and secure it with the provided screws.
6. **Install Bulb:** Screw an E26/E27 base bulb (not included) into the fixture's socket.
7. **Restore Power:** Turn the power back on at the circuit breaker.
8. **Test Fixture:** Turn on the light switch to ensure the fixture is working correctly.


Installation

Please read below details before buying!!!

1. Mounting Bracket Size.



2. Installation.



This diagram provides a visual guide for installing the light fixture, detailing the components and their assembly sequence.

4. Operating Instructions

Once installed, the Lysed Industrial Light Fixture operates like any standard ceiling light. Simply use your wall switch to turn the light on or off. The fixture is designed to work with any E26/E27 base LED, incandescent, or CFL bulb up to 60 watts.

For dimming functionality, ensure you use a dimmable bulb in conjunction with a compatible dimmer switch (both sold separately).



This image demonstrates the light fixture in operation, showcasing the warm ambient light it produces with an appropriate bulb.



This image shows the light fixture with a cool white bulb, illustrating the brighter, more neutral light output.

5. Maintenance

Regular maintenance will help prolong the life and appearance of your light fixture.

Cleaning

- Always turn off the power to the fixture before cleaning.
- Use a soft, dry cloth to wipe down the metal surfaces.
- For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth.
- Avoid using abrasive cleaners, solvents, or polishes as they may damage the finish.

Bulb Replacement

- Ensure the power is off and the bulb has cooled down before attempting to replace it.
- Unscrew the old bulb counter-clockwise.
- Screw in the new E26/E27 base bulb clockwise until snug. Do not overtighten.
- Restore power and test the new bulb.

6. Troubleshooting

If you encounter issues with your light fixture, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wiring connection Faulty bulb	Check circuit breaker/fuse Verify all wire connections are secure (power off first!) Replace bulb with a new one
Light flickers	Loose bulb Incompatible dimmer switch/bulb Loose wiring	Tighten bulb Ensure bulb and dimmer are compatible (if applicable) Check wiring connections (power off first!)
Fixture is hot to the touch	Bulb wattage too high	Ensure bulb wattage does not exceed 60 watts. Replace with a lower wattage bulb.

If the problem persists after attempting these solutions, please contact customer support.

7. Warranty and Support

Warranty Information

This Lysed light fixture comes with a**1-year seller warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, misuse, abuse, or acts of nature.

Customer Support

For any questions, concerns, or assistance with installation or troubleshooting, please contact Lysed customer support. You can find more information and contact details by visiting the official Lysed Store on Amazon: Lysed Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question