Techni Sport TS200

Techni Sport TS200 Gaming Desk Instruction Manual

Model: TS200

Introduction Safety Information Package
Contents Assembly Features Operating Maintenance Troubleshooting Specifications Warranty Support

1. Introduction

Thank you for choosing the Techni Sport TS200 Gaming Desk. This manual provides essential information for the proper assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Figure 1: Techni Sport TS200 Gaming Desk in a complete setup.

2. Safety Information

Please observe the following safety guidelines to prevent injury or damage to the product:

- Always assemble the desk according to the provided instructions.
- Ensure all parts are securely fastened for stability, especially for monitor stands and accessories.
- Do not exceed the maximum weight recommendation of 130 pounds for the tabletop.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid placing hot items directly on the desk surface without protection.
- Do not stand or sit on the desk.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact

customer support.

- Desk Main Surface (Carbon Laminated)
- Steel Frame Components
- Elevated Monitor Stands (2 units)
- CD Rack / Storage Tray
- Cup Holder
- Headphone Holder
- Assembly Hardware (screws, bolts, etc.)
- Assembly Tools (Allen wrench, etc.)
- Instruction Manual




Figure 2: Desk dimensions and component overview.

4. Assembly Instructions

Assembly of the Techni Sport TS200 Gaming Desk is designed to be user-friendly. It is recommended that two people assemble the desk for ease and safety. All necessary assembly tools are included.

General Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Frame:** Attach the main steel frame components using the provided hardware. Ensure all connections are finger-tight before final tightening.
3. **Attach Desk Surface:** Secure the carbon laminated desk surface to the assembled frame.
4. **Install Monitor Stands:** The desk supports two configurations for the elevated monitor stands: one large stand or two individual stands. Choose your preferred setup and attach the stands securely to the desk surface.
5. **Add Accessories:** Install the interchangeable CD rack, cup holder, and headphone holder to your desired positions on either side of the desk.
6. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts using the provided tools. Do not overtighten.




Figure 3: Two assembly options for monitor stands and accessory placement.

Your browser does not support the video tag.

Video 1: Product overview of the Techni Sport TS200 Gaming Desk, demonstrating its features and design.

5. Key Features

The Techni Sport TS200 Gaming Desk is designed with functionality and comfort in mind:

- **Two-Way Assembly:** Configure with one or two elevated monitor stands to suit your setup.
- **Elevated Monitor Stands:** Promotes better posture and frees up desk space.
- **Carbon Laminated Surface:** Durable and easy-to-clean desktop with a sleek finish.
- **Durable Steel Frame:** Provides a stable and robust foundation for your gaming or work setup.
- **Interchangeable Accessories:** Includes a CD rack (also suitable for game cases), cup holder, and headphone holder that can be placed on either side of the desk.
- **Ergonomic Design:** Supports comfortable long-term use for both gaming and office tasks.



Figure 4: Desk configured with two monitor stands and all accessories.

6. Operating Instructions

Using your Techni Sport TS200 Gaming Desk is straightforward. Here are tips for utilizing its features:

- **Monitor Placement:** Place your monitors on the elevated stands. Ensure the weight distribution is even and does not exceed the stand's capacity.
- **Accessory Use:** The cup holder is designed for standard beverage containers. The CD rack can store game cases or other small media. The headphone holder keeps your headset within easy reach and off the desk surface.
- **Cable Management:** Utilize the space under the desk and behind the monitor stands to route and organize your cables for a tidy setup.
- **Keyboard Tray:** The integrated keyboard storage basket provides a convenient space to store your keyboard when not in use, maximizing desktop space.

7. Maintenance

To ensure the longevity and appearance of your Techni Sport TS200 Gaming Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surface and frame with a dry, soft cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the desk surface.
- **Weight Distribution:** Distribute weight evenly across the desk surface and monitor stands to prevent stress on any single point.

8. Troubleshooting

If you encounter any issues with your Techni Sport TS200 Gaming Desk, refer to the following common solutions:

Common Issues and Solutions:

- **Desk is Unstable/Wobbly:**
  - Ensure all assembly screws and bolts are fully tightened.
  - Verify that the desk is placed on a level surface.
  - Check that all frame components are correctly aligned according to the assembly instructions.
- **Missing Parts:**
  - Double-check all packaging materials to ensure no small parts were overlooked.
  - Refer to the 'Package Contents' section and contact customer support with a list of missing items.
- **Difficulty During Assembly:**
  - Review the assembly instructions carefully, paying close attention to diagrams.
  - Ensure you are using the correct hardware for each step.
  - It is recommended to have two people for assembly.

9. Specifications

Attribute	Detail
Brand	Techni Sport
Model Number	TS200

Attribute	Detail
Product Dimensions (D x W x H)	23.5"D x 47.25"W x 41.75"H
Item Weight	41 Pounds
Maximum Weight Recommendation	130 Pounds
Color	Black
Top Material Type	Engineered Wood (Carbon Laminated)
Base Material	Metal
Number of Shelves	2 (Monitor Stands)
Required Assembly	Yes
Recommended Number of People for Assembly	2
Included Components	Cup Holder, CD Rack, Headphone Holder
Product Care Instructions	Wipe with Dry Cloth

10. Warranty Information

The Techni Sport TS200 Gaming Desk comes with a **5-year limited warranty**. This warranty covers manufacturing defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full details regarding warranty coverage and terms, please refer to the official Techni Sport website or contact customer support.

11. Customer Support

For any questions, assistance with assembly, missing parts, or warranty claims, please contact Techni Sport customer support:

- **Website:** Visit the official Techni Sport website for FAQs and support resources.
- **Contact Information:** Refer to the contact section on the Techni Sport website for phone numbers or email addresses.

Please have your model number (TS200) and proof of purchase ready when contacting support.

© 2023 Techni Sport. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question