

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CP Plus](#) /

› [CP Plus CP-UVR-0401E1-S 4 Channel DVR User Manual](#)

CP Plus CP-UVR-0401E1-S

CP Plus CP-UVR-0401E1-S 4 Channel DVR User Manual

Model: CP-UVR-0401E1-S

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your CP Plus CP-UVR-0401E1-S 4 Channel Digital Video Recorder (DVR). This device is designed for surveillance applications, allowing you to record and manage video footage from up to four cameras. Please read this manual thoroughly before using the product to ensure proper and safe operation.

2. SAFETY INFORMATION

- **Power Supply:** Use only the specified power adapter. Incorrect voltage may damage the device and void the warranty.
- **Ventilation:** Ensure adequate ventilation around the DVR. Do not block ventilation openings.
- **Environment:** Avoid exposing the DVR to extreme temperatures, humidity, dust, or direct sunlight.
- **Handling:** Handle the device with care. Avoid dropping or subjecting it to strong vibrations.
- **Servicing:** Do not attempt to open or service the DVR yourself. Refer all servicing to qualified personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- CP Plus CP-UVR-0401E1-S 4 Channel DVR Unit
- Power Adapter
- USB Mouse
- Screws for Hard Disk Drive (HDD) Installation
- Quick Start Guide

4. SETUP

4.1. Hard Disk Drive (HDD) Installation

The CP-UVR-0401E1-S DVR is supplied without a pre-installed hard disk drive. An HDD is required for recording video footage.

1. Unscrew and remove the top cover of the DVR unit.
2. Connect the SATA data cable and power cable from the DVR to the corresponding ports on your 3.5-inch SATA HDD.
3. Secure the HDD to the bottom of the DVR chassis using the provided screws.
4. Replace the top cover and secure it with screws.

4.2. Connecting Cameras

Connect your analog surveillance cameras to the BNC video input ports on the rear panel of the DVR. The DVR supports up to 4 cameras.

4.3. Connecting a Monitor

Connect a monitor to the DVR using either the VGA or HDMI output port on the rear panel. This allows you to view the live feed and configure settings.

4.4. Network Connection

For remote viewing and network features, connect an Ethernet cable from your router or network switch to the LAN port on the DVR's rear panel.

4.5. Power Connection

Connect the provided power adapter to the DC 12V input port on the DVR, then plug the adapter into a power outlet. The DVR will power on automatically.



Image: Front view of the CP Plus CP-UVR-0401E1-S 4 Channel DVR unit, showing its compact black design and front panel indicators.

5. OPERATING

5.1. Initial Boot and Setup Wizard

Upon first power-on, the DVR will guide you through an initial setup wizard. This typically includes setting the date/time, network configuration, and creating an administrator password. Follow the on-screen prompts.

5.2. User Interface Navigation

Use the included USB mouse to navigate the DVR's graphical user interface (GUI). Right-click to access the main menu, and left-click to select options.

5.3. Live View

After setup, the DVR will display the live view from connected cameras. You can switch between single-camera view and multi-camera grid views.

5.4. Recording Configuration

Access the 'Record' settings from the main menu to configure recording schedules, motion detection, and

other recording parameters for each camera. Ensure your HDD is formatted and recognized by the system.

5.5. Playback

To review recorded footage, select 'Playback' from the main menu. You can search for recordings by date, time, and camera channel. Use the playback controls to fast forward, rewind, and pause.

5.6. Network Access / Remote Viewing

Configure network settings (IP address, port forwarding, or P2P cloud service) to enable remote access to your DVR via a web browser or mobile application. Refer to the DVR's network settings menu for specific options.

6. MAINTENANCE

6.1. Regular Cleaning

Periodically clean the exterior of the DVR with a soft, dry cloth. Ensure ventilation openings are free from dust and debris to prevent overheating.

6.2. HDD Management

Regularly check the status of your Hard Disk Drive (HDD) through the DVR's system settings. Ensure there is sufficient storage space and that the HDD is functioning correctly. The DVR may automatically overwrite older footage when the disk is full, depending on your settings.

6.3. Firmware Updates

Check the manufacturer's official website for available firmware updates. Firmware updates can improve performance, add new features, or fix bugs. Follow the provided instructions carefully when performing an update.

7. TROUBLESHOOTING

7.1. No Power

- Ensure the power adapter is securely connected to the DVR and a working power outlet.
- Verify the power outlet is functional by plugging in another device.

7.2. No Video Signal on Monitor

- Check the VGA or HDMI cable connection between the DVR and the monitor.
- Ensure the monitor is powered on and set to the correct input source.
- Verify that cameras are properly connected and powered.

7.3. Recording Issues

- Confirm that an HDD is installed and properly formatted within the DVR's settings.
- Check the recording schedule and ensure it is enabled for the desired channels.
- Verify that the HDD has sufficient free space.

7.4. Network Connectivity Problems

- Ensure the Ethernet cable is securely connected to the DVR and your router/switch.
- Check the network settings in the DVR to confirm correct IP address configuration (DHCP or static IP).
- Verify your router is functioning correctly and providing network access.

8. SPECIFICATIONS

Feature	Specification
Model Number	CP-UVR-0401E1-S
Number of Channels	4
Connectivity Technology	USB, Ethernet
Total USB Ports	4
Media Format Digital Video	HDD (Hard Disk Drive, not included)
Package Dimensions	33.6 x 30.6 x 8.6 cm
Item Weight	1.44 kg
Batteries Required	No

9. WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official CP Plus website. Keep your purchase receipt as proof of purchase for warranty claims.

10. SUPPORT

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact CP Plus customer support. Contact details can typically be found on the manufacturer's website or in the product packaging.