Ariete AT4056035810

Ariete Espresso Machine Portafilter (AT4056035810) Instruction Manual

Model: AT4056035810 | Brand: Ariete

1. Product Overview

This document provides instructions for the Ariete Espresso Machine Portafilter, part number AT4056035810. This portafilter is a replacement component designed for specific Ariete espresso machine models, essential for holding ground coffee and facilitating the pressurized water extraction process to brew espresso.



Image 1.1: The Ariete Espresso Machine Portafilter, featuring a black handle and a chrome-plated head. Two stainless steel filter baskets, one for a single shot and one for a double shot, are shown alongside the portafilter.

Key Features:

- Original replacement parts accessory
- High-quality metal construction
- Ensures good fit and compatibility with specified models

2. Compatibility

This portafilter is compatible with various Ariete espresso machine models, including the MCE24 and Cafè Retro series. Please verify your machine's model number against the list below to ensure proper fit and function. If your model is not

listed, contact customer support for assistance before purchase.

Compatible Models (Partial List):

- Ariete Cafè Retro (Article numbers: 00M138810AR0, 00M138830LDDK, 00M138830LDCH, 00M138830LDCZ, 00M138831LDUK, 00M138831LDDK, 00M138831LDCH, 00M138831LDCZ, 00M138835LDUK, 00M138835LDDK, 00M138835LDCH, 00M138835LDCZ, 00M138820ALUK, 00M138826ALUK, 00M138830LDUK, 00M138835LDD, 00M138831LDD, 00M138811AR0, 00M138801STD, 00M138801ALA, 00M138810LDD, 00M1388R1AR0, 00M138802STD, 00M138802ALA, 00M138804STD, 00M138803STD, 00M138803ALA, 00M138830AR0, 00M138831AR0, 00M1388830LDD, 00M138827ALUK)
- Aldi Ambiano Model 1389A (as reported by users)

Note: The provided list is based on product information and user feedback. Always cross-reference with your specific machine's documentation.

3. Setup and Installation

Proper installation of the portafilter is crucial for optimal espresso extraction and machine safety. Ensure the espresso machine is turned off and unplugged before proceeding.

1. **Unpack:** Carefully remove the new portafilter and filter baskets from its packaging. Inspect for any damage.
2. **Select Filter Basket:** Choose the appropriate filter basket (single or double shot) for your desired coffee quantity. Place it firmly into the portafilter head.
3. **Insert Coffee:** Fill the filter basket with freshly ground espresso coffee. Do not overfill.
4. **Tamp Coffee:** Use a coffee tamper to press the ground coffee evenly and firmly into the basket. This creates a compact puck for proper extraction.
5. **Attach to Machine:** Align the portafilter head with the group head of your espresso machine. Insert the portafilter and rotate it firmly to the right until it is securely locked into place. It should feel snug and not wobble.

Caution: Do not force the portafilter into the group head. If it does not seat correctly, check for obstructions or misalignment.

4. Operating Instructions

Once the portafilter is correctly installed with coffee, you can proceed with brewing espresso according to your espresso machine's specific operating instructions.

1. **Prepare Machine:** Ensure your espresso machine is preheated and the water reservoir is filled.
2. **Place Cup:** Position your espresso cup(s) under the portafilter spouts.
3. **Start Brewing:** Activate the brewing cycle on your espresso machine. Hot, pressurized water will flow through the coffee in the portafilter, extracting the espresso.
4. **Monitor Extraction:** Observe the coffee flow. It should be a steady, thin stream with a rich, golden-brown crema.
5. **Stop Brewing:** Stop the brewing cycle once the desired volume of espresso is achieved, typically 25-30 seconds for a standard shot.
6. **Remove Portafilter:** Carefully rotate the portafilter to the left to unlock and remove it from the group head. Be aware that the portafilter and spent coffee grounds will be hot.

5. Maintenance and Cleaning

Regular cleaning and maintenance of your portafilter are essential for hygiene, optimal performance, and longevity.

1. **After Each Use:**

- Remove the spent coffee puck from the filter basket. Tap the portafilter against a knock box or trash bin to dislodge the puck.
- Rinse the filter basket and portafilter head under hot running water to remove any coffee residue.
- Wipe the portafilter head and handle with a clean cloth.

2. **Weekly Cleaning (Deep Clean):**
    - Remove the filter basket from the portafilter head.
    - Soak the filter basket and the metal part of the portafilter head (avoid soaking the handle if it's not fully submersible) in a solution of warm water and a specialized espresso machine cleaner (e.g., Puly Caff) for about 15-30 minutes. Follow the cleaner manufacturer's instructions.
    - Use a brush to scrub away any stubborn coffee oils or residue from the filter basket and portafilter spouts.
    - Rinse all components thoroughly with clean water to remove any cleaning solution.
    - Ensure all parts are completely dry before reassembling.

Important: Do not use abrasive cleaners or scouring pads, as these can damage the finish of the portafilter. Avoid putting the entire portafilter in a dishwasher, especially if it has a plastic handle, as high heat can cause damage.

6. Troubleshooting

If you encounter issues with your portafilter, consider the following common problems and solutions:

- **Portafilter Leaks from Group Head:**
    - **Cause:** Portafilter not securely locked, worn group head gasket, or coffee grounds on the gasket.
    - **Solution:** Ensure the portafilter is fully tightened. Clean the group head gasket area. If the gasket is old or cracked, it may need replacement.
- **Coffee Flows Too Fast/Weak Espresso:**
    - **Cause:** Coffee grounds too coarse, insufficient coffee dose, or tamping too lightly.
    - **Solution:** Use finer coffee grounds. Increase the coffee dose slightly. Tamp more firmly and evenly.
- **Coffee Flows Too Slow/No Flow:**
    - **Cause:** Coffee grounds too fine, excessive coffee dose, or tamping too hard.
    - **Solution:** Use coarser coffee grounds. Reduce the coffee dose slightly. Tamp with less force. Ensure the filter basket holes are not clogged (see Maintenance).
- **Portafilter Difficult to Attach/Remove:**
    - **Cause:** Coffee grounds or residue on the group head rim, new group head gasket, or portafilter misalignment.
    - **Solution:** Clean the group head thoroughly. New gaskets can be stiff initially; it will ease with use. Ensure correct alignment before twisting.

For issues not covered here, refer to your espresso machine's main instruction manual or contact Ariete customer support.

7. Specifications

Attribute	Detail
Brand	Ariete

Model Number (Part)	AT4056035810
Material	Metal
Product Dimensions	22.5 x 9.2 x 6.4 cm
Item Weight	0.35 Kilograms
Compatible Coffee Maker Type	Espresso Machine
Number of Items	1 (Portafilter with filter baskets)

8. Warranty and Support

For information regarding warranty coverage, please refer to the original purchase documentation or the official Ariete website. For technical support or further assistance, contact Ariete customer service through their official channels.

Note: Using non-original or incompatible parts may void your espresso machine's warranty.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question