De'Longhi 7313285789

De'Longhi Portafilter User Manual

Model: 7313285789

1. Introduction

This manual provides essential information for the proper use, maintenance, and troubleshooting of your De'Longhi original portafilter. This portafilter is a genuine replacement part designed for specific De'Longhi 'Caffe Venezia' coffee machine models.
Please read this manual thoroughly before using the product to ensure safe and efficient operation and to avoid any potential errors or damage.

2. Safety Instructions

Always observe the following safety precautions when handling and using the portafilter:

- Ensure the portafilter is securely locked into the coffee machine before brewing to prevent hot liquid spills.
- Handle the portafilter with care, especially after brewing, as metal parts can become hot. Use the handle provided.
- Do not attempt to modify the portafilter. Use only genuine De'Longhi replacement parts.
- Keep out of reach of children.
- Refer to your coffee machine's main instruction manual for specific safety guidelines related to the appliance itself.

3. Product Overview

The De'Longhi portafilter is a crucial component of your espresso machine, designed to hold ground coffee and allow pressurized hot water to extract the espresso.



Figure 3.1: De'Longhi original portafilter. It features a chrome-plated metal filter basket holder and a sturdy black plastic handle. The handle is ergonomically designed for a comfortable grip, and the filter basket is where the ground coffee is placed.

Compatible Models:

This portafilter is compatible with the following De'Longhi 'Caffe Venezia' coffee machine models:

- BAR 12 F (Code: 0132103071, 0132103070)
- BAR 14 F (Code: 0132103067, 0132103074)
- BAR 14 FE (Code: 0132103060)
- CF 8 (Code: 0132104065)

If your model is not listed, please contact De'Longhi customer support or your retailer before purchase to confirm compatibility.

4. Setup

This section describes how to prepare your new portafilter for first use and how to attach it to your coffee machine.

4.1 Initial Cleaning

1. Before first use, wash the portafilter and its filter basket with warm water and a mild dish soap.
2. Rinse thoroughly under running water to remove all soap residue.
3. Dry completely with a soft cloth.

4.2 Attaching the Portafilter

1. Ensure the filter basket is correctly seated within the portafilter.
2. Fill the filter basket with the desired amount of ground coffee, then tamp it evenly.
3. Align the portafilter with the group head of your De'Longhi coffee machine. The handle should typically be pointing slightly to the left.
4. Insert the portafilter into the group head and rotate the handle firmly to the right until it is securely locked in place. You should feel resistance and it should not wobble.
5. Refer to your coffee machine's manual for precise instructions on attaching the portafilter for your specific model.

5. Operating the Portafilter

The portafilter's primary function is to hold the coffee grounds during the brewing process. Its operation is integrated with your coffee machine's brewing cycle.

5.1 Preparing for Brewing

1. Ensure the portafilter is clean and dry.
2. Place the appropriate filter basket (single or double shot) into the portafilter.
3. Add freshly ground coffee to the filter basket. For best results, use espresso grind.
4. Distribute the coffee evenly and tamp it down with a coffee tamper to create a compact puck.
5. Wipe any excess coffee grounds from the rim of the portafilter to ensure a good seal with the group head.

5.2 Brewing Process

1. Attach the prepared portafilter to the group head of your coffee machine as described in Section 4.2.
2. Place your cup(s) under the spouts of the portafilter.
3. Initiate the brewing cycle on your coffee machine according to its specific instructions.
4. Once brewing is complete, turn off the machine's brewing function.

5.3 After Brewing

1. Carefully remove the portafilter from the group head by rotating the handle to the left. Be cautious as it may be hot.
2. Discard the used coffee puck. You can tap the portafilter against a knock box or use a spoon to remove the grounds.
3. Rinse the portafilter and filter basket under hot water immediately after use to prevent coffee oils from drying and building up.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your portafilter and ensure optimal coffee flavor.

6.1 Daily Cleaning

- After each use, remove the filter basket and rinse both the portafilter and basket under hot running water.
- Use a small brush or cloth to remove any coffee grounds stuck in the basket holes or on the portafilter rim.
- Dry thoroughly to prevent water spots and mineral buildup.

6.2 Weekly / Deep Cleaning

- Once a week, or as needed, soak the portafilter and filter basket in a solution of warm water and a specialized espresso machine cleaner (e.g., Puly Caff or similar). Follow the cleaner's instructions for dilution and soaking time.
- This helps remove stubborn coffee oils and residue that can affect taste.
- After soaking, scrub with a brush and rinse thoroughly under running water. Ensure no cleaning solution remains.

6.3 Storage

Store the portafilter in a clean, dry place when not in use. It is recommended to store it detached from the machine to allow the group head gasket to relax.

7. Troubleshooting

This section addresses common issues related to the portafilter. For machine-specific problems, refer to your coffee machine's manual.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Portafilter difficult to attach/remove.	Coffee grounds on rim; Worn group head gasket; Portafilter not aligned.	Clean rim thoroughly. Check and replace group head gasket if worn. Ensure correct alignment before twisting.
Water leaks from around portafilter during brewing.	Portafilter not securely locked; Worn group head gasket; Dirty portafilter rim.	Ensure portafilter is fully tightened. Inspect and replace group head gasket. Clean portafilter rim.
Coffee tastes bitter or burnt.	Portafilter/basket dirty with old coffee oils.	Perform a deep clean of the portafilter and basket (Section 6.2).

8. Specifications

Feature	Detail
Brand	De'Longhi
Model Number (Part)	7313285789
Compatible Coffee Maker Models	De'Longhi 'Caffe Venezia' series (BAR 12 F, BAR 14 F, BAR 14 FE, CF 8)
Material	Stainless Steel (filter basket), Plastic (handle)
Special Feature	Espresso, Portable (as a component)
Included Components	Filter (Portafilter with basket)
Operation Mode	Manual (as part of a manual espresso machine)
Date First Available on Amazon.com.be	25 May 2022

9. Warranty and Support

This product is an original De'Longhi spare part. For information regarding warranty coverage, please refer to the warranty policy provided with your original De'Longhi coffee machine or visit the official De'Longhi website.
For technical support, spare parts inquiries, or further assistance, please contact De'Longhi customer service:

- **De'Longhi Official Website:** www.delonghi.com
- **Customer Service:** Refer to the "Contact Us" section on the official website for regional phone numbers and email support.

Please have your product model number (7313285789) and your coffee machine's model number ready when contacting support.

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question