

[manuals.plus](#) /› [Moulinex](#) /› [Moulinex Replacement Paddle for IG50 Series Ice Cream Makers \(SS-193611\)](#)

## Moulinex SS-193611

# Moulinex Replacement Paddle for IG50 Series Ice Cream Makers (SS-193611)

Instruction Manual

## INTRODUCTION

This manual provides essential instructions for the proper installation, use, and maintenance of your Moulinex SS-193611 replacement paddle. This paddle is an original Moulinex part designed for specific IG50 series ice cream makers. Please read this manual carefully before installation to ensure correct operation and longevity of your appliance.

## COMPATIBILITY

The Moulinex SS-193611 replacement paddle is compatible with the following Moulinex IG50 series ice cream maker models:

- IG5001 (e.g., IG500131/6R0, IG500140/6R0, IG500150/6R0)
- IG5007 (e.g., IG500700/6R0, IG500710/6R0, IG500760/6R0, IG5007B1/6R0, IG5007B2/6R0)
- IG5017 (e.g., IG501720/6R0, IG501756/6R0, IG5017CL/6R0)
- IG5025 (e.g., IG502550/6R0)

If your specific model number is not listed, please verify compatibility with Moulinex customer support before installation.

## INSTALLATION

1. **Safety First:** Ensure your ice cream maker is unplugged from the power outlet before attempting any installation or removal of parts.
2. **Remove Old Paddle (if applicable):** If replacing an existing paddle, gently pull the old paddle upwards from the central shaft of the mixing bowl.
3. **Clean Components:** Before installing the new paddle, ensure the mixing bowl and the central shaft are clean and free from any food residue.

- 4. Insert New Paddle:** Align the new Moulinex SS-193611 paddle with the central shaft in the ice cream maker's mixing bowl. Gently push it down until it is securely seated. It should fit snugly but not require excessive force.
- 5. Verify Seating:** Give the paddle a slight twist to ensure it is properly engaged with the shaft and can rotate freely when the machine is assembled.



*Image: The Moulinex SS-193611 replacement paddle. This white plastic paddle is designed to fit securely onto the central shaft of compatible Moulinex IG50 series ice cream makers, ensuring proper churning during the ice cream making process.*

## OPERATION

---

Once the paddle is correctly installed, you can proceed with operating your ice cream maker according to its main instruction manual. The paddle's function is to continuously mix the ingredients within the freezing bowl, preventing ice crystal formation and creating a smooth, consistent texture.

- Ensure the paddle is securely in place before adding ingredients.
- Do not overfill the mixing bowl beyond the maximum fill line specified in your ice cream maker's manual, as this can impede paddle movement.
- Monitor the churning process; the paddle should rotate smoothly throughout.

## MAINTENANCE AND CLEANING

---

Regular cleaning of the paddle is essential for hygiene and to maintain its performance.

- 1. Immediate Cleaning:** After each use, remove the paddle from the ice cream maker.
- 2. Hand Washing:** Wash the paddle with warm, soapy water. Use a soft sponge or cloth to remove any food residue.
- 3. Rinsing:** Rinse thoroughly under running water to remove all soap.
- 4. Drying:** Dry the paddle completely before storing or re-installing. Air drying is recommended, or use a clean, dry cloth.
- 5. Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the paddle's material.

## TROUBLESHOOTING

If you encounter issues related to the paddle, consider the following:

Problem	Possible Cause	Solution
Paddle not rotating	<ul style="list-style-type: none"><li>Paddle not seated correctly.</li><li>Too much mixture in the bowl.</li><li>Mixture too thick/frozen.</li></ul>	<ul style="list-style-type: none"><li>Ensure paddle is fully pushed onto the central shaft.</li><li>Reduce the amount of mixture.</li><li>Allow mixture to soften slightly before churning.</li></ul>
Unusual noise during churning	<ul style="list-style-type: none"><li>Paddle not installed correctly.</li><li>Foreign object in the bowl.</li></ul>	<ul style="list-style-type: none"><li>Remove and re-install the paddle, ensuring it clicks into place.</li><li>Inspect the bowl and paddle for any obstructions.</li></ul>

If problems persist, refer to your ice cream maker's main instruction manual or contact Moulinex customer support.

## SPECIFICATIONS

- Part Number:** SS-193611
- Material:** Metal or plastic (as per product description, typically food-grade plastic for paddles)
- Brand:** Moulinex
- Compatibility:** Moulinex IG50 series ice cream makers (IG5001, IG5007, IG5017, IG5025)

## WARRANTY AND SUPPORT

This Moulinex original replacement part is designed for durability and performance. For specific warranty information regarding replacement parts, please refer to the documentation provided with your original ice cream maker or visit the official Moulinex website. For technical assistance or further inquiries, please contact Moulinex customer support.

You can often find support contact details on the official Moulinex website or within the original product manual.