Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hamilton Beach 80393

Hamilton Beach 80393 Electric Coffee Grinder User Manual

Model: 80393

Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and care of your Hamilton Beach Electric Coffee Grinder. Please read all instructions carefully before first use and retain for future reference.
The Hamilton Beach Electric Coffee Grinder is designed to provide freshly ground coffee beans and can also be used for grinding spices. Its hands-free operation and multiple grind settings allow for customized results, from coarse to fine, for up to 14 cups of coffee.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not immerse cord, plug, or grinder in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the appliance manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Check grinding chamber for presence of foreign objects before using.
- Do not use appliance for other than intended use.

Parts and Features

Familiarize yourself with the components of your coffee grinder:

- **Lid:** Transparent lid with safety lock mechanism.

- **Removable Grinding Chamber:** Stainless steel chamber for holding beans or spices.
- **Stainless Steel Blades:** Durable blades for efficient grinding.
- **Grind Control Dial:** Adjusts grind fineness (Coarse, Medium, Fine).
- **On/Off Button:** Initiates and stops the grinding process.
- **Cup Selector Lever:** Selects the desired amount of coffee to grind (4, 8, 12, 14 cups).
- **Base with Cord Wrap:** Main unit housing the motor and power cord storage.



Front view of the Hamilton Beach Electric Coffee Grinder, showcasing its sleek design and control panel.

Setup

1. **Unpack:** Carefully remove all packaging materials and inspect the grinder for any damage.
2. **Clean Before First Use:** Wash the removable grinding chamber and lid in hot, soapy water. Rinse thoroughly and dry completely. The main unit (base) should be wiped clean with a damp cloth. Do not immerse the base in water.
3. **Placement:** Place the grinder on a dry, level, and stable surface.
4. **Cord Management:** The power cord can be wrapped underneath the base for convenient storage and to adjust to the ideal length, reducing countertop clutter.



Rear view of the coffee grinder, illustrating the integrated cord wrap feature for tidy storage.

Operating Instructions

1. **Fill Grinding Chamber:** Ensure the grinder is unplugged. Remove the lid and the removable grinding chamber. Fill the chamber with whole coffee beans or spices. Do not overfill; the maximum capacity is 10 tablespoons of beans, sufficient for up to 14 cups of coffee.
2. **Secure Lid:** Place the grinding chamber back into the base. Position the lid onto the grinding chamber and twist it clockwise until it locks securely into place. The grinder will not operate unless the lid is properly locked.
3. **Select Grind Fineness:** Rotate the grind control dial to your desired setting:**Coarse** for French press, **Medium** for automatic drip coffee makers, or **Fine** for espresso machines.
4. **Select Quantity:** Move the cup selector lever to indicate the number of cups of coffee you intend to brew (4, 8, 12, or 14). This helps the grinder determine the appropriate grinding time.
5. **Start Grinding:** Plug the grinder into a standard electrical outlet. Press the On/Off button once. The grinder will operate hands-free and automatically shut off when the selected grind cycle is complete.
6. **Remove Grounds:** Once grinding is complete and the unit has stopped, unplug the grinder. Twist the lid counter-clockwise to unlock and remove it. Carefully lift out the removable grinding chamber for mess-free pouring of your fresh grounds.



A close-up view of the grind control dial, allowing selection between coarse, medium, and fine settings.



Grind enough to brew up to 14 cups of coffee

Easily move the lever to select the amount of coffee you plan to brew

The cup selector lever on the grinder's base, used to choose the desired amount of coffee to grind, up to 14 cups.



Demonstration of the hands-free grinding feature, where the grinder automatically stops once the cycle is complete.

Operational Videos

Your browser does not support the video tag.

This video demonstrates the Hamilton Beach coffee grinder in action, showing how to load beans, select grind settings, and initiate the grinding process for fresh coffee.

Your browser does not support the video tag.

A detailed review video highlighting the features and ease of use of the Hamilton Beach coffee grinder, including a look at its compact design and removable parts.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder.

1. **Always Unplug:** Before cleaning, ensure the grinder is unplugged from the electrical outlet.
2. **Remove Grinding Chamber:** Unlock and remove the lid, then lift out the stainless steel grinding chamber.

3. **Wash Removable Parts:** The grinding chamber and lid are dishwasher safe for easy cleaning. Alternatively, wash them by hand in hot, soapy water, then rinse and dry thoroughly.
4. **Clean Base:** Wipe the exterior of the grinder base with a damp cloth. Do not use abrasive cleaners or immerse the base in water.
5. **Brush Away Residue:** Use the included cleaning brush to remove any coffee grounds or spice residue from the blades and inside the grinding chamber before washing.



The removable stainless steel grinding chamber, designed for easy filling, pouring, and cleaning.

Hamilton Beach



Custom Grind™ Coffee Grinder

The coffee grinder shown with its cleaning brush, emphasizing the ease of maintenance and the integrated cord wrap.

Troubleshooting

If your coffee grinder is not functioning as expected, please refer to the following common issues and solutions:

- **Grinder does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Verify that the lid is properly aligned and twisted into the locked position. The grinder has a safety interlock feature that prevents operation if the lid is not secured.
- **Inconsistent grind:**

- Check that the grind control dial is set to the desired fineness.
- Ensure the grinding chamber is not overfilled, which can hinder proper blade movement.

- **Grinder stops unexpectedly:**
  - The grinder is designed for hands-free operation and will automatically shut off when the selected grind cycle is complete. This is normal operation.
  - If it stops prematurely, check for foreign objects in the grinding chamber or ensure the lid remains securely locked.

If issues persist, please contact Hamilton Beach customer support.

Specifications

Feature	Specification
Brand	Hamilton Beach
Model Number	80393
Color	Black
Material	Plastic
Item Weight	1.9 pounds
Item Dimensions (L x W x H)	4.7"L x 4.5"W x 8"H
Capacity	14 cups (10 tablespoons of beans)
Wattage	150 watts
Voltage	240
Included Components	Coffee Grinder



Product image displaying the dimensions of the Hamilton Beach Electric Coffee Grinder.

Warranty and Support

Your Hamilton Beach Electric Coffee Grinder is covered by a **One (1) Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For detailed warranty information, product registration, or customer support, please visit the official Hamilton Beach store or refer to the comprehensive user guide PDF.

- Official Hamilton Beach Store: Visit Store
- User Guide (PDF): Download PDF

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0743STL26

More documents and user manuals: **https://manuals.plus/**