

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AXA](#) /

› [AXA Blueline Steady Bicycle Tail Light Instruction Manual](#)

## AXA Blueline Steady

# AXA Blueline Steady Bicycle Tail Light

Instruction Manual

## 1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your AXA Blueline Steady LED bicycle tail light. The Blueline Steady is designed for pannier rack mounting and features a parking light function, providing enhanced visibility and safety for cyclists.

This product complies with German certification marks and includes 2 LEDs for optimal light output.

## 2. SAFETY INFORMATION

- **Always ensure the tail light is securely mounted** before riding. A loose light can fall off and cause damage or injury.
- **Do not look directly into the LED light** when it is active, as it may cause temporary vision impairment.
- **Keep the light clean** to ensure maximum visibility. Dirt or mud can reduce light output.
- **This product is not water resistant**. Avoid prolonged exposure to heavy rain or submersion in water to prevent damage.
- **Dispose of batteries responsibly** according to local regulations.

## 3. PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x AXA Blueline Steady LED Rear Pannier Light

*Note: Mounting hardware may be sold separately or included with your bicycle's pannier rack.*

## 4. SETUP AND INSTALLATION

### 4.1 Mounting the Tail Light

The AXA Blueline Steady is designed for mounting on a bicycle pannier rack. It features a screw spacing of

50 mm.

1. **Identify Mounting Points:** Locate the two mounting holes on your bicycle's pannier rack, typically at the rear, with a 50 mm distance between them.
2. **Position the Light:** Align the mounting holes on the back of the Blueline Steady tail light with the holes on your pannier rack.
3. **Secure with Screws:** Insert appropriate screws (not included) through the light and into the pannier rack. Tighten the screws firmly but do not overtighten, as this may damage the light housing.
4. **Verify Stability:** Gently tug on the light to ensure it is securely attached and does not wobble.

*Image: Blueline Steady Tail Light Mounting Points*

This image illustrates the rear of the AXA Blueline Steady tail light, highlighting the two circular screw holes positioned 50mm apart, designed for secure attachment to a bicycle's pannier rack.

## 4.2 Battery Installation (if applicable)

The Blueline Steady is battery-powered. Ensure batteries are correctly installed before first use.

1. **Open Battery Compartment:** Locate the battery compartment cover on the light. Use a small screwdriver or coin to open it if necessary.
2. **Insert Batteries:** Insert the required batteries (e.g., AAA, not included) according to the polarity indicators (+/-) inside the compartment.
3. **Close Compartment:** Securely close the battery compartment cover.

## 5. OPERATING INSTRUCTIONS

### 5.1 Turning On/Off

The AXA Blueline Steady typically operates automatically or via a simple switch, depending on the specific model variant. Consult the light's housing for a power button or sensor.

- **Automatic Operation:** Some models are designed to turn on automatically when motion is detected or in low light conditions.
- **Manual Operation:** If a button is present, press it once to turn the light on. Press it again to turn it off.

### 5.2 Parking Light Function

The Blueline Steady features a parking light function that keeps the light active for approximately 4 minutes after the bicycle stops. This enhances safety when pausing at traffic lights or during short stops.

- The parking light function activates automatically when the main light is on and the bicycle comes to a stop.
- The light will remain illuminated at a reduced intensity for about 4 minutes, or until the bicycle resumes motion.

## 6. MAINTENANCE

- **Cleaning:** Wipe the light's lens and housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** When the light dims or stops functioning, replace the batteries. Refer to

Section 4.2 for battery installation.

- **Storage:** If storing the bicycle for an extended period, remove the batteries from the tail light to prevent leakage and damage.
- **Inspection:** Periodically check the mounting screws for tightness and ensure the light is free from cracks or damage.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Dead or incorrectly installed batteries.	Replace batteries, ensuring correct polarity.
Light is dim.	Low battery power; dirty lens.	Replace batteries; clean the lens.
Light flickers.	Loose battery connection; low battery power.	Check battery contacts; replace batteries.
Parking light function not working.	Main light not active; internal sensor issue.	Ensure main light is on. If problem persists, contact support.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	Blueline Steady
Part Number	03112406
Light Type	LED Rear Light
Number of LEDs	2
Brightness	50 Lumens (Maximum Light Output)
Parking Light Duration	Approx. 4 minutes
Mounting Type	Pannier Rack Mount
Screw Spacing	50 mm
Power Source	Battery Powered
Material	Plastic
Color	Black
Item Weight	0.04 Kilograms
Water Resistance Level	Not Water Resistant (IPX4 rating)

## 9. WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your AXA Blueline Steady tail light,

please contact AXA customer service or visit the official AXA website. Keep your proof of purchase for warranty claims.

## 10. MEDIA INFORMATION

No product images or videos were provided in the available data for this manual.

© 2024 AXA. All rights reserved.