

[Manuals.plus](#) /

› [Fisher-Price](#) /

› Fisher-Price Thomas & Friends TrackMaster Glowing Mine Set Instruction Manual

Fisher-Price FBK52

Fisher-Price Thomas & Friends TrackMaster Glowing Mine Set

Model: FBK52

INTRODUCTION

Welcome to the world of Thomas & Friends TrackMaster! This instruction manual provides essential information for setting up, operating, and maintaining your Fisher-Price Thomas & Friends TrackMaster Glowing Mine Set. This set allows children to send motorized Thomas on an exciting mining adventure through glow-in-the-dark tracks, caves, and tunnels to discover glowing gems.



Image: A young child playing with the glowing mine set, showcasing its interactive features.

Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

Adult assembly is required. Please ensure all parts are securely connected before play. Regularly inspect the toy for any damage or loose parts that could pose a hazard. Keep batteries out of reach of small children.

What's in the Box

Your Fisher-Price Thomas & Friends TrackMaster Glowing Mine Set includes the following components:

- Motorized Thomas train engine with glow-in-the-dark designs
- Cargo car
- Barrel accessory
- Glow-in-the-dark gem cargo piece
- Full glow-in-the-dark track layout
- Tunnels and caves
- Barrel loader station
- Boulder accessory








Image: All components of the Glowing Mine Set.

SETUP AND ASSEMBLY

Follow these steps to assemble your TrackMaster Glowing Mine Set:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Refer to the 'What's in the Box' section to ensure all components are present.
2. **Battery Installation:** The motorized Thomas train requires 2 Lithium Metal batteries. Locate the battery compartment on the underside of the engine. Using a Phillips head screwdriver (not included), open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the compartment.
3. **Assemble Track Layout:** Connect the track pieces as shown in the diagram below. Ensure all connections are firm to prevent derailments. The glow-in-the-dark tracks are designed to interlock easily.
4. **Place Accessories:** Position the tunnels, caves, barrel loader, and boulder accessories around the track as desired or as depicted in the layout.
5. **Prepare Thomas:** Attach the cargo car to the motorized Thomas engine. Place the barrel into the cargo car or the glowing gem cargo piece near the boulder for play.



Image: Fully assembled track layout of the Glowing Mine Set.

OPERATING INSTRUCTIONS

Once the set is assembled and batteries are installed, you can begin playing:

1. **Start Thomas:** Flip the switch on the motorized Thomas engine to the 'ON' position. Thomas will begin to move along the track.
2. **Explore the Mine:** Watch as Thomas races over, under, and through the glowing caves and tunnels. The glow-in-the-dark features are best experienced in a dimly lit room.
3. **Cargo Loader Interaction:** Stop Thomas at the cargo loader. Lift the gate, and the barrel will roll into his cargo car.
4. **Gem Discovery:** Park Thomas in front of the boulder to discover the cluster of glowing gems. The gem cargo piece can be loaded or unloaded from Thomas's cargo car.
5. **Expand Your Railway:** This TrackMaster set is connectable with other TrackMaster train sets and expansion packs (sold separately) to create a larger, more exciting motorized railway.



Image: Thomas at the barrel loader.



Image: Thomas with the glowing gem cargo.

MAINTENANCE

To ensure the longevity of your TrackMaster Glowing Mine Set:

- **Cleaning:** Wipe down tracks and train with a damp cloth. Do not immerse electronic components in water.
- **Battery Care:** Remove batteries from the motorized Thomas engine when not in use for extended periods to prevent leakage.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to preserve the glow-in-the-dark properties and plastic integrity.

TROUBLESHOOTING

If you encounter issues with your set, try the following:

- **Train Not Moving:** Check if the batteries are correctly installed and have sufficient power. Replace them if necessary. Ensure the ON/OFF switch on Thomas is in the 'ON' position.
- **Train Derails:** Verify that all track pieces are securely connected and laid on a flat surface. Check for any obstructions on the track.

- **Glow-in-the-Dark Not Working:** Ensure the set has been exposed to light to 'charge' the glow-in-the-dark material. The effect is most visible in complete darkness.

SPECIFICATIONS

Feature	Detail
Brand	Fisher-Price
Model Name	TrackMaster Glowing Mine Set
Model Number	FBK52
Age Range	36 months to 78 months
Power Source	Battery Powered
Battery Type	2 Lithium Metal batteries (required)
Item Weight	16 ounces
Item Dimensions	7.09 x 59.06 x 23.62 inches
Number of Pieces	7 (Playset components)
CPSIA Cautionary Statement	Choking Hazard - Small Parts, No Warning Applicable

WARRANTY AND SUPPORT

This product is sold without a manufacturer's warranty. For further assistance or inquiries, please visit the official Fisher-Price Store: [Fisher-Price Store on Amazon](#).

© 2023 Fisher-Price. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question