

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Aurora](#) /

› [Aurora® Enchanting Sparkle Tales™ Rainbow Unicorn™ Stuffed Animal Instruction Manual](#)

Aurora 31571

Aurora® Enchanting Sparkle Tales™ Rainbow Unicorn™ Stuffed Animal Instruction Manual

Model: 31571

INTRODUCTION

The Aurora® Enchanting Sparkle Tales™ Rainbow Unicorn™ is a soft plush toy designed for cuddly play. Crafted with quality materials, this unicorn features a soft plush exterior and poly-bean filling for stability. It is suitable for various ages and intended for imaginative play and companionship.

Key Features:

- Soft plush material for a gentle feel.
- Poly-bean filling for stability and durability.
- Features lock washer eyes for enhanced safety.
- Colorful rainbow mane and tail.
- Sparkly accents on horn and hooves.

SETUP AND INITIAL USE

The Aurora® Rainbow Unicorn™ is ready for use directly out of its packaging. No assembly is required. Simply remove all packaging materials and tags before giving the plush toy to a child. Inspect the toy for any loose parts or damage prior to first use.



Image: The Aurora Rainbow Unicorn plush toy, ready for play.

OPERATING INSTRUCTIONS

This plush toy is designed for imaginative play and companionship. It can be used for cuddling, storytelling, and creative adventures. Encourage children to engage in gentle play to maintain the toy's condition.

Recommended Play:

- **Cuddling:** The soft material makes it ideal for comforting and snuggling.
- **Imaginative Play:** Use the unicorn as a character in stories and adventures.
- **Travel Companion:** Its size makes it suitable for taking on trips.



Image: The Aurora Rainbow Unicorn in a sitting position, showcasing its design.

MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your Aurora® Rainbow Unicorn™, follow these care instructions:

- **Spot Cleaning:** For minor stains, use a damp cloth with mild soap to gently clean the affected area. Blot dry with a clean towel.
- **Hand Washing:** For a more thorough cleaning, hand wash the plush toy using cold water and a gentle detergent. Avoid harsh scrubbing to preserve the material's softness and integrity.
- **Drying:** Air dry the unicorn completely. Do not use a machine dryer, as high heat can damage the plush material and internal components.
- **Avoid Bleach:** Do not use bleach or harsh chemicals, as these can discolor or damage the fabric.

TROUBLESHOOTING

Most issues with plush toys are minor and can be resolved with simple care.

- **Shedding:** Minimal shedding may occur, especially with new plush toys. This typically reduces over time.
- **Loss of Softness:** Regular gentle cleaning and air drying can help maintain the plush's softness. Avoid excessive washing or harsh detergents.
- **Damage to Stitching:** If stitching becomes loose, carefully hand-stitch the area to prevent further damage.

SPECIFICATIONS

Feature	Detail
Brand	Aurora
Model Number	31571
Product Dimensions	13 x 7 x 6.5 inches
Item Weight	6.7 ounces
Recommended Age	1 month and up
Material	Soft plush with poly-bean filling




Image: Product dimensions for the Aurora Rainbow Unicorn.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not suitable for children under 3 years if small parts become detached. Always supervise young children during play. Ensure all tags and plastic attachments are removed before giving the toy to a child.

WARRANTY AND SUPPORT

Aurora products are manufactured with quality and durability in mind. For any questions regarding your Aurora® Enchanting Sparkle Tales™ Rainbow Unicorn™ or for support, please contact Aurora customer service through their official website or the retailer where the product was purchased. Keep your proof of purchase for any potential claims. For more information, visit the [Aurora Store](#).



Video: A detailed review of the Sparkle Tales by Aurora Stuffed Unicorn, highlighting its features and quality. This video is provided by a seller.

