

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [noot products](#) /
- > [noot products K11 Kids Headphones Instruction Manual](#)

noot products k11

Instruction Manual

NOOT PRODUCTS K11 KIDS HEADPHONES

Model: K11 | Brand: noot products

Introduction

The noot products K11 Kids Headphones are designed for comfortable and safe listening for children and teens. Featuring a durable, foldable design and a tangle-free wired cord, these headphones are ideal for various uses including school, travel, and everyday entertainment. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your headphones.

Key Features

- **Comfortable Design:** Padded soft cushions and an adjustable headband ensure a perfect fit for children aged 3 and up.
- **Durable Construction:** Lightweight design with a 5-foot long nylon braided cable for enhanced durability and tangle-free use.
- **Foldable for Portability:** Compact, foldable design allows for easy storage and transport.
- **Universal Compatibility:** Compatible with all smartphones, Chromebooks, iPads, tablets, computers, laptops, and any device with a 3.5mm audio jack. (Note: iPhone 7 and above, and iPad Pro 11/12.9 year 2020 models require a Lightning to 3.5mm jack adapter, sold separately).
- **No Integrated Microphone/Controls:** These headphones do not include a microphone, remote, or volume control. Audio input will be captured by the microphone on your connected device.

What's in the Box

- 1 x noot products K11 Kids Headphones (Navy/Teal)

Setup

Follow these steps to set up your noot products K11 Kids Headphones:

1. **Unfold the Headphones:** Gently unfold the headphones from their compact, travel-ready position. The earcups can swivel and the headband extends to fit comfortably.



Image: The noot products K11 headphones in their folded, compact state, ready for storage or travel.

2. **Adjust the Headband:** Extend or retract the adjustable headband to ensure a snug yet comfortable fit on the user's head. The soft ear cushions should fully cover the ears without applying excessive pressure.

Sleek & Streamlined Design



Image: A detailed view highlighting the adjustable headband and soft ear cushions, designed for comfortable fit.

3. **Connect to Device:** Insert the 3.5mm audio jack firmly into the headphone port of your compatible device (smartphone, tablet, laptop, etc.). Ensure the connection is secure for optimal audio quality.

Nylon Braiding Cord

Premium nylon fabric feel great, strong and doesn't tangle




Image: The durable nylon braided cord, designed to be tangle-free and robust for daily use.

Operating Instructions

Once connected, the noot products K11 headphones are ready for use. Simply play audio from your connected device.

- **Audio Playback:** Control audio playback (play, pause, skip tracks) and volume directly from your connected device.
- **Microphone Functionality:** As these headphones do not have an integrated microphone, any voice input will be captured by the microphone on your connected device.



Image: A child comfortably wearing the root products K11 headphones during an activity, illustrating typical usage.

Maintenance

Proper care will extend the life of your headphones:

- **Cleaning:** Use a soft, dry cloth to wipe down the ear cushions and headband. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, fold the headphones to their compact size and store them in a clean, dry place away from extreme temperatures and direct sunlight.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable to prevent damage. The nylon braided design helps resist tangles.

Troubleshooting

If you encounter issues with your root products K11 headphones, try the following:

- **No Sound:**
 - Ensure the 3.5mm audio jack is fully inserted into the device's port.
 - Check the volume level on your connected device.

- Test the headphones with another device to rule out a device-specific issue.

- **Sound Distortion:**

- Lower the volume on your device.
- Ensure the audio jack is clean and free of debris.

- **Headphones Not Fitting Comfortably:**

- Adjust the headband length.
- Ensure the earcups are properly positioned over the ears.

If problems persist, please refer to the Warranty and Support section.

Specifications

Model Name	K11
Connectivity Technology	Wired (3.5 mm Jack)
Ear Placement	On Ear
Frequency Response	20 Hz - 20,000 Hz
Sensitivity	95 dB
Impedance	32 Ohm
Cable Feature	Tangle Free
Material	Faux Leather, Metal, Nylon, Plastic
Product Dimensions	5 x 4 x 2 inches
Item Weight	8 Ounces
Age Range (Description)	Kids, teens

Warranty and Support

Your noot products K11 Kids Headphones come with a **24-Month Hassle-Free Warranty**.

For any questions, technical support, or warranty claims, please contact noot products customer service. Refer to the product packaging or the official noot products website for the most current contact information.

We are committed to providing easy-to-reach customer service to ensure your satisfaction.