

[Manuals.plus](#) /

› [Geberit](#) /

› Geberit 200F Actuator Plate (Model 115.222.111) Instruction Manual

Geberit 21183 3

Geberit 200F Actuator Plate (Model 115.222.111)

Instruction Manual

INTRODUCTION

The Geberit 200F Actuator Plate, model 115.222.111, is designed for use with specific Geberit flush-mounted cisterns. This plate features an interruption lever for flush control and includes necessary mounting hardware for installation. It is compatible with Geberit flush-mounted cisterns such as Duofix Pur and Kombifix Pur, manufactured up to the end of 2001, and also with the Geberit conversion set 215.423.00.1.

SETUP AND INSTALLATION

Before installation, ensure the actuator plate dimensions are compatible with your existing flush-mounted cistern. This plate is specifically designed for Geberit flush-mounted cisterns including Duofix Pur and Kombifix Pur models produced until the end of 2001, and the Geberit conversion set 215.423.00.1. Mounting hardware is included to facilitate the installation process.



Rear view of the Geberit 200F Actuator Plate, showing the mounting points and internal mechanism. This view is helpful for understanding how the plate connects to the cistern.




Diagram illustrating the dimensions of the Geberit 200F Actuator Plate. The plate measures 340 mm (13.39 inches) in width, 185 mm (7.28 inches) in height, and 39 mm (1.54 inches) in depth. Verify these measurements against your cistern's requirements before installation.

OPERATING INSTRUCTIONS

The Geberit 200F Actuator Plate features an interruption lever for flush control. To operate, press the appropriate button to initiate the flush. To stop the flush prematurely, press the interruption lever.



Front view of the Geberit 200F Actuator Plate in white. This image displays the two flush buttons and the interruption lever, which allows for controlled water usage.

MAINTENANCE

To maintain the appearance and functionality of your Geberit 200F Actuator Plate, regularly clean the surface with a soft, damp cloth and a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. Ensure that the flush buttons and interruption lever move freely and are not obstructed.

TROUBLESHOOTING

If the flush mechanism does not operate correctly, first check for any obstructions around the buttons or lever. Ensure the plate is securely mounted. If issues persist, consult a qualified plumber or refer to the specific cistern's manual for further troubleshooting steps, as the actuator plate interacts directly with the cistern's internal components.

SPECIFICATIONS

Manufacturer	Sanitop-Wingenroth
Part Number	21183 3
Geberit Item Number	115.222.111
Item Weight	1.36 pounds
Product Dimensions	1.54 x 13.39 x 7.28 inches (39 x 340 x 185 mm)
Color	White
Style	Single
Item Package Quantity	1
Number Of Pieces	1

Measurement System	Metric
Batteries Required?	No
ASIN	B0747SWMNV
Date First Available	March 20, 2019

WARRANTY INFORMATION

Information regarding the warranty for the Geberit 200F Actuator Plate is typically provided with the product packaging or can be obtained directly from Geberit or your retailer. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For technical assistance, installation guidance, or spare parts, please contact Geberit customer support or your authorized Geberit dealer. Refer to the official Geberit website for contact information and additional resources.