

[Manuals.plus](#) /

› [Miseno](#) /

› Miseno MK036 PureSteel Kitchen Faucet Instruction Manual

Miseno MK036

Miseno MK036 PureSteel Kitchen Faucet Instruction Manual

Model: MK036

PRODUCT OVERVIEW

The Miseno MK036 PureSteel Kitchen Faucet is designed for durability and functionality, featuring 100% T304 stainless steel construction. This design ensures a smooth interior surface to prevent mineral build-up and eliminates lead exposure, offering a health benefit over traditional brass counterparts. The exterior finish is brushed, not plated, which prevents fading and rust. Equipped with high-quality ceramic valve cartridges, this faucet guarantees drip-free performance. Its 360-degree swivel spout and pull-out sprayer provide enhanced versatility for various kitchen tasks.



Image: The Miseno MK036 PureSteel Kitchen Faucet, showcasing its brushed stainless steel finish and elegant design.

SPECIFICATIONS

Feature	Detail
Brand	Miseno
Model Name	MK036
Material	T304 Stainless Steel
Finish Type	Brushed Stainless
Mounting Type	Deck Mount (Single Hole Installation)
Number of Handles	1
Maximum Flow Rate	1.8 Gallons Per Minute (GPM)
Spout Design	Swivel Pull-Out
Spout Height	8.25 Inches
Spout Reach	9.63 Inches
Included Components	Cartridge




Image: Technical drawing showing the dimensions of the Miseno MK036 faucet.

SAFETY INFORMATION

Before beginning installation, ensure that the main water supply to your kitchen is turned off. Always wear appropriate safety gear, such as safety glasses. If you are unsure about any part of the installation process, it is recommended to consult a qualified plumber to avoid potential water damage or injury. Do not use harsh chemicals or abrasive tools for cleaning, as this may damage the faucet's finish.

INSTALLATION INSTRUCTIONS

Before You Begin

- Ensure all necessary parts are present in the packaging.
- Turn off the hot and cold water supply lines at the shut-off valves under the sink.

- Clear the area under the sink for easy access.
- **Recommended Tools:** Adjustable wrench, basin wrench, plumber's putty or silicone sealant, screwdriver, flashlight.

Step-by-Step Installation

1. **Prepare the Mounting Hole:** Ensure your sink or countertop has a single standard faucet hole. Clean the area around the hole.
2. **Install the Faucet:** Place the faucet body through the mounting hole. From underneath the sink, secure the faucet using the provided mounting hardware (washer, nut). Tighten firmly but do not overtighten.
3. **Connect Water Supply Lines:** Attach the hot and cold water supply lines from the faucet to your home's water supply. Use an adjustable wrench to tighten connections, ensuring a watertight seal. Do not overtighten.
4. **Connect the Sprayer Hose:** Connect the pull-out sprayer hose to the designated connection point under the faucet body. Ensure the connection is secure.
5. **Install the Weight:** Attach the counterweight to the pull-out sprayer hose at the appropriate height to ensure smooth retraction of the sprayer.
6. **Test for Leaks:** Once all connections are made, slowly turn on the hot and cold water supply valves. Check all connections for any signs of leaks. Run the faucet for a few minutes to flush out any debris.



Image: The Miseno MK036 faucet with its pull-out sprayer hose extended, illustrating the connection point.

OPERATING YOUR FAUCET

Water Flow and Temperature Control

The Miseno MK036 features a single lever handle for controlling both water flow and temperature. Lift the handle to increase water flow. Move the handle left for hot water and right for cold water. The ceramic valve cartridges ensure smooth and precise control.



Image: Diagram illustrating the range of motion for the faucet handle, controlling both temperature and water flow.

Pull-Out Sprayer Function

The integrated pull-out sprayer provides extended reach and flexibility for various tasks, such as rinsing dishes or cleaning the sink. Simply pull the sprayer head from the spout. The sprayer typically features a button or switch to toggle between stream and spray modes (if applicable). After use, the hose retracts smoothly back into the faucet body.



Image: A close-up view of the pull-out sprayer head, showing the nozzle and control button.

360-Degree Swivel Spout

The faucet's spout can swivel 360 degrees, allowing for full sink coverage and increased convenience when using multiple basins or performing tasks that require directing water to different areas of the sink.



Image: The Miseno MK036 faucet with water flowing from the spout, demonstrating its operational state.

CARE AND MAINTENANCE

To maintain the appearance and functionality of your Miseno MK036 faucet, follow these guidelines:

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with water and dry with a soft cloth to prevent water spots. Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the brushed stainless steel finish.
- **Aerator Maintenance:** If water flow decreases, the aerator at the tip of the spout may be clogged. Unscrew the aerator, clean any debris, and rinse it before reattaching.
- **Stainless Steel Care:** The T304 stainless steel construction is resistant to rust and tarnishing. Regular cleaning as described above is sufficient to maintain its appearance.

TROUBLESHOOTING

If you encounter issues with your Miseno MK036 faucet, refer to the following common problems and solutions:

- **Low Water Flow:**
 - Check if the water supply valves are fully open.
 - Clean the aerator for any mineral deposits or debris.
 - Inspect water supply lines for kinks or obstructions.
- **Leaks from Faucet Base or Connections:**
 - Ensure all connections under the sink are tightened properly. Do not overtighten.
 - Check the O-rings and gaskets for proper seating and wear.
 - If the leak persists from the handle or spout, the ceramic valve cartridge may need inspection or replacement.
- **Sprayer Not Retracting Properly:**
 - Ensure the counterweight on the sprayer hose is positioned correctly and not obstructed.
 - Check the hose for kinks or damage.

If these steps do not resolve the issue, please contact Miseno customer support for further assistance.

WARRANTY AND CUSTOMER SUPPORT

The Miseno MK036 PureSteel Kitchen Faucet is covered by a **Limited Warranty** on both its finish and function. This warranty ensures that the finish resists tarnishing and that the faucet is engineered for reliable performance.

For detailed warranty information, technical support, or to inquire about replacement parts, please visit the official Miseno website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Contact Information:

Please refer to the Miseno official website or product packaging for the most current customer support contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question