

[Manuals.plus](#) /

> [UPBRIGHT](#) /

> UpBright AC/DC Adapter Instruction Manual for Ridgeway QS-2915BS Speaker System

UPBRIGHT Ridgeway QS-2915BS Power Supply

UpBright AC/DC Adapter Instruction Manual

For Ridgeway QS-2915BS 15-inch Rechargeable Portable Bluetooth PA Speaker System

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Power Source:** Use only with the specified voltage and frequency (100-240 VAC, 50/60 Hz).
- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose to rain, moisture, or extreme temperatures.
- **Ventilation:** Ensure adequate ventilation around the adapter. Do not cover it or place it in an enclosed space.
- **Cable Care:** Do not place heavy objects on the power cord. Avoid kinking, bending, or stretching the cord excessively.
- **Disconnection:** Always unplug the adapter from the wall outlet before cleaning or if it will be unused for an extended period.
- **Damage:** Do not use the adapter if the cord or plug is damaged. Contact customer support for replacement.
- **Children:** Keep the adapter out of reach of children.

2. PRODUCT OVERVIEW

The UpBright AC/DC Adapter is a replacement power supply designed for the Ridgeway QS-2915BS 15-inch Rechargeable Portable Bluetooth PA Speaker System. It converts standard AC wall power to the DC power required by your speaker, enabling both operation and battery charging.



Figure 2.1: Front view of the UpBright AC/DC Adapter, showing the main unit, two-prong AC plug, and the DC output cable with a barrel connector.



Figure 2.2: Side view of the UpBright AC/DC Adapter, illustrating its compact design and the attached power cable.



Figure 2.3: Rear view of the UpBright AC/DC Adapter, showing the power brick and the coiled output cable.

The adapter features a universal input voltage range (100-240V AC), making it suitable for international use with appropriate plug adapters (not included with the core product, but may be supplied by seller for international orders).



Figure 2.4: Examples of various international outlet adapters (AU, EU, UK types) that may be provided for international orders to ensure compatibility with local power outlets.

3. SETUP

Follow these steps to properly set up your UpBright AC/DC Adapter with the Ridgeway QS-2915BS speaker system:

1. **Verify Compatibility:** Ensure that the adapter's output voltage and connector type match the requirements of your Ridgeway QS-2915BS speaker. This adapter is specifically designed for this model.
2. **Connect to Speaker:** Locate the DC input port on your Ridgeway QS-2915BS speaker. Carefully insert the barrel connector of the UpBright adapter's output cable into this port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the two-prong AC plug of the adapter into a standard wall power outlet (100-240V AC, 50/60 Hz). If you are in a region with a different outlet type, use the appropriate international plug adapter (if provided or acquired separately).
4. **Power On:** Once connected, the speaker should receive power, and if its battery is low, it will begin charging. Refer to your speaker's manual for indicators of charging status.

4. OPERATING INSTRUCTIONS

The UpBright AC/DC Adapter functions as a direct power source and battery charger for your Ridgeway QS-2915BS

speaker.

- **Direct Power:** When connected to a wall outlet and the speaker, the adapter provides continuous power for speaker operation.
- **Battery Charging:** If the speaker's internal battery is depleted or low, the adapter will automatically initiate charging. The charging time will vary depending on the battery's current level and capacity.
- **Charging Indicators:** Consult your Ridgeway QS-2915BS speaker's user manual for specific LED indicators or display messages that show charging status.
- **Disconnection:** To disconnect, first unplug the adapter from the wall outlet, then carefully remove the DC connector from the speaker.

5. MAINTENANCE

Proper care ensures the longevity and safe operation of your AC/DC adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable.
- **Inspection:** Periodically inspect the power cord and connectors for any signs of damage, such as fraying, cuts, or bent pins. If damage is found, discontinue use and replace the adapter.

6. TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC Adapter, refer to the following common solutions:

Problem	Possible Cause	Solution
Speaker not powering on or charging.	◦ Adapter not properly plugged in. ◦ Wall outlet is not active. ◦ Adapter or cable is damaged. ◦ Speaker's DC input port is faulty.	◦ Ensure both ends of the adapter are securely connected. ◦ Test the wall outlet with another device. ◦ Inspect the adapter and cable for visible damage. If damaged, replace the adapter. ◦ Try powering the speaker with its original adapter (if available) to rule out a speaker issue.
Adapter feels excessively hot.	◦ Poor ventilation. ◦ Overload or internal fault.	◦ Ensure the adapter is in an open area with good airflow. ◦ Disconnect immediately and discontinue use. Contact customer support.

If the problem persists after trying these solutions, contact UpBright customer support or a qualified technician.

7. SPECIFICATIONS

Feature	Detail
Brand	UPBRIGHT

Feature	Detail
Compatible Model	Ridgeway QS-2915BS 15" Rechargeable Portable Bluetooth PA Speaker System
Input Voltage	100-240 VAC
Input Frequency	50/60 Hz
Power Source Type	Corded Electric
Connector Type	Barrel Connector (DC)
Certifications	CE, UL (as per product details)

8. WARRANTY AND SUPPORT

This UpBright product comes with a limited warranty. Please refer to the warranty certificate included with your purchase for specific terms and conditions, including coverage duration and claim procedures.




Figure 8.1: An example of the UpBright Limited Warranty Certificate, detailing the terms and conditions of the product warranty.

For technical support, warranty claims, or any questions regarding your UpBright AC/DC Adapter, please contact UpBright customer service. Contact information can typically be found on the product packaging or the official UpBright website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B074869RZP>

More documents and user manuals: <https://manuals.plus/>