

[Manuals.plus](#) /

› [Bose](#) /

› Bose SoundLink Micro Bluetooth Speaker User Manual

Bose 783342-0100

Bose SoundLink Micro Bluetooth Speaker User Manual

Model: 783342-0100

INTRODUCTION

The Bose SoundLink Micro Bluetooth speaker is designed to deliver powerful, clear sound in a compact, portable, and highly durable form factor. Its robust construction and waterproof design make it ideal for various environments, from indoor use to outdoor adventures. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your SoundLink Micro speaker.



Figure 1: Front view of the Bose SoundLink Micro Bluetooth Speaker.

WHAT'S IN THE BOX

Ensure all items are present before proceeding with setup:

- Bose SoundLink Micro Bluetooth speaker
- Micro-B USB charging cable
- Quick Start Guide



Figure 2: Bose SoundLink Micro speaker and its Micro-B USB charging cable.

SETUP

1. Charging the Speaker

Before first use, fully charge the SoundLink Micro speaker. Connect the Micro-B USB charging cable to the speaker's charging port and the other end to a USB power source (e.g., wall adapter, computer USB port). The battery indicator lights will illuminate during charging and turn solid white when fully charged. A full charge takes approximately 6 hours.

2. Powering On/Off

Press the Power button () located on the top of the speaker to turn it on or off. A voice prompt will indicate the battery level upon powering on.

3. Bluetooth Pairing

To pair with a new device:

1. Turn on the speaker.
2. Press and hold the Bluetooth button () until the Bluetooth indicator light blinks blue and a voice prompt says "Ready to connect."
3. On your device (smartphone, tablet), enable Bluetooth and select "Bose SoundLink Micro" from the list of available devices.
4. Once connected, a voice prompt will confirm the connection, and the Bluetooth indicator will glow solid white.

The speaker can remember up to eight paired devices. When powered on, it will automatically try to connect to the most recently connected device.

OPERATING THE SPEAKER

Basic Controls

- **Volume Control:** Press the + button to increase volume and the- button to decrease volume.
- **Play/Pause:** Press the multi-function button (center button with three dots) once to play or pause audio.
- **Skip Track:** Press the multi-function button twice quickly to skip to the next track.
- **Previous Track:** Press the multi-function button three times quickly to go to the previous track.
- **Call Handling:** An integrated microphone allows you to take phone calls directly from the speaker. Press the multi-function button once to answer or end a call.
- **Voice Assistant:** Press and hold the multi-function button to access your phone's voice assistant (Siri or Google Assistant).

Tear-Resistant Silicone Strap

The SoundLink Micro features a durable, tear-resistant silicone strap on its back, allowing for versatile attachment. Secure it to backpacks, bicycle handlebars, cooler handles, or other objects for convenient portability.






Figure 3: Examples of attaching the SoundLink Micro using its silicone strap.

Party Mode and Stereo Mode (Bose SimpleSync Technology)

Use the free Bose Connect app to enable Party Mode or Stereo Mode with compatible Bose Bluetooth speakers.

- **Party Mode:** Play the same music through multiple compatible Bose speakers for a wider soundstage.
- **Stereo Mode:** Separate left and right audio channels across two compatible Bose speakers for a true stereo experience.

For quick linking without the app, press and hold the Bluetooth button on each device to sync their sound.

MAINTENANCE

Waterproof and Dustproof Design (IP67)

The SoundLink Micro is rigorously tested to an IP67 rating, meaning it is waterproof and dustproof. It can withstand immersion in water up to 1 meter (3.3 feet) for up to 30 minutes. This makes it suitable for use by the pool, at the beach, or in the shower.



Figure 4: The SoundLink Micro's waterproof capability.

Cleaning

To clean the speaker, wipe it with a soft, damp cloth. Do not use any solvents, chemicals, or cleaning sprays. Ensure the charging port is dry before charging.

Battery Care

The rechargeable lithium-ion battery provides up to 6 hours of playtime. For optimal battery life, avoid fully discharging the speaker frequently and store it in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Solution
No power	Ensure the speaker is charged. Connect it to a power source using the USB cable.
No sound	Increase the volume on both the speaker and your connected device. Ensure the device is properly paired via Bluetooth.
Bluetooth pairing issues	Ensure the speaker is in pairing mode (blinking blue light). Turn off and on Bluetooth on your device. Forget the speaker from your device's Bluetooth list and re-pair. Move closer to the speaker.
Poor sound quality	Move the speaker closer to your device. Avoid obstacles between the speaker and device. Check for interference from other wireless devices.

SPECIFICATIONS

Feature	Detail
Model Name	SoundLink Micro
Dimensions (D x W x H)	1.37"D x 3.87"W x 3.87"H
Item Weight	0.75 Pounds (12 ounces)
Material	Silicone, Rubber
Connectivity Technology	Bluetooth
Wireless Range	Up to 30 Feet
Battery Life	Up to 6 Hours
Charging Time	Approximately 6 Hours
Water Resistance Level	Waterproof (IP67)
Built-in Microphone	Yes (for calls and voice assistant)
Included Components	SoundLink Micro Bluetooth speaker, Micro-B USB charging cable, Quick Start Guide

WARRANTY AND SUPPORT

The Bose SoundLink Micro Bluetooth Speaker comes with a limited warranty. For detailed warranty information, product support, and additional resources, please refer to the official Bose website or the included Quick Start Guide.

You can also find the User Guide in PDF format here [Bose SoundLink Micro User Guide \(PDF\)](#)