Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dyson 231772-01

Dyson V7 Car+Boat Cord-Free Handheld Vacuum Cleaner User Manual

Model: 231772-01

Introduction

The Dyson V7 Car+Boat Cord-Free Handheld Vacuum Cleaner is engineered for powerful and convenient cleaning of vehicles and boats. It features the Dyson digital motor V7, providing strong suction for effective dirt and debris removal. This cord-free design offers flexibility and ease of use, allowing you to quickly clean various surfaces without the hassle of cords.
Key features include:

- Cord-free operation for unrestricted movement.
- Powered by Dyson digital motor V7 for powerful suction.
- Up to 30 minutes of fade-free suction with lithium-ion batteries.
- Hygienic dirt ejector for easy and touch-free bin emptying.
- Includes specialized tools for tough tasks in cars and boats.

Package Contents

Upon unboxing your Dyson V7 Car+Boat vacuum, ensure all components are present:

- Dyson V7 Car+Boat Handheld Vacuum Unit
- Mini Motorized Tool
- Combination Tool
- Extension Hose
- Car Charger



Figure 1: Dyson V7 Car+Boat vacuum with all included accessories, including the main unit, various cleaning tools, and charging cables.



Figure 2: Detailed view of the specialized cleaning tools provided with the vacuum, designed for different cleaning tasks.

Setup

Initial Charging

Before first use, fully charge your Dyson V7 Car+Boat vacuum. Connect the car charger to the vacuum's charging port and plug it into a 12V car outlet. A full charge takes approximately 3.5 hours. The indicator light will show charging status.



Figure 3: The car charger (right) and standard charger (left) for the Dyson V7 Car+Boat vacuum. Use the car charger for in-vehicle charging.

Attaching Accessories

To attach any accessory, align the accessory with the main vacuum unit's nozzle and push firmly until it clicks into place. To remove, press the red release button on the accessory and pull it away from the main unit.





Figure 4: The extension hose and crevice tool, demonstrating how accessories connect to the vacuum for extended reach and specialized cleaning.

Operating Instructions

Powering On/Off

To operate the vacuum, simply pull and hold the trigger. Release the trigger to turn off the vacuum. This design helps conserve battery life by only operating when needed.

Suction Modes

The Dyson V7 Car+Boat offers two suction modes:

- **Standard Mode:** Provides up to 30 minutes of fade-free suction for general cleaning tasks.
- **MAX Mode:** For more demanding tasks, push the MAX button located on top of the vacuum. This mode provides

increased suction power for up to 6 minutes.

Using Attachments

Select the appropriate tool for your cleaning needs:

- **Mini Motorized Tool:** Ideal for removing pet hair and ground-in dirt from upholstery and carpets.
- **Combination Tool:** Features a wide nozzle and brush for switching between cleaning larger debris and dusting.
- **Extension Hose:** Provides extra reach for cleaning tight spaces, under seats, or around corners.



Figure 5: The Dyson V7 Car+Boat vacuum in use, demonstrating its compact design and attached crevice tool for reaching narrow areas.

Maintenance

Emptying the Clear Bin

To hygienically empty the clear bin, hold the vacuum over a trash can. Push the red lever on the top of the cyclone assembly to release the bin base and eject debris. Close the bin base firmly until it clicks into place.

Washing the Filter

For optimal performance, wash the filter at least once a month. The filter is located at the top of the cyclone assembly. Twist and pull to remove it. Wash the filter under cold running water until the water runs clear. Squeeze out excess water and allow it to air dry completely for at least 24 hours before reinserting. Do not use a washing machine or tumble dryer.



Figure 6: Visual instructions for washing the vacuum's filter and hygienically emptying the dirt bin, crucial steps for maintaining suction power.

Troubleshooting

Problem	Possible Cause	Solution
No power / Blinking red lights	Battery issue or vacuum not fully charged.	Ensure the vacuum is fully charged using the provided charger. If the issue persists, contact Dyson support.
Reduced suction	Clogged filter or full dirt bin.	Empty the dirt bin. Wash and thoroughly dry the filter as per maintenance instructions. Check for blockages in the nozzle or attachments.
Attachments not fitting securely	Improper alignment or debris in connection.	Ensure the accessory is aligned correctly and pushed firmly until it clicks. Clear any debris from the connection points.

Specifications

- **Brand:** Dyson
- **Model Name:** V7 Car+Boat
- **Model Number:** 231772-01
- **Color:** Purple
- **Power Source:** Battery Powered (Lithium-Ion)
- **Runtime:** Up to 30 minutes
- **Suction Power:** Maximum 100 Air Watts

- **Capacity:** 0.15 Gallons
- **Item Weight:** 3.77 pounds
- **Product Dimensions:** 12.45 x 5.17 x 8.11 inches
- **Noise Level:** 78 dB

Warranty and Support

The Dyson V7 Car+Boat Cord-Free Handheld Vacuum Cleaner comes with a**2-year warranty** that covers parts and labor. For warranty claims, technical support, or further assistance, please visit the official Dyson support website or contact their customer service. You can also refer to the official User Manual (PDF) for detailed information: Dyson V7 User Manual PDF.

© 2024 Dyson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0748QCKZ5

More documents and user manuals: **https://manuals.plus/**