

UPBRIGHT Resound GN Hearing SAS-3 USB Cable

UPBRIGHT USB-C and Micro USB Charging Cable User Manual

Model: Resound GN Hearing SAS-3 USB Cable

Brand: UPBRIGHT

1. INTRODUCTION

This manual provides instructions for the UPBRIGHT USB-C and Micro USB 5V Charging Cable. This versatile cable is designed to provide reliable power delivery for a range of compatible devices, including the Resound Model SAS-3, C-3, SAS3, C3 Unite TV Streamer 2, and other 2nd Generation GN Hearing A/S devices. It features both Micro USB and USB-C connectors to ensure broad compatibility with various electronic devices.

Please read this manual thoroughly before using the product to ensure proper operation and longevity.

2. PRODUCT FEATURES

- **Dual Connectivity:** Equipped with both Micro USB and USB-C connectors, offering compatibility with a wide array of devices, including both older and newer models.
- **Universal Charging:** Provides 5V DC power for efficient and safe charging.
- **Broad Compatibility:** Specifically designed for devices such as Resound Model SAS-3, C-3, SAS3, C3 Unite TV Streamer 2, and other 2nd Generation GN Hearing A/S products. Also compatible with various PCs and televisions for power delivery.
- **Durable Design:** Constructed for long-lasting performance and features a tangle-free design for ease of use and storage.
- **Quality Assurance:** Each unit undergoes testing to ensure functionality and reliability.



Image 1: The UPBRIGHT charging cable set, featuring both Micro USB and USB-C connectors for broad device compatibility.




Image 2: A visual representation of the cable's dual Micro USB and USB-C connectors, highlighting their compatibility with various devices. The standard USB-A connector is also shown.

Product Overview Video

Your browser does not support the video tag.

Video 1: An official overview of the UpBright USB Charging Cable, demonstrating its features and compatibility.

3. SETUP

- 1. Identify Connectors:** Determine whether your device requires a Micro USB or a USB-C connector. The cable includes both types.
- 2. Connect to Power Source:** Insert the standard USB-A end of the charging cable into a compatible 5V DC USB power adapter (not included), a computer's USB port, or a USB hub.
- 3. Connect to Device:** Carefully insert the appropriate Micro USB or USB-C connector into the charging port of your device. Ensure the connector is oriented correctly to avoid damage.
- 4. Verify Connection:** Confirm that both ends of the cable are securely connected. Most devices will indicate

charging status (e.g., an LED indicator or on-screen icon).



Image 3: The Micro USB charging cable, suitable for devices with a Micro USB port.



Image 4: The USB-C charging cable, designed for devices equipped with a USB-C port.

4. OPERATION

Once properly connected, the cable will facilitate the charging of your compatible device. The charging speed may

vary depending on the power source and the device's charging capabilities. For optimal performance, use a 5V DC power adapter.

The cable is designed for simple plug-and-play operation. No additional software or drivers are required.

5. MAINTENANCE

- **Storage:** Store the cable in a cool, dry place away from direct sunlight and extreme temperatures. The tangle-free design helps prevent knots and damage.
- **Cleaning:** If necessary, gently wipe the cable and connectors with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Handling:** Avoid excessive bending, twisting, or pulling on the cable, especially near the connectors, to prevent internal wire damage. Always grasp the connector head when plugging or unplugging.
- **Inspection:** Periodically inspect the cable for any signs of wear, fraying, or damage. Discontinue use if any damage is observed.

6. TROUBLESHOOTING

Device Not Charging

- **Check Connections:** Ensure both ends of the cable are securely plugged into the power source and the device.
- **Verify Compatibility:** Confirm that the correct connector (Micro USB or USB-C) is being used for your device.
- **Test Power Source:** Try plugging the USB-A end into a different USB port or power adapter to rule out issues with the power source.
- **Inspect Cable:** Check the cable for any visible damage, such as cuts or frayed wires. If damaged, replace the cable.
- **Device Issue:** If the cable and power source are confirmed to be working, the issue might be with the device's charging port or internal components.

Slow Charging

- **Power Source Output:** Ensure your power adapter provides sufficient current (amperage) for your device. Some devices require higher amperage for faster charging.
- **Background Apps:** Close unnecessary applications on your device that might be consuming power during charging.

7. SPECIFICATIONS

Brand	UPBRIGHT
Model Number	Resound GN Hearing SAS-3 USB Cable
Connector Type	USB-A, Micro USB, USB-C
Cable Type	USB
Compatible Devices	Resound Model SAS-3, C-3, SAS3, C3 Unite TV Streamer 2, 2nd Generation GN Hearing A/S devices, PC, Television
Power Output	5V DC

Special Feature	Tangle Free
Product Dimensions	5 x 2 x 1 inches; 1 ounces

8. WARRANTY AND SUPPORT

This UPBRIGHT product comes with a **24-month exchange warranty**, ensuring long-lasting performance and customer satisfaction. Additionally, a **30-day refund policy** is available from the date of purchase. For technical support, warranty claims, or further assistance, please refer to the seller's contact information on the product's purchase page or visit the official UPBRIGHT store on Amazon:

[Visit the UPBRIGHT Store on Amazon](#)

© 2025 UPBRIGHT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question