

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Simpeak](#) /

› [Simpeak S10 Protective Case for Anker SoundCore Mini/Mini 3 Bluetooth Speaker User Manual](#)

## Simpeak S10

# Simpeak S10 Protective Case for Anker SoundCore Mini/Mini 3 Bluetooth Speaker

User Manual

## 1. INTRODUCTION

---

This manual provides comprehensive instructions for the Simpeak S10 Protective Case, designed to safeguard your Anker SoundCore Mini or SoundCore Mini 3 Bluetooth portable speaker. Please read this manual thoroughly to ensure proper use and care of your protective case.



Figure 1.1: The Simpeak S10 protective case in black, featuring a durable zipper and an attached carabiner for portability.

## 2. PRODUCT FEATURES

---

- **Compact Size:** Designed to fit the Anker SoundCore Mini/Mini 3 perfectly without adding unnecessary bulk.
- **Premium EVA Material:** Constructed from durable EVA material with a thick fabric interior for excellent scratch and shock protection.
- **Integrated Accessory Compartment:** Features a mesh pocket inside the lid for storing charging cables or small accessories.
- **Portable Design:** Includes a sturdy carabiner for easy attachment to backpacks, belts, or bicycle handlebars, enhancing portability.
- **Secure Closure:** Equipped with a reliable zipper to keep your speaker securely enclosed.



Figure 2.1: The interior of the Simpeak S10 case with a speaker, illustrating the protective EVA material.

### 3. SETUP

---

The Simpeak S10 Protective Case requires minimal setup. Follow these steps to prepare your case for use:

1. **Unpack the Case:** Carefully remove the protective case from its packaging.
2. **Inspect for Damage:** Before first use, inspect the case for any signs of damage during transit.
3. **Prepare Speaker:** Ensure your Anker SoundCore Mini or Mini 3 speaker is clean and free of debris before placing it into the case.

### 4. OPERATING INSTRUCTIONS

---

Using the Simpeak S10 Protective Case is straightforward:

1. **Open the Case:** Unzip the case completely to reveal the interior.
2. **Insert Speaker:** Gently place your Anker SoundCore Mini or Mini 3 speaker into the main compartment of the case. Ensure it fits snugly.
3. **Store Accessories:** Use the mesh pocket in the lid to store small accessories such as charging cables or USB adapters.
4. **Close the Case:** Zip the case securely to protect your speaker from impacts, dust, and scratches.
5. **Attach Carabiner (Optional):** If desired, attach the included carabiner to the case's loop and then to a backpack, belt loop, or other suitable attachment point for convenient carrying.



Figure 4.1: The Simpeak S10 case opened, showing the main compartment for the speaker and the mesh pocket for accessories.



Figure 4.2: The Simpeak S10 case attached to a bicycle handlebar using the carabiner for outdoor use.

## 5. MAINTENANCE

---

Proper maintenance will extend the life of your Simpeak S10 Protective Case:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth. Allow to air dry completely.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Zipper Care:** Periodically check the zipper for smooth operation. If it becomes stiff, a small amount of zipper lubricant can be applied.

## 6. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your protective case.

Problem	Possible Cause	Solution
Speaker does not fit	Incorrect speaker model.	Ensure your speaker is an Anker SoundCore Mini or SoundCore Mini 3. This case is specifically designed for these models.
Zipper is stiff or stuck	Dirt or debris in zipper teeth; lack of lubrication.	Clean the zipper teeth with a small brush. Apply a small amount of zipper lubricant or wax.
Case appears damaged	Impact during use or manufacturing defect.	If the damage affects protection, consider replacing the case. Contact Simpeak customer support if it's a manufacturing defect.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	Simpeak
Model Number	S10
Compatible Devices	Anker SoundCore Mini, Anker SoundCore Mini 3
Material	EVA (Ethylene-vinyl acetate)
Color	Black
Special Features	Integrated accessory compartment, carabiner for portability
Dimensions (Case)	Approximately 91mm (height) x 80mm (diameter)



Figure 7.1: Dimensions of the Simpeak S10 case and a compatible Anker SoundCore Mini speaker.

## 8. WARRANTY AND SUPPORT

Simpeak products are designed for durability and performance. For warranty information or technical support, please refer to the official Simpeak website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, you may visit the [product page on Amazon](#).

