

Brondi Window

Brondi Window Flip Phone User Manual

Model: Window

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Brondi Window flip phone. Please read it carefully before using the device and keep it for future reference.





Image 1.1: Brondi Window Flip Phone (Open, Front View). This image displays the phone in its open position, showing the main display, keypad, and the outer window.

2. GETTING STARTED: SETUP

2.1 Package Contents

Ensure your package contains the following items:

- Brondi Window Mobile Phone
- Mains Charger

2.2 Installing the Battery and SIM Cards

To install the battery and SIM cards:

1. Carefully remove the back cover of the phone.
2. Insert your SIM card(s) into the designated slot(s). This phone supports Dual SIM functionality.
3. Insert the battery, ensuring the contacts align correctly.
4. Replace the back cover until it clicks into place.



Image 2.1: Brondi Window Flip Phone (Back View). This image shows the rear of the phone, including the camera lens and speaker grille, where the back cover is located for battery and SIM access.

2.3 Charging the Phone

Before first use, fully charge the phone battery. Connect the charger to the phone's charging port and plug it into a power outlet. The charging indicator will show the charging status.

2.4 Powering On/Off

To power on the phone, press and hold the Power/End Call button until the screen lights up. To power off, press and hold the same button and select 'Power off' from the options.

2.5 Initial Settings

Upon first power-on, you may be prompted to set the language, date, and time. Follow the on-screen instructions to configure these basic settings.

3. OPERATING YOUR PHONE

3.1 Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the Call button (green).
- **Receiving a Call:** Open the flip to answer an incoming call. Close the flip to end a call.

3.2 Keypad Functions

The keypad includes numerical keys, navigation keys, and dedicated function keys. Refer to the on-screen prompts for specific key functions within menus.



Image 3.1: Brondi Window Flip Phone (Open, Keypad View). This image highlights the phone's keypad and navigation buttons, crucial for dialing and menu interaction.

3.3 Display Information

The 1.77-inch color display shows network signal strength, battery level, time, date, and caller ID information through the outer window when the phone is closed.

3.4 Menu Navigation

Use the navigation keys to scroll through menu options. Press the central selection key to confirm an option. The menu allows access to contacts, messages, call history, settings, and other features.

3.5 Camera Usage

Access the camera from the main menu. Use the navigation keys to frame your shot and the central selection key to capture photos. The phone features a 1.3 MP optical sensor resolution.

3.6 Bluetooth Connectivity

To pair with a Bluetooth device, go to the Bluetooth settings in the menu, turn Bluetooth on, and search for available devices. Select your device and follow the pairing instructions.

3.7 Dual SIM Management

If you have two SIM cards installed, you can manage them through the SIM management settings in the phone's menu. This allows you to select which SIM to use for calls, messages, or data (if applicable).

4. MAINTENANCE

4.1 Cleaning

Clean the phone with a soft, dry cloth. Avoid using liquid cleaners or aerosols, as they may damage the device.

4.2 Battery Care

To prolong battery life, avoid exposing the phone to extreme temperatures. Do not leave the phone charging for extended periods after it is fully charged.

4.3 Storage

Store the phone in a dry place, away from direct sunlight and moisture, when not in use for extended periods.

4.4 Water Resistance

The Brondi Window phone is *not water resistant*. Avoid contact with liquids to prevent damage.

5. TROUBLESHOOTING

If you encounter issues with your phone, try the following solutions:

- **Phone does not power on:** Ensure the battery is correctly installed and sufficiently charged. Connect the charger and try again.
- **No network signal:** Check if your SIM card is properly inserted. Move to an area with better network coverage.
- **Cannot make or receive calls:** Verify network signal. Check if call barring is enabled in settings. Ensure your SIM card is active.
- **Charging issues:** Ensure the charger is correctly connected to both the phone and the power outlet. Try a different power outlet or charger if available.
- **Screen is unresponsive or frozen:** Try restarting the phone by removing and reinserting the battery, then powering it on again.

6. SPECIFICATIONS

Feature	Specification
Brand	Brondi
Model Name	Window
Operating System	Android (Basic Phone OS)
Screen Size	1.77 Inches
Resolution	128 x 160 Pixels
Cellular Technology	GSM
Connectivity	Bluetooth
Wireless Network Technology	GSM, Wi-Fi
SIM Slots	Dual SIM
Camera Resolution	1.3 MP
Weight	78 Grams
Dimensions	5 x 1.7 x 10.3 cm
Talk Time	2 Hours
Average Battery Life (in use)	2 Hours

Video Capture Resolution	1280 x 720
Headphone Jack	3.5 mm
Water Resistance	Not Water Resistant
Package Contents	Mobile Phone, Mains Charger

7. WARRANTY INFORMATION

The Brondi Window flip phone comes with a**2-year product warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized repairs.

8. SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Brondi customer service. Refer to the official Brondi website or product packaging for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question