

Manuals.plus /

› SOAIY /

› SOAIY Touch LED Night Light (3-Pack) Instruction Manual

SOAIY Touch Light

SOAIY Touch LED Night Light Instruction Manual

Model: Touch Light

INTRODUCTION

Thank you for choosing the SOAIY Touch LED Night Light. This manual provides detailed instructions for the safe and efficient use of your new lights. Please read this manual thoroughly before installation and operation, and retain it for future reference.

SAFETY INFORMATION

- Use only AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- Ensure batteries are inserted with correct polarity (+/-). Incorrect insertion can cause damage.
- Remove batteries if the light will not be used for an extended period to prevent leakage.
- Do not expose the light to water or excessive moisture. This product is designed for indoor use only.
- Keep out of reach of small children to prevent choking hazards from small parts or batteries.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 3 x SOAIY Touch LED Night Lights
- 3 x 3M Double-sided Adhesive Pads
- 6 x Metal Plates (for magnetic mounting)

Note: 3 AAA batteries are required per light (total 9 AAA batteries for a 3-pack) and are not included.



Image: Package contents showing three SOAIY Touch LED Night Lights, 3M adhesive pads, and metal plates.

SETUP

1. Battery Installation

1. Hold the edge of the light with your fingers.
2. Place your other palm on the back cover.
3. Press slightly and twist the back cover counter-clockwise to open.
4. Insert 3 AAA batteries, ensuring correct polarity.
5. Align the back cover with the light and twist clockwise to close securely.

**Ultra thin only 0.8inch, Portable Size for Anywhere.
3AAA Battery Powered, Safe for Kids**



Image: Visual guide for opening the light and installing batteries.

2. Mounting Options

The SOAIY Touch LED Night Light offers two primary mounting methods:

- **Direct Magnetic Attachment:** The light has a built-in magnet and can directly attach to any metal surface (e.g., refrigerators, metal cabinets).
- **Adhesive Mounting with Metal Plate:** For non-metal surfaces, use the provided 3M adhesive pads and metal plates.
 1. Clean the desired mounting surface to ensure it is dry and free of dust.
 2. Peel the protective film from one side of a 3M adhesive pad and attach it to a metal plate.
 3. Peel the protective film from the other side of the adhesive pad and firmly press the metal plate onto the cleaned surface.
 4. Attach the light magnetically to the installed metal plate. This allows for easy removal for battery changes.



Image: Mounting options illustrating direct magnetic attachment and use of 3M adhesive with metal plates.

OPERATING INSTRUCTIONS

1. Power On/Off

To turn the light on or off, simply touch the center of the light's surface. A soft touch will toggle the power state.

One Touch for ON/OFF



Image: One-touch functionality for turning the light on and off.

2. Stepless Dimming and Brightness Memory

The light features stepless dimming and a brightness memory function:

- **To Adjust Brightness:** Long press the touch button. The brightness will gradually increase or decrease. Release your finger when the desired brightness level is reached.
- **Brightness Memory:** The built-in memory chip will remember the last brightness setting you selected, so the light will turn on at that level next time.

Hold Down for Stepless Dimming



Image: Demonstrating the long-press function for stepless dimming.

MAINTENANCE

1. Battery Replacement

When the light begins to dim or fails to turn on, it's time to replace the batteries. Follow the battery installation steps in the Setup section to replace the 3 AAA batteries.

2. Cleaning

To clean the light, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or immerse the light in water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Dead or incorrectly installed batteries.	Check battery polarity and replace with fresh AAA batteries.
Light is dim.	Low battery power.	Replace batteries with fresh AAA batteries.
Light does not dim.	Not performing a long press.	Ensure you are long-pressing the touch surface to activate dimming.
Light falls off mounting surface.	Improper surface preparation or weak adhesive.	Clean surface thoroughly before applying adhesive. Replace adhesive pad if necessary. Ensure metal plate is securely attached for magnetic mounting.

SPECIFICATIONS

Feature	Detail
Brand	SOAIY
Model Name	SOAIY Touch Light Battery Powered Ultra-Thin Touch Sensor LED Cabinet Lights, Magnet Stick-on Closet Light, LED Tap Night Lights
Light Source Type	LED (6 SMD LEDs)
Color Temperature	5000K (Cool White Light)
Brightness	36 Lumens
Power Source	3 x AAA Batteries (not included)
Control Method	Touch (On/Off, Dimmable)
Special Feature	Dimmable, Brightness Memory, Magnetic Mounting
Product Dimensions	3.1"L x 3.1"W x 0.8"H
Material	Plastic
Indoor/Outdoor Usage	Indoor



Image: Product dimensions highlighting the ultra-thin design.



- Space-Saving Flat Panel Design
- Neutral White Light for Various Occasions
- Compact and Slim not Block Things

5000K
NEUTRAL WHITE LIGHT

LIGHT COLOR

CORRELATED COLOR TEMPERATURE (CCT) :




Image: Light color temperature information, indicating 5000K neutral white light.

APPLICATIONS

The SOAIY Touch LED Night Light is versatile and suitable for various indoor locations:

- Closets and Wardrobes
- Under Cabinets (Kitchen, Bathroom)
- Hallways and Stairwells
- Bedrooms (as a nightstand light)
- Drawers and Bookcases
- Home Bars and Safe Boxes




Image: Examples of the light in use in different household areas.

WARRANTY AND SUPPORT

SOAIY products are designed for quality and reliability. For any issues or questions regarding your Touch LED Night Light, please contact SOAIY customer support. Refer to the product packaging or the official SOAIY website for contact information and specific warranty details.