

[Manuals.plus](#) /

> [Babymoov](#) /

> Babymoov Duo Meal Station Grey: Multi-Speed Baby Food Maker Steamer and Puree Blender, Baby Food Processor that warms & defrosts (Nutritionist Approved) Industrial Grey

Babymoov A001125

Babymoov Duo Meal Station User Manual

Brand: Babymoov | Model: A001125

PRODUCT OVERVIEW

The Babymoov Duo Meal Station is a versatile 6-in-1 baby food maker designed to simplify meal preparation for parents. It combines steaming, blending, warming, defrosting, sterilizing, and bottle warming functionalities into a single, easy-to-use appliance.

Key Features:

- **6-in-1 Functionality:** Steam cooking, blending, defrosting, sterilizing, and bottle warming.
- **Large Capacity:** Generous 74 oz capacity for preparing multiple meals.
- **Nutrient Preservation:** Optimal steam cooking preserves natural flavors and nutrients.
- **Intuitive Controls:** Easy-to-read LCD display and programmable settings.
- **Easy to Clean:** Dishwasher-safe components and BPA-free materials.

PRODUCT COMPONENTS

The Babymoov Duo Meal Station consists of several key components designed for ease of use and versatility.



Figure 1: Exploded view of the Duo Meal Station showing all detachable parts.

Included in the Box:

- Main Unit (Base with control panel)
- Steaming Unit (with two separate cooking baskets)
- Blending Unit (with chopping blade and lid)
- Spatula

SETUP GUIDE

Before First Use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash all removable parts (steaming baskets, blending jug, lids, chopping blade) with warm soapy water or in the dishwasher. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the main unit on a stable, flat, heat-resistant surface away from direct heat sources.

Assembly:

1. **Steaming Unit Assembly:** Place the steaming base onto the main unit. Insert the lower steaming basket, followed by the upper steaming basket if using both. Place the lid securely on top.
2. **Blending Unit Assembly:** Ensure the chopping blade is securely in place within the blending jug. Place the blending jug onto its designated spot on the main unit. Secure the blending lid.



Figure 2: Fully assembled Babymoov Duo Meal Station ready for use.

OPERATING INSTRUCTIONS

1. Steaming Food:

1. **Add Water:** Fill the water reservoir in the main unit (under the steaming baskets) with the appropriate amount of water according to the food type and desired cooking time.
2. **Prepare Food:** Cut ingredients into small, uniform pieces for even cooking. Place them in the steaming baskets. You can use one or both baskets.
3. **Select Program:** On the control panel, press the steam icon. Use the arrow buttons to adjust the steaming time (e.g., 10-25 minutes depending on food). Press 'OK' to confirm.
4. **Start Steaming:** The unit will begin steaming. An audible and visual alarm will indicate when the cycle is complete.



Figure 3: Steaming vegetables in the Duo Meal Station.

2. Blending Food:

1. **Transfer Food:** Once steamed, carefully transfer the cooked ingredients from the steaming baskets into the blending jug.
2. **Add Liquid (Optional):** For smoother purees, add some of the cooking liquid from the steaming unit or breast milk/formula.
3. **Select Speed:** Secure the blending lid. On the control panel, press the blend icon. Choose from 3 speed settings using the arrow buttons.
4. **Start Blending:** Press 'OK' to begin blending. Blend in short pulses until desired consistency is achieved.



Figure 4: Blending pureed food for baby.

3. Warming Bottles/Jars:

1. **Place Bottle/Jar:** Place the bottle or jar directly into one of the steaming baskets.
2. **Add Water:** Fill the water reservoir with the recommended amount of water for warming (refer to manual for specific quantities based on bottle size).
3. **Select Program:** Press the bottle warming icon on the control panel. Adjust time if necessary. Press 'OK'.

4. Defrosting Food:

1. **Place Food:** Place frozen food portions (in appropriate containers) into the steaming baskets.
2. **Add Water:** Fill the water reservoir with the recommended amount of water for defrosting.
3. **Select Program:** Press the defrost icon on the control panel. Adjust time if necessary. Press 'OK'.

5. Sterilizing:

1. **Place Items:** Place small items like pacifiers, bottle nipples, or small accessories into the steaming baskets.

2. **Add Water:** Fill the water reservoir with the recommended amount of water for sterilizing.
3. **Select Program:** Press the sterilize icon on the control panel. Adjust time if necessary. Press 'OK'.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your Duo Meal Station.

Daily Cleaning:

- **Detachable Parts:** All removable components (steaming baskets, blending jug, lids, chopping blade) are dishwasher safe. Alternatively, wash them by hand with warm soapy water and rinse thoroughly.
- **Main Unit:** Wipe the main unit and control panel with a damp cloth. Do not immerse the main unit in water.

Descaling (Monthly or as needed):

To prevent limescale buildup in the water reservoir, descale the unit regularly, especially in areas with hard water.

1. Mix 1 part white vinegar with 1 part water.
2. Pour the mixture into the water reservoir.
3. Run a steaming cycle (without food) for 10-15 minutes.
4. Empty the reservoir and rinse thoroughly with clean water.

TROUBLESHOOTING

If you encounter any issues with your Duo Meal Station, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Unit not turning on.	Not plugged in, power switch off.	Ensure unit is properly plugged into a working outlet and the main power switch is on.
Steaming function not working.	Insufficient water in reservoir, lid not properly closed.	Fill water reservoir to the appropriate level. Ensure steaming lid is securely closed.
Blending function not working.	Blending jug/lid not properly assembled, food too hard/large.	Ensure blending jug and lid are correctly assembled and locked. Cut food into smaller pieces.
Limescale buildup.	Hard water usage.	Perform regular descaling as per maintenance instructions.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Babymoov
Model Name	Duo Meal Station
Item Model Number	A001125
Color	Industrial Grey

Feature	Detail
Product Dimensions	12.4"D x 9.8"W x 15.6"H
Item Weight	5.95 pounds
Bowl Capacity	4.6 Pounds (approx. 74 oz)
Number of Speeds	3
Blade Material	Stainless Steel
Material Type	Cooking baskets: Tritan, Trays and lids: Polypropylene BPA-Free, Mixing bowl: SAN
Dishwasher Safe	Yes (removable parts)

WARRANTY AND SUPPORT

Babymoov stands behind the quality of the Duo Meal Station with a comprehensive warranty and dedicated support.

Lifetime Warranty:

The Babymoov Duo Meal Station is backed by a lifetime warranty, ensuring your investment is protected for years to come. Please register your product on the official Babymoov website to activate your warranty.

Additional Resources:

- **Official User Manual (PDF):** [Download PDF Manual](#)
- **Babymoov Official Store:** [Visit Babymoov Store on Amazon](#)
- **Customer Support:** For further assistance, please visit the Babymoov support page on their official website or contact their customer service team.