Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEDGLE 3045655

LEDGLE LED Neck Reading Light

Model: 3045655

Introduction

Thank you for choosing the LEDGLE LED Neck Reading Light. This innovative, hands-free lighting solution is designed for comfort and versatility, perfect for reading, crafting, or any activity requiring focused illumination. This manual provides essential information for the safe and efficient use of your device.

Product Overview and Features

The LEDGLE Neck Reading Light offers a unique design with flexible arms and multiple lighting modes to suit various needs.

- **High Performance Illumination:** Each light head features both a wide flood light and an intensive spot light, allowing you to choose the appropriate illumination for your task.
- **Flexible Arms:** The bendable and strong arms allow for precise positioning of the light, ensuring optimal angle and brightness.
- **Rechargeable Design:** Equipped with a built-in 650mAh lithium battery, providing long-lasting and stable illumination on a single charge.
- **Portable and Lightweight:** Designed to be worn comfortably around the neck, freeing your hands for other activities.
- **Wide Application:** Ideal for indoor and outdoor use, including reading in bed, night running, repairs, knitting, and more.



A detailed diagram highlighting the key components of the neck light: the 2 flood and 2 spot LED lights on each head, the flexible soft rubber lamp arms, the anti-slip cotton pad for comfort, and the USB charging port.



This image focuses on the anti-slip design in the middle section for comfortable wear and the easily accessible USB charging port for convenient recharging.

Setup

Initial Charging

Before first use, fully charge the device. Connect the included USB cable to the light's charging port and to a standard USB power source (e.g., computer, wall adapter). The charging indicator will glow red while charging and turn green when fully charged. A full charge takes approximately 2.5 hours.



This image illustrates the charging process, showing the micro-USB charging port, the red indicator light for charging, the green indicator light for a full charge, and the included USB charging cable.

Wearing the Device

Place the light around your neck with the flexible arms extending forward. Adjust the arms to position the light heads as desired for your activity. The anti-slip pad in the middle ensures a comfortable and secure fit.



A visual guide showing four steps to properly adjust and wear the neck reading light, ensuring a secure and comfortable fit around the neck.

Operating Instructions

Power On/Off and Brightness Adjustment

Each light head operates independently. Locate the touch switch on each light head.

1. **First Touch:** Activates the wide flood light (low brightness).
2. **Second Touch:** Switches to the intensive spot light (medium brightness).
3. **Third Touch:** Activates both the flood and spot lights (high brightness).
4. **Fourth Touch:** Turns the light off.

You can mix and match the settings on each arm to achieve your desired lighting combination.



An illustration demonstrating the two types of illumination provided by each light head: a wide, soft flood light and an intensive, bright spot light, allowing for versatile lighting options.

Adjusting Light Angle

Gently bend the flexible arms to direct the light exactly where you need it. The arms are designed to hold their position once adjusted.

Charging

When the battery is low, the light output may diminish. Recharge the device using the provided USB cable. The charging indicator will show red during charging and green when fully charged. Avoid overcharging by disconnecting the device once the green indicator appears.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.


- **Storage:** Store the light in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, charge the device regularly, even if not in frequent use. Avoid completely draining the battery for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the device fully.
Light is dim.	Low battery.	Recharge the device.
Charging indicator not working.	Cable or power source issue.	Try a different USB cable or power adapter. Ensure connections are secure.
Flexible arms do not hold position.	Excessive force or wear.	Avoid over-bending the arms. If the issue persists, contact support.

Specifications

Feature	Detail
Brand	LEDGLE
Model Number	3045655
Product Dimensions	26 x 3.6 x 14 cm (10.2 x 1.4 x 5.5 inches)
Item Weight	135 grams
Lamp Type	Book light, Night light
Shade Color	Black
Shade Material	Acrylonitrile Butadiene Styrene (ABS)
Switch Type	Touch
Style	Modern
Battery	650mAh Lithium Battery
Charging Time	Approx. 2.5 hours



This diagram provides the approximate dimensions of the neck light, measuring 10.2 inches (26 cm) in height and 5.5 inches (14 cm) in width when laid flat.

Safety Information

- Do not look directly into the LED lights to avoid eye strain.
- Keep out of reach of children.
- Do not disassemble or modify the device. This may void the warranty and pose a safety risk.
- Avoid exposing the device to water or extreme temperatures.
- Use only the provided USB cable or a certified equivalent for charging.

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074DS8J8Z

More documents and user manuals: **https://manuals.plus/**