

[Manuals.plus](#) /

› [PROALLER](#) /

› PROALLER Electric Heated Blanket Queen Size User Manual BLV-HP204B

PROALLER BLV-HP204B

PROALLER Electric Heated Blanket User Manual

MODEL: BLV-HP204B

Queen Size, 84" x 90"

1. Introduction

Thank you for choosing the PROALLER Electric Heated Blanket. This blanket is designed to provide warmth and comfort with advanced heating technology and user-friendly features. Please read this manual thoroughly before use to ensure safe and optimal operation.



Figure 1: PROALLER Electric Heated Blanket, folded with its controller.

This image shows the PROALLER Electric Heated Blanket in a warm gray color, neatly folded. The white digital controller is visible,

connected to the blanket, indicating its readiness for use. The blanket's soft flannel texture is apparent.

2. Important Safety Instructions

To reduce the risk of burns, electric shock, fire, or injury, please observe the following:

- Do not use with an infant, a child, an incapacitated person, or anyone insensitive to heat.
- Do not use on areas of the body that are swollen, inflamed, or have open wounds.
- Never use the blanket if it is wet.
- Do not use pins or other metallic objects with this blanket.
- Do not use if the power cord or controller is damaged.
- Always unplug the blanket from the electrical outlet when not in use.
- Do not dry clean this product. Cleaning solvents may damage the insulation of the heating element.
- Do not tuck in the power cord or controller.
- Ensure the blanket is used on a flat surface and not bunched up.

3. Product Features

- **Fast Heating:** Utilizes PTC and NTC heating technology for even and rapid heating.
- **6 Heating Levels:** Temperature range from 85°F to 110°F for personalized comfort.
- **8-Hour Auto-Off Timer:** Provides safety and conserves energy.
- **Overheat Protection:** Enhanced safety feature.
- **Ultra Soft Flannel:** Made of double-sided flannel for skin-friendly softness.
- **Full Body Coverage:** Queen size (84" x 90") ensures ample coverage.
- **Versatile Use:** Can be used on a bed, as a cape, for naps, or on a sofa.
- **Machine Washable:** Easy to clean after detaching the controller.
- **Long Power Cord:** 10.7ft cord for flexible placement.




Figure 2: Internal heating element structure.

This diagram illustrates the multi-layer construction of the heated blanket, highlighting the internal heating wires and the soft flannel layers that ensure even heat distribution and comfort.

Ultra Soft Flannel & Use Friendly



Comfortable



ETL Certified



Smart Timer



Overheat
Protection

Figure 3: Ultra Soft Flannel and Key Features.

A close-up view of the blanket's ultra-soft flannel fabric, emphasizing its comfortable texture. Icons indicate features such as comfort, ETL certification, smart timer, and overheat protection.

4. Setup Instructions

1. Unpack the electric heated blanket and controller from its packaging.
2. Lay the blanket flat on your bed or desired surface, ensuring there are no wrinkles or folds.
3. Connect the controller to the blanket by firmly inserting the connector into the blanket's port. Ensure a secure connection.
4. Plug the power cord into a standard 120V AC electrical outlet.
5. Ensure the power cord is not pinched or covered by the blanket or other objects.



Figure 4: Controller and Power Cord.

This image displays the white digital controller and its attached power cord, ready to be connected to the electric blanket and plugged into a power source.

5. Operating Instructions

The blanket is operated using the attached digital controller. Familiarize yourself with the buttons:

- **Power Button:** Turns the blanket ON/OFF.
- **Temperature Buttons (+/-):** Adjusts the heating level (1-6).
- **Timer Button:** Sets the auto-off timer (1-8 hours).

5.1 Powering On and Adjusting Heat

1. Press the Power Button to turn on the blanket. The display will illuminate.
2. Use the '+' or '-' buttons to select your desired heating level from 1 to 6. Level 1 is the lowest heat (approx. 85°F), and Level 6 is the highest (approx. 110°F).
3. The blanket will begin to heat up quickly.

5.2 Setting the Auto-Off Timer

1. Press the Timer Button to cycle through the available auto-off settings (1 to 8 hours).
2. The selected time will be displayed on the controller. The blanket will automatically turn off after the set time has elapsed.

5.3 Powering Off

Press the Power Button again to turn off the blanket. Always unplug the blanket from the wall outlet when not in use for extended periods.

6 Heat Settings

To Meet Various Demands



Figure 5: Digital Controller in Use.

A hand is shown holding the digital controller, which displays the current heat setting and timer. An accompanying graphic illustrates the temperature range from 85°F to 110°F, corresponding to the 6 heating levels.



Figure 6: Detailed View of the Controller.

This close-up image highlights the digital display and control buttons of the blanket's controller, showing options for adjusting temperature and setting the timer.

Video 1: PROALLER Electric Blanket Overview.

This video provides a general overview of the PROALLER Electric Blanket, demonstrating its size and how it appears on a bed. It highlights the blanket's features and ease of use in a home setting.

6. Care and Maintenance

Proper care ensures the longevity and performance of your heated blanket.

6.1 Cleaning Instructions

1. **Disconnect Controller:** Always remove the controller from the blanket before washing. Pull out the power cord firmly at the connection point on the blanket.
2. **Machine Wash:** The blanket can be machine washed on a gentle cycle with water temperature below 30°C/86°F.
3. **Hand Wash:** Alternatively, the blanket can be hand washed.
4. **Drying:** Tumble dry on low heat or line dry. Ensure the blanket is completely dry before reconnecting the controller or using it.
5. **Do Not Dry Clean:** Avoid dry cleaning as it may damage the heating elements.
6. **Do Not Iron:** Do not iron the blanket.

Easy to Wash by Machine



Figure 7: Detaching Controller for Washing.

This image demonstrates the process of detaching the controller from the electric blanket, a necessary step before washing the blanket to prevent damage to the electronic components.

7. Troubleshooting

If your heated blanket is not functioning as expected, please refer to the following common issues and solutions:

- **Blanket not heating:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Verify that the controller is firmly connected to the blanket.
 - Check if the power button on the controller has been pressed to turn the unit ON.
 - If the controller displays an error code, unplug the blanket for a few minutes and then plug it back in.
- **Controller lights blinking:**

- This may indicate a loose connection or an internal error. Unplug the blanket from the wall, ensure all connections are secure, and then plug it back in.
- **Uneven heating:**
 - Ensure the blanket is laid flat and not bunched, folded, or tucked in tightly.

If the problem persists after trying these steps, please contact customer support.

8. Specifications

Brand	PROALLER
Model Number	BLV-HP204B
Material	Flannel
Color	Warm Gray
Size	84" x 90" (Queen)
Heating Levels	6 (85°F to 110°F)
Auto-Off Timer	1 to 8 hours
Power Cord Length	10.7 ft
Product Weight	7.24 pounds
UPC	713752495955

9. Warranty and Customer Support

For warranty information or if you require assistance with your PROALLER Electric Heated Blanket, please contact the manufacturer directly. Keep your purchase receipt as proof of purchase.
For further support, visit the [PROALLER Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question