VODA B074FV7T6P

VODA Replacement Fan Motor for Stove Fans

Instruction Manual - Model: B074FV7T6P

1. Introduction

Thank you for choosing the VODA Replacement Fan Motor. This motor is designed as a high-quality spare part for heat-powered stove fans, ensuring efficient operation and heat distribution. This manual provides essential information for safe installation, operation, and maintenance of your replacement motor.

Please read this manual thoroughly before attempting any installation or maintenance to ensure proper function and safety.

2. Safety Information

- Always ensure the stove fan is completely cool and disconnected from any heat source before attempting to replace the motor.
- Wear appropriate personal protective equipment, such as gloves, to prevent injury during installation.
- Handle the motor carefully to avoid damage to its components.
- Keep small parts, such as screws, out of reach of children.
- If you are unsure about any step, consult a qualified technician.

3. Package Contents

Verify that all items are present in your package:

- 1 x VODA Replacement Fan Motor
- 1 x Allen Wrench (for fan blade set screw)
- 1 x Screwdriver (for motor mounting screws)
- Mounting Screws

4. Setup and Installation

This section guides you through the process of replacing the motor in your heat-powered stove fan.

Tools Required:

- Included Allen Wrench
- Included Screwdriver

Installation Steps:

1. **Prepare the Fan:** Ensure your stove fan is completely cool. Carefully remove the fan from the stove surface.
2. **Access the Motor:** Depending on your fan model, you may need to remove a protective casing or cover to access the motor assembly. Refer to your original fan's manual if necessary.
3. **Remove Fan Blade:** Locate the set screw on the fan blade hub that secures it to the motor shaft. Use the provided Allen wrench to loosen this screw and carefully slide the fan blade off the old motor shaft.
4. **Disconnect Old Motor:** Identify the mounting screws holding the old motor in place. Use the provided screwdriver to remove these screws. Carefully disconnect any wiring if present (some models are direct thermoelectric connections).
5. **Install New Motor:** Position the VODA Replacement Fan Motor in the fan's housing. Secure it with the new mounting screws provided, using the screwdriver. Ensure the motor is firmly seated.
6. **Attach Fan Blade:** Slide the fan blade onto the shaft of the new motor. Align the set screw with the flat part of the motor shaft (if applicable) and tighten it securely with the Allen wrench. Ensure the blade spins freely without obstruction.
7. **Reassemble Fan:** Reattach any protective casings or covers that were removed.



Image 1: VODA Replacement Fan Motor. This image shows the compact design of the replacement motor, ready for installation into a compatible stove fan.



Image 2: Example of a heat-powered stove fan. The replacement motor is designed to fit inside the base of such a fan, driving the blades to circulate warm air.

5. Operating Instructions

Once the replacement motor is installed, the stove fan will operate as designed by its original manufacturer. The motor is heat-activated and requires no external power source.

- **Placement:** Place the stove fan on a flat, level surface on top of your wood stove, near the side or back. Ensure it is not directly in front of the stove pipe, as excessive heat can damage the fan.
- **Temperature Range:** The fan will begin to operate as the stove surface heats up, typically between 80°C (176°F) and 345°C (653°F). Operation outside this range may reduce efficiency or cause damage.
- **Automatic Operation:** The fan will automatically start spinning as the stove heats up and slow down/stop as it cools.

6. Maintenance

Regular maintenance ensures the longevity and efficiency of your stove fan with the new motor.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth to remove dust and debris. Ensure the fan is cool before cleaning.
- **Inspection:** Regularly inspect the fan blades for any signs of damage or bending. Ensure the motor is securely mounted and the fan blade set screw remains tight.
- **Storage:** If storing the fan for an extended period, ensure it is clean and dry, and store it in a cool, dry place.

7. Troubleshooting

If you encounter issues after replacing the motor, refer to the table below:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not spin after motor replacement.	• Stove surface not hot enough. • Fan blade set screw loose. • Motor not properly seated. • Damage during installation.	• Ensure stove surface reaches operating temperature (80°C - 345°C). • Check and tighten the fan blade set screw. • Verify motor mounting screws are secure. • Inspect for any visible damage to the motor or wiring.
Fan makes unusual noise.	• Fan blade unbalanced or bent. • Debris in fan mechanism. • Motor not securely mounted.	• Inspect fan blades for damage; gently adjust if slightly bent. • Clean fan blades and motor area. • Ensure motor mounting screws are tight.
Fan spins slowly or inconsistently.	• Stove temperature fluctuating. • Excessive dust/debris on fan. • Motor friction.	• Monitor stove temperature for consistency. • Clean fan blades and motor. • Ensure fan blade spins freely without resistance when cool.

8. Specifications

Feature	Detail
Brand	VODA
Model Number (ASIN)	B074FV7T6P
Material	Aluminum
Item Weight	4.2 ounces
Package Dimensions	6.61 x 5.35 x 1.61 inches
UPC	758910036564

9. Warranty and Support

For warranty information or technical support regarding your VODA Replacement Fan Motor, please contact the manufacturer directly through their official website or the retailer where the product was purchased. Please have your model number (B074FV7T6P) and purchase date available when contacting support.

© 2023 VODA. All rights reserved.