

[Manuals.plus](#) /

> [SONGMICS](#) /

> SONGMICS 72L Bamboo Laundry Basket with Lid - Model LCB10Y Instruction Manual

SONGMICS LCB10Y

SONGMICS 72L Bamboo Laundry Basket with Lid - Model LCB10Y

Instruction Manual

PRODUCT OVERVIEW

Thank you for choosing the SONGMICS 72L Bamboo Laundry Basket. This product is designed to provide a practical and aesthetically pleasing solution for laundry storage. It features a durable bamboo frame, a convenient lid, and a removable, washable inner bag.





Image 1: The SONGMICS 72L Bamboo Laundry Basket, showcasing its natural bamboo finish and lid.

PRODUCT FEATURES

- **Lid Design:** The basket includes a lid that can be opened and closed with one hand, helping to contain odors and protect laundry from dust.
- **Durable Construction:** Made from natural bamboo with 17 mm wide strips, ensuring stability and robustness. It supports a load of up to 20 kg.
- **Removable Laundry Bag:** Features a resistant and durable inner bag made from a 160 g/m² polyester/cotton blend. This bag is easily removable for transport to the washing machine and is machine washable (or hand washable).
- **Portability and Storage:** Equipped with cotton handles for easy relocation. The basket has a foldable structure, allowing it to be collapsed flat for compact storage when not in use.
- **Generous Capacity:** Offers a 72L storage capacity, suitable for a week's worth of laundry for one person, while maintaining a compact footprint (40 x 30 cm).

- Couvercle facile à ouvrir et à refermer d'une seule main
- Empêche les odeurs désagréables de se répandre
- Protège les vêtements de la poussière



En bambou

- Bandes de bambou de 17 mm de large
- Stable et robuste



Image 2: The laundry basket with its lid open, revealing the inner bag and the sturdy bamboo construction.

Avec sac intérieur

Fabriqué en tissu 160 g/m², le sac est résistant et durable



Amovible



Tissu de haute qualité



Lavable en machine

Image 3: Demonstration of the removable inner laundry bag, highlighting its portability and washability.

SETUP AND ASSEMBLY

The SONGMICS laundry basket is designed for easy assembly without the need for tools. It arrives flat-packed and can be quickly set up.

Assembly Steps:

1. Unfold the bamboo frame: Carefully expand the flat-packed bamboo structure into its upright rectangular shape.

2. Insert the bottom support: Ensure the bottom panel is securely placed to stabilize the basket.
3. Position the inner bag: Place the removable fabric bag inside the bamboo frame, aligning its top edge with the basket's rim.
4. Attach the lid: Secure the lid to the top of the basket. Ensure the lid's hinges align correctly with the basket's structure for proper function.

- Avec poignées en coton pour changer facilement sa place
- Facile à plier et à déplier



Image 4: Visual representation of the basket's foldable design and how it expands for use.

Assembly Video:

Video 1: A demonstration of the laundry basket's assembly process and its features in a home setting.

OPERATING INSTRUCTIONS

Using your SONGMICS laundry basket is straightforward:

- **Placing Laundry:** Lift the lid using the integrated handle and place dirty clothes into the removable inner bag. Close the lid to conceal contents and prevent odors.
- **Transporting Laundry:** When the basket is full, use the cotton handles on the sides to carry it to your washing area. Alternatively, remove the inner bag by its handles for easier transport of laundry.
- **Storage:** If the basket is not needed, remove the inner bag, collapse the bamboo frame flat, and store it in a compact space.

Léger et facile à déplacer

2 poignées latérales pour une mobilité pratique



Image 5: A person demonstrating the ease of moving the laundry basket using its side handles.

Product in Use Video:

Video 2: A short video showcasing the laundry basket's functionality and appearance in a bathroom setting.

MAINTENANCE AND CARE

Proper care will extend the life of your laundry basket:

- **Humidity Control:** To prevent mold growth, keep the product away from excessive humidity. Regularly dry the

basket in a dry and well-ventilated area.

- **Avoid Overfilling:** Do not overfill the basket beyond its capacity to prevent stress on the frame and potential dislocation of components.
- **Lid Usage:** Avoid frequently opening and closing the lid with excessive force to prolong the lifespan of the metal rings and hinges.
- **Cleaning the Inner Bag:** The removable cotton bag should be washed in water at 30°C (86°F).
- **Cleaning the Bamboo Frame:** Clean the bamboo parts with a damp cloth. Avoid harsh chemicals or abrasive cleaners.

SPECIFICATIONS

Feature	Detail
Model Number	LCB10Y
Material	Natural Bamboo, Polyester/Cotton Blend (Inner Bag)
Color	Natural Colors
Overall Dimensions (L x W x H)	40 x 30 x 60 cm (15.7 x 11.8 x 23.6 inches)
Capacity	72 Liters
Weight	2.2 kg (4.85 lbs)
Max. Load Capacity	20 kg (44 lbs)
Special Feature	Foldable



Volume



Capacité
de charge

Image 6: Detailed dimensions, volume, and load capacity of the laundry basket.

TROUBLESHOOTING

- **Lid not closing properly:** Ensure the inner bag is correctly positioned and not obstructing the lid's hinges. Check that the bamboo frame is fully expanded and stable.
- **Basket feels unstable:** Verify that the bottom support panel is firmly in place and the bamboo frame is fully extended and locked into its upright position.
- **Odor persistence:** Ensure the lid is closed completely. Regularly wash the inner bag and air out the bamboo

frame in a well-ventilated area.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact SONGMICS customer service directly. Keep your purchase receipt for any warranty claims.

