PopBabies P20

PopBabies P20 Portable Blender Instruction Manual

Model: P20 | Brand: PopBabies

1. About Your PopBabies Portable Blender

The PopBabies P20 Portable Blender is designed for convenience and healthy living. This personal blender allows you to prepare fresh shakes and smoothies wherever you are, thanks to its compact design and USB rechargeable battery.

- **Blend and Go:** Prepare and drink directly from the 14 oz. jar.
- **Compact Design:** Ideal for home, office, or travel.
- **Safe and Versatile:** Dishwasher-safe, food-grade material cups, perfect for shakes, smoothies, protein drinks, and baby food.
- **Unique Functionality:** Capable of blending while charging.
- **Powerful Performance:** Strong enough to crush ice cubes, frozen fruits, and seeds.



Figure 1: PopBabies Portable Blender, showcasing its compact design.

2. What's in the Box

Your PopBabies P20 Portable Blender package includes the following components:

- PopBabies Portable Blender (Grey Black)
- Ice Cube Tray
- Funnel
- Recipe Booklet

- User Manual
- USB Charging Cable



Figure 2: All included accessories: blender, ice cube tray, funnel, recipe book, user manual, and USB cable.

3. Setup

3.1 Initial Charge

Before first use, fully charge your blender. Connect the provided USB charging cable to the charging port on the blender base and to a compatible USB power source. A full charge typically takes 3-5 hours.



Figure 3: The USB charging port located on the blender base.

3.2 Assembly

Ensure the blender jar is securely twisted onto the motor base. The blender will not operate if the jar is not correctly aligned and tightened.

4. Operating Instructions

4.1 Preparing Ingredients

- Cut fruits and vegetables into pieces no larger than 2 inches.
- Add liquid (e.g., water, milk) up to 1/5 of the bottle's capacity.
- Do not fill the bottle more than 2/3 full with ingredients.
- Use the provided funnel for easy addition of ingredients like protein powder or small ice cubes.



Figure 4: The included funnel and ice cube tray simplify adding ingredients to the blender.

4.2 Blending Process

1. Add your prepared ingredients to the blender jar.
2. Securely attach the lid to the jar.
3. For optimal blending, reverse the blender first (turn it upside down), then press the power button to start.
4. Gently shake the blender during operation to ensure all ingredients are thoroughly mixed.
5. The blender will run for approximately 15 seconds per cycle. Press the button again for additional blending cycles if needed.



Figure 5: Visual instructions for preparing ingredients and operating the blender.

4.3 Blending Examples

Watch these official seller videos for demonstrations on how to create delicious smoothies with your PopBabies Portable Blender:

Your browser does not support the video tag.

Video 1: Demonstration of making a mango and banana smoothie using the PopBabies blender.

Your browser does not support the video tag.

Video 2: Short clip demonstrating the portability and ease of use for blending and drinking on the go.

Your browser does not support the video tag.

Video 3: Step-by-step preparation of a blueberry banana smoothie.

5. Maintenance and Cleaning

Proper maintenance ensures the longevity and hygiene of your PopBabies Portable Blender.

- **Easy Cleaning:** The blender jar and lid are dishwasher safe. Ensure the motor base is detached before placing the jar in the dishwasher.
- **Quick Clean:** For a quick clean, add a small amount of water and a drop of dish soap to the jar, reattach the base, and run a short blending cycle. Rinse thoroughly.
- **Motor Base:** Do not immerse the motor base in water. Wipe it clean with a damp cloth.

6. Troubleshooting

If you encounter issues with your PopBabies Portable Blender, refer to the following common solutions:

- **Blender Not Starting:** Ensure the jar is securely attached to the motor base. The blender has a safety mechanism that prevents operation if not properly assembled. Also, check if the battery is charged.
- **Ingredients Not Blending Smoothly:** Ensure ingredients are cut into small pieces (no larger than 2 inches). Add sufficient liquid (at least 1/5 of the bottle capacity). Do not overfill the blender (max 2/3 full). Try reversing the blender and shaking it gently during operation.
- **Battery Not Holding Charge:** Ensure the USB cable and power source are functioning correctly. Allow for a full 3-5 hour charge. If issues persist, contact customer support.
- **Motor Straining/Stopping:** This can occur with overly large or hard ingredients (like large ice cubes or fibrous greens). Reduce ingredient size and ensure adequate liquid. Do not force the blender if it struggles.

7. Specifications

Feature	Detail
Brand	PopBabies
Model Number	P20
Color	Grey Black
Capacity	14 Fluid Ounces
Product Dimensions	3.2"D x 3.2"W x 10.2"H
Item Weight	0.88 Pounds
Power Source	Battery Powered
Wattage	175 watts
Voltage	7.4 Volts
Blade Material	Aircraft 304 stainless steel
Container Material	Food grade AS, ABS
Material Type Free	BPA Free

Dishwasher Safe	Yes (jar and lid only)

8. Warranty and Support

Your PopBabies P20 Portable Blender comes with a**12-month limited warranty**. For any product inquiries, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official PopBabies website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question