

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sony](#) /

› [Sony WF-1000X Wireless Headphones Instruction Manual](#)

Sony WF-1000X

Sony WF-1000X Wireless Headphones Instruction Manual

Model: WF-1000X | Brand: Sony



INTRODUCTION

These true wireless earbuds feature a minimal design for a secure fit. Digital Noise Cancelling technology allows for an immersive audio experience, while Smart Listening adapts noise cancellation levels based on your activity. The included chargeable case provides up to 9 hours of uninterrupted listening.

WHAT'S IN THE Box

- Charging Case
- USB Cable (1)
- Earbuds (Long Hybrid silicone rubber earbuds: SS, S, M, L x2; Fitting Supporters: M, L x2; Triple-Comfort Earbuds: S, M, L x2)

PRODUCT OVERVIEW



The Sony WF-1000X earbuds securely placed within their compact charging case.



A detailed close-up of the Sony WF-1000X earbuds, highlighting their design.



A user wearing the Sony WF-1000X earbuds, demonstrating their in-ear fit.

SETUP

1. Charging the Earbuds and Case

Before initial use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB cable to the charging case and a power source. The indicator light on the case will show charging status. A full charge provides up to 9 hours of battery life.

2. Pairing with a Device

To pair the headphones with your device via Bluetooth:

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device, enable Bluetooth and search for available devices.
3. Select "WF-1000X" from the list to complete pairing.

For quick pairing with NFC-enabled devices, simply touch the device to the N-Mark on the charging case.

3. Sony | Headphones Connect App

Download the Sony | Headphones Connect app from your device's app store (Android/iOS). This app allows you to customize ambient sound settings, adjust noise cancelling levels, and access other smart listening features.

OPERATING INSTRUCTIONS

Digital Noise Cancelling and Ambient Sound Mode

The WF-1000X features Digital Noise Cancelling to minimize distractions. Utilize the Sony | Headphones Connect app to adjust noise cancelling levels or activate Ambient Sound Mode. Ambient Sound Mode allows you to hear important sounds from your surroundings without removing the earbuds, ideal for situations requiring awareness.

Hands-Free Calling

Make and receive calls hands-free using the left earpiece. Simply tap the earpiece to answer or end a call. The integrated microphone ensures clear communication.

Smart Listening by Adaptive Sound Control

This feature automatically detects your activity (e.g., walking, traveling, waiting) and adjusts the ambient sound settings accordingly. Configure preferences within the Sony | Headphones Connect app.

MAINTENANCE

Cleaning

- Regularly wipe the earbuds and charging case with a soft, dry cloth.
- Remove ear tips and clean any earwax or debris from the speaker mesh using a small, soft brush.
- Ensure all components are completely dry before placing earbuds back into the charging case.

Storage

Store the earbuds in their charging case when not in use to protect them and ensure they remain charged. Avoid exposing the device to extreme temperatures, humidity, or direct sunlight.

TROUBLESHOOTING

No Sound or Intermittent Connection

- Ensure both earbuds are charged.
- Verify Bluetooth is enabled on your device and the earbuds are paired.
- Try re-pairing the earbuds with your device.
- Move closer to your device to avoid interference.

Noise Cancelling Not Effective

- Ensure the ear tips are correctly sized and provide a snug fit in your ears.
- Adjust noise cancelling settings via the Sony | Headphones Connect app.

Cannot Make/Receive Calls

- Confirm the earbuds are connected to your phone for calls.
- Check microphone settings on your connected device.

SPECIFICATIONS

Feature	Detail
Model Name	WF-1000X
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth, NFC
Included Components	Headphone
Material	Rubber, Silicone
Specific Uses For Product	Travel, Mobility, Commuting, Exercise
Charging Time	1.5 Hours
Compatible Devices	Smartphones, Tablets, Laptops, Desktops, Bluetooth-enabled Devices
Control Type	Control
Cable Feature	Without Cable
Item Weight	9.12 ounces
Water Resistance Level	Water Resistant
Control Method	App
Number of Items	1
Battery Life	9 Hours
Audio Driver Type	Dynamic Driver
Bluetooth Range	10 Meters
Bluetooth Version	4.1
Carrying Case Material	Plastic
Carrying Case Color	Black
Audio Driver Size	6 Millimeters
Earpiece Shape	Rounded Tips
Input Device Interface	Bluetooth
Generation	1
Special Feature	Wireless
Manufacturer	Sony

Feature	Detail
Product Dimensions	4.96 x 2.36 x 6.02 inches
Ear Placement	In Ear
Form Factor	In Ear
Noise Control	Active Noise Cancellation

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Sony support website. Keep your proof of purchase for any warranty claims.

OFFICIAL PRODUCT VIDEOS

Your browser does not support the video tag.

Official product video showcasing the Sony WF-1000X Wireless Headphones and their key features.