

Fujitsu A572/E

Fujitsu LIFEBOOK A572/E Laptop User Manual

Model: LIFEBOOK A572/E

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Fujitsu LIFEBOOK A572/E laptop. Please read this manual thoroughly before using your device to ensure proper function and safety.

2. SAFETY INFORMATION

- Do not expose the laptop to extreme temperatures, humidity, or direct sunlight.
- Avoid placing heavy objects on the laptop.
- Use only the provided AC adapter.
- Keep liquids away from the device.
- Do not attempt to disassemble or repair the laptop yourself. Refer to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Fujitsu LIFEBOOK A572/E Laptop
- AC Adapter
- Power Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your LIFEBOOK A572/E.



Figure 4.1: Rear view of the Fujitsu LIFEBOOK A572/E laptop with the lid open, showing the keyboard and ports on the sides.

4.1. Front View

The front of the laptop typically includes the display, webcam, and microphone.

4.2. Left Side

The left side features various ports for connectivity:

- USB 3.0 Ports (x2)
- PC Card Standard Slot (Type I/II)

4.3. Right Side

The right side includes additional ports and the optical drive:

- USB 2.0 Ports (x2)
- Super Multi Drive (DVD)

4.4. Rear Side

The rear side provides video output and audio connections:

- D-SUB 15-pin Port (VGA)
- HDMI Output Port
- Headphone/Line-out Jack
- Microphone/Line-in Jack

5. SETUP

5.1. Connecting the AC Adapter

1. Connect the AC adapter to the power input port on the laptop.
2. Plug the power cable into the AC adapter, then into a wall outlet.
3. The battery will begin charging automatically.

5.2. Initial Boot-up

1. Open the laptop lid.
2. Press the power button.
3. Follow the on-screen instructions to complete the Windows 10 Pro setup.

5.3. Connecting to Wi-Fi

1. Once Windows is set up, click the Wi-Fi icon in the taskbar.
2. Select your desired network and enter the password if prompted.

6. OPERATING THE LAPTOP

6.1. Power On/Off

- **Power On:** Press the power button.
- **Shut Down:** Click the Start button, then Power > Shut down.
- **Restart:** Click the Start button, then Power > Restart.
- **Sleep:** Close the lid or click the Start button, then Power > Sleep.

6.2. Using External Displays (HDMI/VGA)

1. Connect an external monitor or TV to the HDMI or D-SUB port.
2. Press **Windows key + P** to select display mode (Duplicate, Extend, Second screen only).

6.3. Optical Drive (DVD Super Multi Drive)

Insert a CD or DVD into the optical drive. The system will typically auto-detect the disc. If not, open "This PC" and double-click the optical drive icon.

7. MAINTENANCE

7.1. Cleaning

- Use a soft, lint-free cloth to clean the screen and exterior.
- Do not use harsh chemicals or abrasive cleaners.
- Ensure the laptop is powered off and unplugged before cleaning.

7.2. Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Laptop does not power on.	No power, discharged battery.	Ensure AC adapter is connected and working. Charge the battery.
Wi-Fi not connecting.	Incorrect password, router issue, Wi-Fi disabled.	Verify password, restart router, check Wi-Fi settings in Windows.
External display not working.	Incorrect cable, wrong display mode.	Check cable connections, press Windows key + P to cycle display modes.

9. SPECIFICATIONS

Feature	Detail
Model Name	LIFEBOOK A572/E
Operating System	Windows 10 Pro (64-bit)
CPU	Intel Core i5-3320M (2.60 GHz, up to 3.30 GHz with Turbo Boost)
CPU Cores/Threads	2 Cores / 4 Threads
RAM	8GB DDR3 SDRAM
Storage	250GB HDD (Serial ATA)
Optical Drive	Super Multi Drive (DVD)
Display	15.6-inch Widescreen (Non-glare, Max 1600x900)
Graphics	Intel HD Graphics 630 (Integrated)
LAN	1000BASE-T/100BASE-TX/10BASE-T compliant, Wakeup On LAN compatible
Wireless	Wi-Fi (801.11ac compatible)
USB Ports	2x USB 3.0, 2x USB 2.0
Video Output	1x D-SUB 15-pin, 1x HDMI
Audio Ports	1x Headphone/Line-out, 1x Microphone/Line-in
Expansion Slot	1x PC Card Standard (Type I/II)
Dimensions (WxDxH)	374 x 245 x 35.0-36.0 mm (excluding protrusions)
Weight	Approx. 2.4 kg

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Fujitsu support website. Keep your purchase receipt as proof of purchase for warranty claims.

Official Fujitsu Support: <https://www.fujitsu.com/global/support/>

