

Kid Trax KT1123KM

Kid Trax Disney Minnie Mouse 6V Toddler Quad Ride-On Instruction Manual

Model: KT1123KM | Brand: Kid Trax

1. IMPORTANT SAFETY INFORMATION

WARNING: Choking hazard; contains small parts. Adult supervision is required. This product may contain sharp points and edges during assembly. Not suitable for children less than 18 months.

- Always ensure the child is within the recommended age range of 18 to 30 months and does not exceed the maximum weight capacity of 45 lbs.
- Adult assembly is required.
- Always supervise children during operation of the ride-on toy.
- Ensure the battery is charged according to instructions to prevent damage or malfunction.

2. WHAT'S IN THE BOX

Before beginning assembly, please ensure all components are present:

- Minnie Mouse Quad Ride-On Body
- Steering Wheel Assembly
- Wheels (4)
- Axles and Fasteners
- 6V Rechargeable Battery
- Battery Charger
- Instruction Manual



Figure 2.1: Complete Kid Trax Disney Minnie Mouse 6V Toddler Quad Ride-On.

3. ASSEMBLY INSTRUCTIONS

The ride-on toy ships ready to be assembled. Adult assembly is required.

1. **Attach Wheels:** Securely attach the wheels to the axles using the provided fasteners. Ensure all wheels spin freely but are firmly attached.
2. **Install Steering Wheel:** Connect the steering wheel assembly to the main body of the quad. Ensure it clicks into place or is secured with the provided screw/nut.
3. **Connect Battery:** Locate the battery compartment, typically under the seat. Connect the battery terminals as indicated in the specific product diagram (usually color-coded).
4. **Secure Seat:** Place the seat back onto the quad and secure it. Some models feature a locking mechanism or screw to prevent accidental removal by children.



Figure 3.1: The assembled Minnie Mouse Quad Ride-On, suitable for ages 18-36 months and up to 44 lbs.

4. CHARGING THE BATTERY

The Kid Trax Disney Minnie Mouse Quad Ride-On includes a 6V rechargeable battery and a direct connect one-step charging system.

1. **Access Battery:** Lift the seat to access the battery compartment.
2. **Connect Charger:** Plug the charger into the designated charging port on the battery.
3. **Plug into Outlet:** Plug the charger into a standard wall outlet. The charger typically has an indicator light (e.g., red for charging, green for fully charged).
4. **Charging Time:** Allow sufficient time for a full charge before first use, typically 8-12 hours. Do not charge for more than 18 hours to prevent battery damage.
5. **Disconnect:** Once fully charged, disconnect the charger from the battery and the wall outlet.



Figure 4.1: The 6V rechargeable battery and Power Trax rubber traction strip tires are key features.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the charging process and battery compartment access for the 6V Minnie Mouse Quad.

5. OPERATING INSTRUCTIONS

This ride-on quad is designed for easy operation by toddlers.

1. **Power On:** Ensure the battery is connected and the seat is securely fastened.
2. **Start Movement:** The quad features easy push-button acceleration. Press the button located on the handlebar to move forward.
3. **Steering:** Use the handlebars to steer the quad left or right.
4. **Stopping:** Release the push button to stop the quad.
5. **Speed:** The maximum forward speed is 1.5 MPH, designed for safety and control for young children.



Figure 5.1: The easy push button on the handlebar allows for simple acceleration.



Figure 5.2: The quad operates at a safe maximum speed of 1.5 MPH.

6. MAINTENANCE

- **Cleaning:** Wipe the ride-on toy with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Care:** Always charge the battery after each use. If storing for an extended period, charge the battery once a month to maintain its lifespan.
- **Tire Inspection:** Regularly check the Power Trax rubber traction strip tires for wear and tear.
- **Storage:** Store the ride-on toy in a dry, cool place away from direct sunlight and moisture.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ride-on does not move.	Battery is not charged or not connected.	Ensure battery is fully charged and all connections are secure.

Problem	Possible Cause	Solution
Slow movement.	Low battery charge or exceeding weight limit.	Recharge battery. Ensure child's weight is within 45 lbs limit.
Unusual noises.	Loose parts or debris in wheels.	Inspect for loose components and clear any obstructions. Contact customer support if noise persists.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	27.95 x 16.93 x 18.9 inches
Item Weight	6.2 pounds
Item Model Number	KT1123KM
Recommended Age	18 months - 3 years
Maximum Weight Capacity	45 lbs
Battery	6V Rechargeable (included)
Max Speed	1.5 MPH
Manufacturer	Pacific Cycle, Inc.



Figure 8.1: Product dimensions for the Minnie Mouse Quad.

9. WARRANTY AND SUPPORT

This Kid Trax ride-on toy comes with a 1-year limited warranty on the product and a 6-month limited warranty on the battery.

For support or warranty claims, please refer to the contact information provided in the original product packaging or visit the official Kid Trax website.

Visit the [Kid Trax Store](#) for more information.