

[Manuals.plus](#) /

› [Teabloom](#) /

› Teabloom Stovetop & Microwave Safe Glass Teapot with Removable Loose Tea Glass Infuser – Includes 2 Blooming Teas – 2-in-1 Tea Kettle and Tea Maker – Tea Purist's Choice 40 OZ / 1.2 L (4-5 CUPS)

Teabloom CEL-POT-US

Teabloom Stovetop & Microwave Safe Glass Teapot

Model: CEL-POT-US

Brand: Teabloom

PRODUCT OVERVIEW

The Teabloom Celebration Glass Teapot is designed for an enhanced tea brewing experience. Crafted from high-quality borosilicate glass, it is safe for use on stovetops and in microwaves. This versatile teapot includes a removable glass infuser for loose leaf teas and is also ideal for blooming teas. Its clear design allows for full visibility of the tea as it steeps.



Image: The Teabloom Celebration Glass Teapot, showcasing its clear glass body, lid, handle, and spout. A removable glass infuser is visible, along with two blooming tea flowers and their packaging, highlighting the product's complete offering.



Image: A detailed diagram illustrating the key features of the Teabloom teapot, including its vented lid, premium borosilicate glass construction, comfortable grip, larger capacity (40 oz / 1200 ml), loose tea infuser, and stovetop safety. It also highlights that the product is lead-free.

For a detailed test report on lead-free certification, please visit: <https://bit.ly/3Uw8LEo>

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove all components from the packaging: the glass teapot, glass lid, and removable glass infuser.
2. **Initial Cleaning:** Before first use, wash all parts of the teapot with warm, soapy water. Rinse thoroughly with clean water and dry completely. The teapot is dishwasher safe for convenience.
3. **Assembly:** Place the removable glass infuser inside the teapot if you plan to brew loose leaf tea. Position the glass lid securely on top of the teapot.

OPERATING INSTRUCTIONS

The Teabloom teapot is designed for versatility, accommodating various tea types and heating methods.



TEA PREPARATION GUIDE



SCAN ME



TEABAG



1

BOIL WATER

Bring water (preferably filtered) just to a boil in your heatproof, stovetop safe Teabloom teapot.



2

2-5 MIN

Place teabags in teapot — 1 bag per cup of tea. Steep 2-5 minutes, pour into cup, and enjoy!



LOOSE TEA



1

ADD TEA

Place infuser into teapot. Add desired amount of tea — approx. 1 teaspoon per cup, or to taste.



2

2-5 MIN

Pour hot water over tea, cover pot with lid and steep 2-5 minutes. Pour tea into cup and enjoy!




BLOOMING TEA



1

3-4 INCHES

Heat filtered water in a separate kettle. Place tea ball in teapot. Pour in hot water to cover (3-4").



2

5-10 MIN

Steep until tea flower has opened fully, usually 5-10 minutes. Swirl tea to balance flavors. Enjoy!

Image: A visual guide detailing the preparation steps for teabags, loose tea, and blooming tea using the Teabloom teapot, including water boiling, steeping times, and water levels.

Brewing with Teabags:

1. **Boil Water:** Bring water (preferably filtered) to a boil in your heatproof, stovetop safe Teabloom teapot or a separate kettle.
2. **Steep:** Place teabags in the teapot. Pour hot water over the teabags. Steep for 2-5 minutes, depending on desired strength.
3. **Serve:** Remove teabags and pour into cups.

Brewing with Loose Leaf Tea:

1. **Prepare Infuser:** Place the removable glass infuser into the teapot. Add your desired amount of loose tea into the infuser (approximately 1 teaspoon per cup, or to taste).
2. **Add Hot Water:** Pour hot water over the tea leaves in the infuser. Cover the pot with the lid.
3. **Steep:** Steep for 2-5 minutes.
4. **Serve:** Remove the infuser and pour the tea into cups.

Brewing with Blooming Tea:

1. **Prepare Water:** Heat filtered water in a separate kettle.
2. **Place Blooming Tea:** Place one blooming tea ball into the bottom of the Teabloom teapot.
3. **Pour Water:** Pour hot water into the teapot, covering the blooming tea ball with approximately 3-4 inches of water.
4. **Bloom:** Allow the tea flower to unfurl. This typically takes 5-10 minutes.
5. **Serve:** Once fully opened, swirl the tea to balance flavors and pour into cups.

Heating Methods:

- **Stovetop Safe:** The Teabloom teapot is made of heat-resistant borosilicate glass and can be safely used on gas or electric stovetops to boil water. Use medium heat and monitor closely.
- **Microwave Safe:** The teapot can also be used in the microwave for heating water or reheating tea. Ensure no metal parts are present if using the infuser.



Image: A woman carefully pouring freshly brewed tea from the Teabloom glass teapot into a small glass cup, demonstrating the teapot's ease of use and elegant design.

MAINTENANCE AND CARE

- **Cleaning:** The Teabloom teapot, lid, and infuser are all dishwasher safe. For hand washing, use warm, soapy water and a soft sponge or cloth. Avoid abrasive cleaners or scourers that could scratch the glass.
- **Stain Removal:** Borosilicate glass is non-porous and resistant to stains. If tea stains occur, a solution of warm water and white vinegar or baking soda can help remove them.
- **Storage:** Store the teapot in a safe place where it is not prone to accidental knocks or falls.
- **Thermal Shock:** While borosilicate glass is highly resistant to thermal shock, avoid extreme temperature changes (e.g., pouring very cold water into a hot teapot, or vice versa) to prolong its

lifespan.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Glass becomes very hot on stovetop.	High heat setting or prolonged exposure to heat.	Use a medium heat setting when boiling water on the stovetop. Always use caution and a heat-resistant mitt when handling a hot teapot.
Minor drips from spout when pouring.	Overfilling the teapot or pouring too slowly.	Avoid filling the teapot completely to the brim. Pour with a steady, confident motion.
Tea leaves escape infuser.	Very fine tea particles or improper placement of infuser.	The infuser has laser-cut slits designed to capture most leaves. Some very fine particles may pass through, which is normal. Ensure the infuser is seated correctly.

SPECIFICATIONS

Brand: Teabloom
Model Name: Celebration Teapot
Model Number: CEL-POT-US
Color: Clear
Capacity: 40 OZ / 1.2 L (4-5 CUPS)
Product Dimensions: 6"D x 6"W x 6"H
Item Weight: 1.4 Pounds
Material: Borosilicate Glass
Dishwasher Safe: Yes
Stovetop Safe: Yes
Microwave Safe: Yes
Country of Origin: China
UPC: 810019872334, 688907971694, 019985759537

WARRANTY AND SUPPORT

Teabloom stands behind the quality of its products. The Teabloom Celebration Glass Teapot comes with a **full one-year warranty** from the date of purchase.

For warranty claims, product support, or any inquiries, please contact Teabloom customer service directly. You can find more information and contact details on the official Teabloom brand store:

Visit Teabloom Store on
Amazon



SUPPLIER OF CHOICE FOR 5-STAR HOTELS WORLDWIDE



EXPLORE THE WORLD'S LARGEST SELECTION OF GLASS TEAPOTS AT TEABLOOM

Image: An image highlighting Teabloom's status as a supplier for 5-star hotels worldwide, along with a "1 Year Warranty" badge and a "Worry-Free Guarantee" indicating a refund if not 100% satisfied.