Hobbywing FLYFUN-60A-6S-V5

Hobbywing FLYFUN-60A-6S-V5 Electronic Speed Controller Instruction Manual

Model: FLYFUN-60A-6S-V5 (HWI30214101)

1. Introduction

This manual provides detailed instructions for the proper installation, operation, and maintenance of your Hobbywing FLYFUN-60A-6S-V5 Electronic Speed Controller (ESC). Please read this manual thoroughly before using the product to ensure safe and efficient operation.



An image showing the Hobbywing FLYFUN-60A-6S-V5 Electronic Speed Controller. The ESC unit is black with a finned heat sink on top, and has various colored wires extending from both ends for power, motor, and signal connections. A blue label with '60A' is visible on the side.

2. Safety Instructions

Always observe the following safety precautions to prevent personal injury or damage to the product and associated equipment:

- **Read the Manual:** Familiarize yourself with all features and functions before operation.
- **Proper Connections:** Ensure all connections are correct and secure. Incorrect polarity can cause severe damage.
- **Insulation:** Insulate all exposed wires and connectors to prevent short circuits.
- **Battery Safety:** Use appropriate batteries and chargers. Never overcharge or discharge batteries.
- **Ventilation:** Ensure adequate airflow around the ESC to prevent overheating.
- **Water and Moisture:** Keep the ESC away from water and moisture unless it is specifically rated as waterproof.
- **Children:** This product is not a toy. Keep out of reach of children. Recommended age for use is 16 years and above.
- **Disposal:** Dispose of electronic components responsibly according to local regulations.

3. Product Features

The Hobbywing FLYFUN-60A-6S-V5 ESC incorporates advanced technology for optimal performance and reliability:

- **Programmable ESC:** Can be programmed via the transmitter or an optional LED program card (sold separately).
- **DEO Technology (Driving Efficiency Optimization):** This technology provides:
  - Faster and smoother throttle response.
  - Improved stability and flexibility during flight.
  - Higher driving efficiency, leading to longer flight times.
  - Lower ESC operating temperature, enhancing reliability.
- **High-Power BEC:** Features a switch-mode BEC with a continuous current of 8A and a peak current of 20A. The output voltage is adjustable among 5.2V, 6.0V, and 7.4V, supporting multiple electronic devices such as servos, flight controllers, and on-board lights.
- **Multiple Protections:** Comprehensive protection features ensure the longevity and safe operation of the ESC, including:
  - Start-up protection.
  - Over-current protection.
  - ESC thermal protection.
  - Capacitor thermal protection.
  - Overload protection.
  - Throttle signal loss (fail-safe) protection.
  - Abnormal input voltage protection.
- **Soft Start-ups & Reverse Brake:** Provides smooth motor initiation and controlled braking capabilities.

4. Specifications

Feature	Specification
Model Number	HWI30214101
Product Dimensions	4.5 x 0.13 x 7.63 inches

Feature	Specification
Item Weight	2.59 ounces
Manufacturer Recommended Age	16 years and up
BEC Output	8A Continuous / 20A Peak, adjustable 5.2V / 6.0V / 7.4V
Input Voltage	3-6S LiPo

Note: Input voltage (3-6S LiPo) is inferred from the product title "6S-V5" and general ESC specifications for this class. Always refer to the official product packaging or manufacturer's website for the most precise and up-to-date specifications.

5. What's in the Box

The product package typically includes:

- Hobbywing FLYFUN-60A-6S-V5 Electronic Speed Controller (ESC)

Note: Additional accessories such as an LED program card are sold separately.

6. Setup and Installation

Follow these general steps for installing your ESC. Specific wiring diagrams may vary based on your aircraft model. Always consult your aircraft's manual for detailed connection instructions.

1. **Mounting the ESC:** Securely mount the ESC in a location with adequate airflow to prevent overheating. Use double-sided tape or zip ties if necessary.
2. **Motor Connection:** Connect the three motor wires from the ESC to the three motor phase wires. The order may affect motor rotation direction; this can be adjusted later if needed.
3. **Battery Connection:** Connect the ESC's power input wires (typically red for positive, black for negative) to your battery connector. Ensure correct polarity.
4. **Receiver/Flight Controller Connection:** Connect the ESC's signal cable (usually a three-wire servo connector) to the throttle channel of your receiver or flight controller.
5. **Initial Calibration:** Perform a throttle range calibration with your transmitter to ensure the ESC recognizes the full throttle range. Refer to your transmitter's manual for this procedure.

7. Operating Instructions

Once the ESC is properly installed and calibrated, follow these steps for operation:

1. **Power On:** Ensure your transmitter is turned on first, then connect the battery to the ESC.
2. **Initialization:** The ESC will emit a series of beeps indicating cell count and readiness. Wait for the initialization sequence to complete.
3. **Throttle Control:** Slowly advance the throttle stick on your transmitter to control motor speed.
4. **Power Off:** Disconnect the battery from the ESC first, then turn off your transmitter.

Always perform a range check and functional test in a safe environment before flight.

8. Programming the ESC

The Hobbywing FLYFUN-60A-6S-V5 ESC offers various programmable parameters to fine-tune its performance. Programming can be done using:

- **Transmitter:** Basic parameters can often be adjusted through specific throttle stick movements. Refer to the detailed programming guide (usually available on the Hobbywing website) for the exact sequence.
- **LED Program Card:** For easier and more comprehensive programming, an optional Hobbywing LED Program Card (sold separately) is recommended. Connect the program card to the ESC's signal cable (after disconnecting from the receiver) and follow the instructions provided with the program card.

Common programmable parameters include throttle curve, timing, brake type, BEC voltage, and various protection thresholds.

9. Maintenance

Proper maintenance ensures the longevity and reliable operation of your ESC:

- **Regular Inspection:** Periodically check all wires and connectors for signs of wear, damage, or corrosion.
- **Cleaning:** Keep the ESC free from dust, dirt, and debris. Use a soft brush or compressed air for cleaning. Avoid using liquids.
- **Heat Management:** Ensure the heat sink is clear of obstructions and that the ESC has adequate ventilation during operation.
- **Storage:** Store the ESC in a cool, dry place away from direct sunlight and extreme temperatures.

10. Troubleshooting

If you encounter issues with your ESC, consider the following common problems and solutions:

Problem	Possible Cause	Solution
Motor does not start or stutters.	Incorrect motor wiring, throttle calibration issue, low battery voltage, motor damage.	Check motor connections, recalibrate throttle range, check battery charge, inspect motor.
ESC overheats.	Insufficient airflow, motor/propeller too large, incorrect timing settings.	Improve ventilation, use appropriate motor/prop, adjust motor timing.
No response from ESC.	No power, signal cable disconnected, damaged ESC.	Check battery connection, ensure signal cable is secure, contact support if damaged.
Motor runs in wrong direction.	Incorrect motor phase wire connection.	Swap any two of the three motor wires between the ESC and motor.

If problems persist after attempting these solutions, please contact Hobbywing customer support.

11. Legal Disclaimer

In regards to product descriptions, product labels, individual product facts and various other informational content found throughout our website and included pages, we try our best to provide current and accurate information. If typographical errors appear on or within our website, we sincerely apologize and appreciate all help in identifying such errors so as to correct them as quickly as possible. Nonetheless,

HobbywingDirect.com cannot be held responsible for typographical errors and assumes no responsibility for said errors. For more information please visit https://www.hobbywingdirect.com/pages/return-policy

© 2023 Hobbywing. All rights reserved. This manual is subject to change without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question