FEICE FM201

FEICE FM201 Bauhaus Automatic Watch User Manual

Model: FM201

1. Product Overview

The FEICE FM201 is a Bauhaus-inspired automatic mechanical watch designed for unisex wear. It features a minimalist dial, sapphire crystal, and a reliable automatic movement. This manual provides essential information for setting up, operating, and maintaining your watch.



Figure 1: FEICE FM201 Bauhaus Automatic Watch, front view with black leather strap.

Key Features:

- **Automatic Movement:** Powered by wrist motion, eliminating the need for batteries.
- **Sapphire Crystal:** Highly scratch-resistant for enhanced durability and clarity.
- **Water Resistance:** 3ATM (30 meters), suitable for splashes and rain, but not for swimming or diving.
- **Minimalist Bauhaus Design:** Clean white dial with a sub-dial for seconds and a date window.
- **Transparent Case Back:** Allows visibility of the intricate mechanical movement.

Your browser does not support the video tag.

Video 1: Overview of the FEICE FM201 Bauhaus Automatic Watch, showcasing its design and features.

2. Setup and Initial Use

2.1 Initial Winding

For the first use, or if the watch has stopped due to lack of movement, it needs to be manually wound. Rotate the

crown clockwise approximately 20-30 times until the second hand begins to move consistently. This provides the initial power reserve.




Figure 2: Watch crown positions for manual winding, date setting, and time setting.

2.2 Setting Time and Date

1. **Manual Winding (Position 0):** With the crown fully pushed in, rotate it clockwise to manually wind the watch.
2. **Setting Date (Position 1):** Gently pull the crown out to the first click. Rotate the crown to adjust the date. To prevent damage to the movement, avoid adjusting the date when the hour hand is between 6:00 PM and 9:00 PM.
3. **Setting Time (Position 2):** Pull the crown out to the second click. Rotate the crown to set the hour and minute hands. Once set, push the crown back in to Position 0.

Your browser does not support the video tag.

Video 2: Instructions for winding and setting the time and date on a FEICE automatic watch.

3. Operating Your Watch

3.1 Automatic Movement

The FEICE FM201 is an automatic watch, meaning it is powered by the natural motion of your wrist. When worn regularly (approximately 8-10 hours a day), the watch will self-wind and maintain its power reserve. If the watch is not worn for an extended period, it may stop and require manual winding as described in Section 2.1.



Figure 3: Transparent case back revealing the automatic mechanical movement.

3.2 Using the Deployment Clasp

The watch features a deployment clasp for secure and comfortable wear. To open the clasp, press the two release buttons located on either side of the buckle. To adjust the strap length, open the buckle to reveal the pin. Insert the pin into the appropriate hole on the strap for your wrist size, then close the clasp securely.



Figure 4: Detail of the deployment clasp mechanism.

4. Care and Maintenance

4.1 Water Resistance

Your FEICE FM201 watch is water-resistant to 3ATM (30 meters). This means it can withstand splashes of water or brief exposure to rain. It is **not** suitable for bathing, showering, swimming, diving, or any activities involving prolonged water immersion or high-pressure water exposure. Ensure the crown is fully pushed in before any contact with water.

4.2 Sapphire Crystal

The watch features a sapphire crystal, known for its exceptional scratch resistance. While highly durable, it is not entirely impervious to damage. Avoid extreme impacts or contact with abrasive materials.

4.3 General Care

- Clean the watch regularly with a soft, dry cloth to remove dust and smudges.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- If the leather strap becomes wet, allow it to air dry naturally, away from direct heat.

5. Troubleshooting

Watch Stops or Runs Slowly

As an automatic watch, the FM201 relies on kinetic energy from your movement. If the watch stops or runs inaccurately, it likely needs more power. Manually wind the watch by rotating the crown clockwise (Position 0) about 20-30 times. Ensure you wear the watch for at least 8-10 hours daily for optimal performance.

6. Specifications



Figure 5: Key dimensions of the FEICE FM201 watch.

Feature	Detail
Model	FM201
Movement Type	Automatic Mechanical (Seagull)
Case Material	Stainless Steel
Case Diameter	38 mm
Case Thickness	10 mm
Crystal	Synthetic Sapphire
Band Material	Leather
Band Width	20 mm
Water Resistance	3 ATM (30 Meters)

Feature	Detail
Display Type	Analog
Additional Features	Independent Second Hand, Date Display
Item Weight	0.2 Kilograms (7.05 ounces)

7. Warranty and Support

For any questions, concerns, or support regarding your FEICE FM201 watch, please contact FEICE customer service. Refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question