

[Manuals.plus](#) /

› [SEAGO](#) /

› SEAGO Kids Electric Toothbrush User Manual

SEAGO SG977

SEAGO Kids Electric Toothbrush User Manual

Model: SG-977 | Brand: SEAGO

INTRODUCTION

Thank you for choosing the SEAGO Kids Electric Toothbrush. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new electric toothbrush. Designed to make brushing fun and effective for children aged 4-12, it features a 2-minute timer, rainbow LED light, and soft bristles for optimal oral hygiene.



Figure 1: SEAGO Kids Electric Toothbrush, showcasing the main unit, packaging, and included replacement brush heads.

SAFETY INFORMATION

Please read and understand all safety instructions before using the product. Failure to do so may result in injury or damage.

- **Do not submerge the toothbrush in water** to avoid electrical hazards. While the toothbrush is IPX7 waterproof, it is designed for rinsing, not full submersion.
- **Keep out of reach of children under 3 years old** to prevent choking hazard from small parts.
- Ensure the battery compartment is securely closed before use to maintain water resistance.
- Do not attempt to disassemble or repair the toothbrush yourself. Contact customer support for assistance.
- If the toothbrush appears damaged, discontinue use immediately.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Electric Toothbrush Handle (Pink)
- 3 x Replacement Brush Heads
- 1 x Protective Bristle Cover
- 1 x Instruction Manual

Inside The Package



1 dustcover



*3 extra replacement
brush heads*



*1 Instruction
Manual*



*1 toothbrush
handle*

Figure 2: All components included in the SEAGO Kids Electric Toothbrush package: handle, three replacement heads, protective cover, and manual.

SETUP

1. Battery Installation

1. Twist the bottom cap of the toothbrush handle counter-clockwise to open the battery compartment.
2. Insert one (1) AAA battery (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators.
3. Twist the bottom cap clockwise to securely close the battery compartment. Ensure it is tightly sealed to maintain IPX7 waterproof rating.

Product Function Introduction



Figure 3: Product function introduction, highlighting the AAA battery compartment at the bottom of the handle.

2. Attaching the Brush Head

1. Align the replacement brush head with the metal shaft on the toothbrush handle.
2. Push the brush head down firmly until it clicks into place.
3. To remove, simply pull the brush head upwards from the handle.

Power On/Off and Mode Selection

The toothbrush features a single button for power and mode selection. Press the button repeatedly to cycle through the modes:

- **First Press:** Activates the toothbrush with vibration and a white LED light. This light can be used to observe the child's dental health.
- **Second Press:** Activates the toothbrush with vibration and a rainbow LED light. This mode is designed to make brushing fun.
- **Third Press:** Activates the toothbrush with vibration only (no light).
- **Fourth Press:** Turns the toothbrush off.




Figure 4: Illustration of the four operating modes: white light, rainbow light, vibration only, and off.

2-Minute Smart Timer & 30-Second Interval Pause

The toothbrush is equipped with a built-in 2-minute timer to ensure children brush for the dentist-recommended duration. It also features a 30-second interval pause, which gently reminds the child to move to a different quadrant of their mouth, ensuring thorough cleaning.

Colorful LED Makes Brushing Fun



Rainbow
light



Figure 5: A child enjoying brushing with the colorful LED light feature of the toothbrush.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the SEAGO Kids Electric Toothbrush with its timer and colorful LED lights, highlighting its features for making brushing fun and effective.

Cleaning the Toothbrush

- After each use, rinse the brush head thoroughly under running water.
- Wipe the toothbrush handle with a damp cloth. Do not use abrasive cleaners or harsh chemicals.
- The toothbrush is IPX7 waterproof, meaning it can withstand splashes and brief immersion. However, avoid prolonged submersion.



Figure 6: The toothbrush is IPX7 waterproof and can be safely rinsed under running water.

Replacing Brush Heads

It is recommended to replace the brush head every 3 months, or sooner if the bristles become frayed or if the child has been sick. The color-fade bristles also serve as a visual reminder to change the brush head.

- Remove the old brush head by pulling it upwards from the handle.

- Attach a new replacement brush head as described in the "Setup" section.

100% MORE PLAQUE REMOVAL*



24000 strokes
sonic vibrations



Color-fade
bristle



End-round
bristle



Wave shape
bristles



BPA-free



*vs. a regular manual toothbrush
*From seago R&D Data

Figure 7: The soft, end-round bristles are designed for effective plaque removal while being gentle on gums.

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is dead or incorrectly inserted.	Check battery orientation or replace with a new AAA battery.
LED light is dim or not working.	Low battery power.	Replace the AAA battery.
Brush head feels loose or falls off.	Brush head not properly attached or worn out.	Ensure brush head is pushed firmly onto the shaft. Replace if worn.
Reduced vibration intensity.	Low battery power.	Replace the AAA battery.

SPECIFICATIONS

Feature	Detail
Brand	SEAGO
Model Number	SG977
Power Source	1 x AAA Battery (not included)
Vibrations per Minute	Up to 24,000
Special Features	2-Minute Timer, 30-Second Interval Pause, Rainbow LED Light, White LED Light
Waterproof Rating	IPX7
Bristle Firmness	Extra Soft
Product Dimensions	0.75 x 0.73 x 7.4 inches
Item Weight	0.96 ounces

WARRANTY AND SUPPORT

SEAGO offers a **six-month quality guarantee** for this product. If there is any quality problem with the product within six months of purchase, please contact SEAGO customer support for replacement or assistance.

For further assistance, questions, or to report any issues, please contact SEAGO customer support through the retailer's platform or visit the official SEAGO website.

Manufacturer: seago electric co.,ltd

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question