

Linq S600

Linq S600 Wireless Bluetooth Gamepad User Manual

Model: S600

1. INTRODUCTION

Thank you for purchasing the Linq S600 Wireless Bluetooth Gamepad. This device is designed to enhance your gaming experience on compatible Android and iOS devices, as well as PCs and tablets. This manual provides detailed instructions on how to set up, operate, and maintain your gamepad.

2. PRODUCT OVERVIEW

The Linq S600 Gamepad features an ergonomic design with anti-slip grips for comfortable extended play. It includes precise mini-sticks, a D-pad, and multiple function buttons for comprehensive control.



Figure 2.1: Front view of the Linq S600 Wireless Bluetooth Gamepad, showing the dual analog sticks, D-pad, action buttons (A, B, X, Y), Home, Select, and Start buttons, and red accents.



Figure 2.2: Back view of the Linq S600 Wireless Bluetooth Gamepad, displaying the battery compartment or charging port area and regulatory markings.



Figure 2.3: Side view of the Linq S600 Wireless Bluetooth Gamepad, highlighting the shoulder buttons and triggers, as well as the ergonomic grip design.

2.1. Package Contents

- Linq S600 Wireless Bluetooth Gamepad
- USB Charging Cable
- User Manual (this document)
- Smartphone Holder (optional, if included)

2.2. Button Layout

The gamepad features the following controls:

- **Dual Analog Sticks:** For precise movement and camera control.
- **D-Pad:** For directional input.
- **Action Buttons (A, B, X, Y):** Standard gaming input buttons.
- **Shoulder Buttons (L1, R1) and Triggers (L2, R2):** For additional in-game actions.
- **Function Buttons:** Select, Start, Home, Back.
- **Synchronization Button:** For pairing the device.

3. SETUP

3.1. Charging the Gamepad

Before first use, fully charge the gamepad. Connect the supplied USB charging cable to the gamepad's charging port and to a USB power source (e.g., computer, USB wall adapter). The charging indicator light will illuminate during charging and turn off or change color when fully charged. A full charge typically takes approximately 3 hours.

3.2. Pairing with Your Device

The Linq S600 uses Bluetooth wireless technology for connection.

1. Ensure the gamepad is sufficiently charged.
2. Turn on the gamepad by pressing the **Home** button.
3. Activate Bluetooth on your Android, iOS device, PC, or tablet.
4. On your device, search for available Bluetooth devices. The gamepad should appear as "S600" or "Gamepad".
5. Select the gamepad from the list to pair. Once paired, the indicator light on the gamepad will confirm the connection.

Note for iOS Users: Full functionality for iOS devices may require a jailbroken device.

3.3. Attaching the Smartphone Holder

If your package includes a smartphone holder, you can attach it to the gamepad to secure your phone for mobile gaming.



Figure 3.1: Linq S600 Gamepad with the smartphone holder attached, ready to hold a mobile device.



Figure 3.2: Close-up view of the detachable smartphone holder, showing its adjustable mechanism.

1. Locate the slot on the top center of the gamepad.
2. Align the smartphone holder with the slot and gently push it in until it clicks securely into place.
3. Adjust the holder to fit your smartphone.

4. OPERATING THE GAMEPAD

4.1. Power On/Off

- **To Power On:** Press and hold the **Home** button for a few seconds until the indicator light turns on.
- **To Power Off:** Press and hold the **Home** button for a few seconds until the indicator light turns off. The gamepad will also automatically power off after a period of inactivity to conserve battery.

4.2. Game Compatibility

The Linq S600 Gamepad is compatible with over 200 games across various platforms. For optimal performance, ensure your game supports external controllers. Some games may require specific controller settings within the game menu.

4.3. Using Function Buttons

The **Select**, **Start**, **Home**, and **Back** buttons provide essential navigation and in-game functions. Their specific actions may vary depending on the operating system and the game being played.

5. MAINTENANCE

5.1. Cleaning

To clean your gamepad, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the surface and internal components.

5.2. Battery Care

- Avoid exposing the gamepad to extreme temperatures.
- Do not attempt to replace the internal battery yourself. Contact customer support if battery issues arise.
- Charge the gamepad regularly, even if not in frequent use, to maintain battery health.

6. TROUBLESHOOTING

6.1. Gamepad Does Not Turn On

- Ensure the gamepad is fully charged. Connect it to a power source and wait for the charging indicator.
- Press and hold the **Home** button for a longer duration (5-10 seconds).

6.2. Unable to Pair with Device

- Make sure Bluetooth is enabled on your device.
- Ensure the gamepad is in pairing mode (usually indicated by a flashing light after pressing the sync button or Home button).
- Move the gamepad closer to your device.
- Turn off and on your device's Bluetooth, then try pairing again.
- If previously paired, try "forgetting" the device in your Bluetooth settings and re-pairing.

6.3. Buttons or Sticks Are Unresponsive

- Ensure the gamepad is properly connected and charged.
- Restart the gamepad and your device.
- Test the gamepad with a different game or application to determine if the issue is game-specific.
- For iOS devices, confirm if jailbreak is required for the specific game or functionality.

7. SPECIFICATIONS

Model	S600
Device Type	Gamepad
Supported Platforms	Android, PC, Tablet, iOS (Jailbreak may be required for full iOS functionality)
Control Technology	Analogue / Digital

Connection Technology	Wireless Bluetooth
Battery Capacity	600 mAh rechargeable battery
Charging Time	Approximately 3 hours
Function Keys	Back, Home, Select, Start, A, B, X, Y, L1, R1, L2, R2, D-Pad, Dual Analog Sticks
Manufacturer Reference	6970334020606
Country of Origin	China

8. WARRANTY AND SUPPORT

8.1. Warranty Information


For information regarding product warranty and return policies, please refer to the purchase platform's specific guidelines or contact the seller directly. Generally, products may be returned within 30 days of receipt if you change your mind. For defective or damaged products, specific return policies apply.

8.2. Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact the seller or manufacturer's customer support. Please have your product model (S600) and purchase details ready when contacting support.

Related Documents - S600

	Linq: Build Your Digital Profile Page and Activate Your Card Learn how to build your Linq digital profile page and activate your Linq card using simple steps. Includes FCC compliance information.
	Linq Fully Custom Card - Product Specifications Detailed specifications for the Linq Fully Custom Card, including dimensions and customization options.
	LINQ 3-in-1 Multiport Hub - Specifications, Manual & Warnings Comprehensive guide for the LINQ 3-in-1 Multiport Hub, detailing its specifications, features like 4K HDMI, USB-C PD 140W, USB-A 3.2, and providing essential safety warnings, recycling information, and EU Declaration of Conformity from Telco Accessories BV.



lang:fr score:17 filesize: 206.21 K page count: 4 document date: 2021-03-26

