

[Manuals.plus](#) /

› [ONN](#) /

› ONN ONA17AV013 DisplayPort to HDMI Adapter Instruction Manual

ONN ONA17AV013

ONN ONA17AV013 DisplayPort to HDMI Adapter Instruction Manual

Model: ONA17AV013

INTRODUCTION

This instruction manual provides detailed information on the setup, operation, and maintenance of your ONN ONA17AV013 DisplayPort to HDMI Adapter. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.

PRODUCT OVERVIEW

The ONN ONA17AV013 is a DisplayPort to HDMI adapter designed to connect a DisplayPort-equipped source device, such as a laptop or desktop computer, to an HDMI-enabled display device, such as a monitor or projector. It facilitates high-definition video and audio transmission, allowing you to extend or mirror your display.



Image of the ONN DisplayPort to HDMI Adapter, showing the DisplayPort connector on one end, the HDMI port on the other, and the cable connecting them. The adapter is black with a white ONN label on the cable.

FEATURES

- Connects DisplayPort source to HDMI display.
- Supports video and audio transmission.
- Compact and portable design.
- Durable construction for reliable performance.

PACKAGE CONTENTS

- 1 x ONN ONA17AV013 DisplayPort to HDMI Adapter

SETUP

1. **Identify Ports:** Locate the DisplayPort output on your source device (e.g., laptop, desktop) and an available HDMI input on your display device (e.g., monitor, projector, TV).
2. **Connect DisplayPort:** Insert the DisplayPort connector of the ONN adapter into the DisplayPort output on your source device. Ensure it is firmly seated.
3. **Connect HDMI Cable:** Connect one end of a standard HDMI cable (not included) into the HDMI port of the ONN adapter.
4. **Connect to Display:** Connect the other end of the HDMI cable into the HDMI input on your display device.
5. **Power On Devices:** Turn on your source device and your display device.
6. **Select Input:** On your display device, select the correct HDMI input source using its remote control or on-screen menu.
7. **Configure Display Settings (if necessary):** Your operating system should automatically detect the new display. If not, go to your computer's display settings (e.g., Windows Display Settings, macOS System Preferences > Displays)

to configure resolution, orientation, and display mode (extend, duplicate, or second screen only).

Note: This adapter is unidirectional, converting DisplayPort to HDMI. It does not convert HDMI to DisplayPort.

OPERATING INSTRUCTIONS

Once the adapter is connected as described in the "Setup" section, the DisplayPort signal from your source device will be converted and transmitted to your HDMI display. No additional drivers or software are typically required for basic operation.

- **Audio Transmission:** Ensure your computer's audio output is set to the HDMI device if you wish to transmit audio through the adapter to your HDMI display. This setting is usually found in your operating system's sound or audio settings.
- **Display Modes:**
 - **Duplicate (Mirror) Mode:** Shows the same content on both your primary and external display.
 - **Extend Mode:** Extends your desktop across both displays, allowing for more workspace.
 - **Second Screen Only:** Displays content only on the external HDMI display, turning off the primary screen.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid bending or twisting the cable excessively. Do not pull on the cable to disconnect; always grasp the connector ends.
- **Protection:** Keep the adapter away from water, moisture, and corrosive substances.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No display on HDMI monitor.	Loose connection. Incorrect input selected on monitor. Display settings not configured. Faulty cables or adapter.	Ensure all connections (DisplayPort, HDMI) are secure. Select the correct HDMI input on your monitor/TV. Check your computer's display settings (resolution, display mode). Try a different HDMI cable. Test the adapter with another DisplayPort source or HDMI display if possible.
No audio from HDMI display.	Audio output not set to HDMI. DisplayPort source does not support audio.	Go to your computer's sound settings and set the HDMI display as the default audio output device. Verify that your source device's DisplayPort supports audio transmission.
Flickering or unstable display.	Loose connection. Resolution/refresh rate incompatibility.	Check all cable connections. Lower the resolution or refresh rate in your computer's display settings.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	4 x 1 x 6 inches
Item Weight	2.4 ounces
ASIN	B074P5C2KD
Date First Available	August 9, 2017
Manufacturer	ONN
Compatible Devices	Desktop, Laptop, Monitor
Connector Type	HDMI (Output from adapter)
Color	Black

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation provided with your purchase or visit the official ONN website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact ONN customer service through their official channels. Please have your product model number (ONA17AV013) ready when contacting support.

