

[Manuals.plus](#) /

› [Alpine Hearing Protection](#) /

› Alpine PartyPlug Concert Ear Plugs User Manual

Alpine Hearing Protection PartyPlug (Transparent Multisize)

Alpine PartyPlug Concert Ear Plugs User Manual

MODEL: TRANSPARENT (MULTISIZE)

Introduction


The Alpine PartyPlug Concert Ear Plugs are designed to protect your hearing in loud environments such as music festivals, raves, and live events, while maintaining clear sound quality and enabling conversation. They feature a special music filter technology that reduces harmful noise by 19dB. This manual provides essential information on how to properly use, maintain, and care for your earplugs to ensure optimal performance and comfort.

Setup and Fit

For effective hearing protection and comfort, selecting the correct ear tip size and proper insertion are crucial. Your Alpine PartyPlug earplugs come with three different tip sizes (S, M, L) to ensure a secure and comfortable fit for various ear canal sizes.

Experience music, stay protected

Special music filter
Enjoy the music,
hear your friends



Certified hearing
protection
SNR 19dB

Alpine

Trusted by millions worldwide since '94

Image: Alpine PartyPlug earplugs showing the three included tip sizes (S, M, L).



Image: Step 1 - Choosing the right earplug size based on comfort and seal.

1. **Choose the Right Size:** The medium (M) size typically comes pre-fitted on the filters. If they feel too tight or

cause discomfort, switch to the small (S) size. If they feel too loose or do not provide adequate noise reduction, try the large (L) size. The goal is a snug fit that creates a good seal without pressure.

2. **Insert the Earplugs:** Hold each earplug by the filter between your thumb and index finger. Gently insert the earplug into your ear canal with a slight twisting motion until it feels snug and comfortable. Do not force the earplug.
3. **Check the Fit:** Once inserted, the earplugs should feel comfortable, create a good seal in your ear canal, and not stick out too far from your ear. You should notice a significant reduction in ambient noise while still being able to hear conversations and music clearly.



Image: Proper insertion and fit of the Alpine PartyPlug earplug.

Operating Instructions

Alpine PartyPlug earplugs are designed for optimal sound experience while protecting your hearing. The integrated music filters ensure that sound quality remains high, allowing you to enjoy music and conversations without distortion, even in loud environments.

- **Noise Reduction:** The earplugs reduce harmful noise levels by 19dB, preventing hearing damage from prolonged exposure to loud sounds.
- **Clear Sound Quality:** Unlike traditional foam earplugs, the special acoustic filters allow you to hear music and speech clearly, maintaining the full musical experience and enabling easy communication.
- **Conversation:** You can comfortably hold conversations without needing to remove your earplugs, as the filters are designed to let speech frequencies pass through more naturally.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and benefits of the new and improved Alpine PartyPlug earplugs, including their noise reduction capabilities and comfortable fit.

Maintenance and Care

To ensure the longevity and hygiene of your Alpine PartyPlug earplugs, regular cleaning and proper storage are recommended.

- **Cleaning:** After each use, gently clean the earplugs with lukewarm water and a mild soap. Rinse thoroughly and allow them to air dry completely before storing. Avoid using harsh chemicals or abrasive materials, as these can damage the earplugs or filters.
- **Storage:** Store your earplugs in the provided compact carry case when not in use. This protects them from dirt, dust, and damage, and keeps them easily accessible. The case is designed to fit on a keychain or in a pocket.

Always within reach

Never lose your earplugs again



Keychain
case



Compact
design




Image: Alpine PartyPlug earplugs neatly stored in their compact carry case.

Troubleshooting

If you encounter any issues with your Alpine PartyPlug earplugs, consider the following common solutions:

- **Poor Noise Reduction or Loose Fit:** If the earplugs feel loose, fall out easily, or do not provide sufficient noise reduction, try using a larger tip size (L). Ensure the earplug is inserted deeply enough to create a proper seal in the ear canal.
- **Muffled Sound or Discomfort:** If sound seems overly muffled, unclear, or if the earplugs cause discomfort, they might be too large or not inserted correctly. Try a smaller tip size (S) or re-insert them with a gentle twisting motion to ensure a comfortable, yet snug, fit.
- **Difficulty Removing Earplugs:** If the earplugs are difficult to remove, gently twist them while pulling outwards. Avoid pulling abruptly. The new design features a wider grip for easier handling.
- **Ear Irritation:** If you experience ear irritation, ensure the earplugs are clean before each use. If irritation persists, discontinue use and consult a healthcare professional.

Specifications

Feature	Detail
Product Dimensions	4.88 x 3.19 x 0.71 inches
Item Weight	0.63 ounces
Model Number	Transparant
Material	Thermoplastic Rubber
Noise Reduction Rating (NRR)	19dB
Included Tip Sizes	Small (S), Medium (M), Large (L)
Included Accessories	Compact carry case

Warranty and Support

For any questions, concerns, or support regarding your Alpine PartyPlug Concert Ear Plugs, please contact Alpine Hearing Protection directly. While specific warranty details are not provided in this manual, Alpine is committed to customer satisfaction. You can find more information and contact details by visiting the official Alpine store on Amazon: [Alpine Hearing Protection Store](#).

© 2025 Alpine Hearing Protection. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

