JBL JBLPULSE3WHTAM

JBL Pulse 3 Wireless Bluetooth Waterproof Speaker

Model: JBLPULSE3WHTAM | Brand: JBL

Product Overview

The JBL Pulse 3 is a portable, waterproof Bluetooth speaker designed to enhance your audio experience with a unique 360-degree sound and an integrated 360-degree light show. It features a built-in rechargeable battery providing up to 12 hours of playtime and an IPX7 waterproof rating, making it suitable for use near water, such as at the beach or by the pool. The JBL Connect+ technology allows for wireless linking with over 100 other JBL Connect+ enabled speakers for an amplified sound experience. Additionally, the Pulse 3 includes a noise and echo-cancelling speakerphone for clear calls and offers customizable light show experiences via the JBL Connect app. You can also synchronize light shows with other Pulse 3 devices by simply shaking the speaker.



The JBL Pulse 3 speaker, showcasing its dynamic 360-degree light show with warm, glowing colors. The speaker features a white mesh base and a translucent upper cylinder that illuminates.

What's Included

- JBL Pulse 3 Speaker
- Micro USB Cable
- Quick Start Guide
- Power Adaptor



This image displays the JBL Pulse 3 speaker alongside its included orange micro USB charging cable, highlighting the speaker's

illuminated upper section with a gradient of pink and orange light.

Setup Guide

1. Charging the Battery

Before first use, fully charge the JBL Pulse 3. Connect the provided Micro USB cable to the charging port on the speaker and the other end to the power adaptor. Plug the power adaptor into a wall outlet. The LED indicators on the speaker will show charging progress. A full charge takes approximately 12 hours.

2. Powering On/Off

Press and hold the Power button () located on the control panel until the speaker powers on or off. You will hear an audible cue.

3. Bluetooth Pairing

When powered on for the first time, the JBL Pulse 3 will automatically enter Bluetooth pairing mode. The Bluetooth indicator light will flash. On your device (smartphone, tablet, etc.), enable Bluetooth and select "JBL Pulse 3" from the list of available devices. Once connected, the Bluetooth indicator will glow solid. To manually enter pairing mode, press the Bluetooth button ( ) on the speaker.



A detailed view of the JBL Pulse 3's control panel, featuring clearly labeled buttons for power, Bluetooth pairing, light show mode selection, volume control, and JBL Connect+. The speaker's light cylinder displays a blend of blue and green.

Operating Your JBL Pulse 3

1. Adjusting Volume

Use the Volume Up (+) and Volume Down (-) buttons on the speaker to adjust the audio output level.

2. Controlling Music Playback

Press the Play/Pause button (►) to play or pause music. Double-press to skip to the next track.

3. Managing the 360° Light Show

Press the Light Mode button (☀) to cycle through different pre-set light show themes. You can also customize and create new light shows using the JBL Connect app on your smartphone or tablet.



The JBL Pulse 3 speaker, illuminated with a vibrant pink and orange light, is shown next to a smartphone. The phone's screen displays the JBL Connect app, illustrating how users can control the speaker's features, including its light show.

4. JBL Connect+

The JBL Connect+ feature allows you to wirelessly link multiple JBL Connect+ enabled speakers together for a

synchronized audio experience. Press the JBL Connect+ button (≈) on all desired speakers to connect them. For best results, ensure all speakers are within close proximity.
To synchronize light shows across multiple Pulse 3 speakers, simply shake one of the connected speakers. The light show will then synchronize across all linked Pulse 3 devices.

5. Speakerphone Functionality

When a call comes in, press the Play/Pause button to answer. Press again to end the call. The built-in noise and echo-cancelling speakerphone ensures clear conversations.

Care and Maintenance

Cleaning

Gently wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive materials. Ensure the charging port cover is securely closed before cleaning or exposing to water.

Waterproof Rating (IPX7)

The JBL Pulse 3 is IPX7 waterproof, meaning it can be immersed in water up to 1 meter (3.3 feet) for up to 30 minutes. Ensure all port covers are tightly sealed before exposing the speaker to water. Do not expose the speaker to salt water or other liquids besides fresh water.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on	Battery is depleted.	Connect the speaker to a power source and charge it fully.
Cannot connect via Bluetooth	Speaker is not in pairing mode; device Bluetooth is off; too far from speaker.	Press the Bluetooth button on the speaker to enter pairing mode. Ensure Bluetooth is enabled on your device. Move your device closer to the speaker (within 10 meters).
No sound	Volume is too low; speaker is muted; device is not playing audio.	Increase volume on both the speaker and your connected device. Ensure audio is playing on your device.
Light show not working	Light mode is off; app connection issue.	Press the Light Mode button to activate. Check JBL Connect app for settings and updates.

Technical Specifications

Model Name: JBL Pulse 3 - White

Model Number: JBLPULSE3WHTAM

Speaker Type: Outdoor

Special Features: Built-in Microphone, Stereo Pairing, Waterproof

Recommended Uses: Indoor/Outdoor

Connectivity Technology: Bluetooth

Wireless Communication Technology: Bluetooth

Bluetooth Range: 10 Meters

Output Wattage: 20 Watts

Audio Output Mode: Stereo

Signal-to-Noise Ratio: 80 dB

Power Source: Battery Powered

Battery Life: 12 Hours

Charging Time: 12 Hours

Battery Capacity: 6000 mAh

Water Resistance Level: IPX7 Waterproof

Product Dimensions: 8"D x 8"W x 12"H

Item Weight: 2.05 pounds (0.93 Kilograms)

Manufacturer: JBL

UPC: 050036337526

Warranty and Support

Warranty Information

The JBL Pulse 3 comes with a Limited Warranty. Please refer to the included Quick Start Guide or visit the official JBL website for detailed warranty terms and conditions specific to your region.

Customer Support

For further assistance, technical support, or service inquiries, please visit the official JBL support website or contact their customer service department. Contact information can typically be found on the JBL website or in the product packaging. You can also find additional resources and FAQs on theJBL Store on Amazon.

© 2023 JBL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question