

- Manuals.plus /
- > Prominence Home /
  - > Prominence Home Almadale 56-Inch Ceiling Fan Instruction Manual (Model 50330)

Prominence Home 50330

# Prominence Home Almadale 56-Inch Ceiling Fan Instruction Manual

MODEL 50330

## Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Prominence Home Almadale 56-inch ceiling fan. This contemporary ceiling fan features a brushed nickel finish, three high-performance blades, and a reversible motor for year-round comfort. Please read all instructions carefully before beginning installation and retain this manual for future reference.



Image: The Prominence Home Almadale 56-inch ceiling fan, showcasing its design and key features such as 3 blades, powerful airflow, and suitability for large rooms.

## Safety Information

To reduce the risk of electrical shock, fire, or personal injury, always follow these basic safety precautions:

- **Read all instructions:** Ensure you understand all safety warnings and installation steps before proceeding.
- **Disconnect power:** Before installing, cleaning, or servicing the fan, disconnect power by turning off the circuit breaker at the main fuse box.
- **Electrical connections:** All electrical connections must be in accordance with local codes, ordinances, and the National Electrical Code. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- **Mounting:** The fan must be mounted to a structurally sound outlet box or support system capable of supporting a minimum of 35 lbs (15.9 kg).
- **Blade clearance:** Ensure there is adequate clearance from the floor to the blade trailing edge (at least 7 feet / 2.13 meters) and from the blades to any walls or obstructions.
- **Avoid contact:** Do not insert objects into the path of the fan blades while the fan is operating.

# Code Compliant

Our products are designed with **YOU** in mind.



Our products have been safety tested to ensure the ceiling fan you are installing in your home our business will not present a safety hazard.



 PROMINENCE HOME

*Image: Prominence Home products are designed with safety in mind, meeting ETL, DOE, and Prop 65 compliance standards.*

# Package Contents

Verify that all components listed below are included in your package:

- Fan Motor Housing
- Blades (3)
- Blade Irons
- Mounting Bracket
- Downrod
- Canopy
- Hardware Pack (screws, washers, wire nuts)
- Owner's Manual

# Setup & Installation

## 1. Mounting Options

The Almadale ceiling fan supports two primary mounting configurations: Downrod and Angled.



**Downrod Mount:** Suitable for standard ceiling heights. A longer downrod (sold separately) may be required for taller ceilings.



**Angled Mount:** For sloped or vaulted ceilings, an angled mounting method is necessary to ensure proper fan operation and clearance.

## 2. Wiring

Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the full owner's manual and local electrical codes. Ensure all connections are secure and insulated with wire nuts.

## 3. Blade Attachment

Attach the three engineered wood blades to the blade irons, then secure the blade irons to the motor housing using the provided screws. Ensure all screws are tightened securely to prevent wobbling during operation.



# ALMADALE

## Industrial

### 56"

#### MOUNTING OPTIONS

2 POSITION DUAL MOUNT



Downrod



Angled

#### LIGHT TYPE

N/A

#### BASE + BULB

N/A

#### DIMENSIONS



#### BLADE FINISHES



BLACK

REVERSIBLE?  
YES

**3** BLADES

Style | Industrial Motor | Reversible Finish | Brushed Nickel Installation | 45-60 mins

Image: Visual guide to the Almadale fan's dimensions, mounting options, and blade details.

## Operation

### 1. Power and Speed Control

The fan is operated using the integrated pull chain. Pull the chain once to turn the fan on at high speed. Subsequent pulls will cycle through medium speed, low speed, and off.



*Image: Close-up of the fan's motor housing and pull chain for speed control.*

## 2. Reversible Motor Function

The Almadale fan features a reversible motor for optimal comfort in both warm and cool seasons. A switch on the fan's motor housing allows you to change the direction of blade rotation.

- **Summer Mode:** Set the switch to allow blades to rotate counter-clockwise, creating a downward airflow that produces a cooling effect.
- **Winter Mode:** Set the switch to allow blades to rotate clockwise, creating an upward airflow that helps circulate warm air trapped near the ceiling.

*Always turn off the fan and wait for the blades to stop completely before changing the direction of the motor.*

## Maintenance

---

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Check connections:** Annually, check all screws and connections for tightness. Loose connections can cause noise or wobbling.
- **No lubrication needed:** The motor is permanently lubricated and does not require oiling.

## Troubleshooting

If you experience issues with your fan, refer to the following common problems and solutions:

| Problem            | Possible Cause                                                                                     | Solution                                                                                                           |
|--------------------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| Fan does not start | No power to the fan; Loose wire connections; Incorrect wiring.                                     | Check circuit breaker/fuses; Ensure all wire connections are secure; Verify wiring against manual diagram.         |
| Fan is noisy       | Loose motor housing screws; Loose blade attachment screws; Fan not properly secured to outlet box. | Tighten all screws on motor housing and blade attachments; Ensure mounting bracket is securely fastened.           |
| Fan wobbles        | Loose blade screws; Unbalanced blades; Loose mounting hardware.                                    | Tighten all blade screws; Use a balancing kit (not included) if necessary; Ensure all mounting hardware is secure. |

## Specifications

Key technical specifications for the Prominence Home Almadale 56-inch ceiling fan:

| Feature                        | Detail                       |
|--------------------------------|------------------------------|
| Brand                          | Prominence Home              |
| Model Name                     | Almadale                     |
| Model Number                   | 50330                        |
| Product Dimensions (D x W x H) | 13.9"D x 23"W x 10"H         |
| Blade Length                   | 56 Inches                    |
| Number of Blades               | 3                            |
| Number of Speeds               | 3                            |
| Power Source                   | Corded Electric              |
| Wattage                        | 60 watts                     |
| Material                       | Nickel/Alloy Steel           |
| Blade Material                 | Engineered Wood              |
| Finish Type                    | Brushed Nickel               |
| Indoor Outdoor Usage           | Indoor, Outdoor (Damp Rated) |

| Feature        | Detail      |
|----------------|-------------|
| Control Method | Pull Chain  |
| Item Weight    | 13.5 Pounds |



# ALMADALE

## Industrial

### 56"

#### WET RATING

#### INDOOR

DRY

Indoor

DAMP

Covered


WET

Outdoor

#### ROOM SIZE

#### GREAT ROOM

20 ft. x 20 ft.  
or larger



Style | Industrial Motor | Reversible Finish | Brushed Nickel Installation | 45-60 mins

*Image: Wet rating information and recommended room size for the Almadale 56-inch fan.*

## Warranty and Support

Your Prominence Home Almadale ceiling fan is backed by a **Limited Lifetime Manufacturer's Warranty**. For detailed information regarding warranty coverage, terms, and conditions, please refer to the complete warranty statement included in the full owner's manual or contact Prominence Home customer support.

For technical assistance, troubleshooting not covered in this manual, or to inquire about replacement parts, please contact Prominence Home customer service through their official website or the contact information provided in your product packaging.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B074R6HHND>

More documents and user manuals: <https://manuals.plus/>