



[Manuals.plus](#) /

- › [Possini Euro Design](#) /
- › Possini Euro Design Pendant Light Fixture Instruction Manual

Possini Euro Design 23N40

Possini Euro Design Pendant Light Fixture

INSTRUCTION MANUAL

Introduction

Thank you for purchasing the Possini Euro Design Pendant Light Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.

This elegant pendant light, model 23N40, features a clear glass shade and a warm antique gold finish, designed to enhance various indoor spaces such as kitchens, dining rooms, bedrooms, and entryways.



Image: The Possini Euro Design Pendant Light Fixture, showcasing its clear glass shade and antique gold accents.

Important Safety Information

To reduce the risk of fire, electric shock, or personal injury, always follow these basic safety precautions:

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installing or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Use only UL listed wire connectors for the supply wires.
- This fixture is intended for indoor use only. Do not expose to water or moisture.
- Do not exceed the maximum wattage specified for the bulb.
- Always allow the fixture to cool before replacing the bulb.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Package Contents

Carefully unpack your fixture and check that all parts are included. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer support immediately.

- Pendant Light Fixture Assembly (Canopy, Downrods, Socket, Glass Shade)
- One 6-inch downrod
- Three 12-inch downrods
- Mounting Hardware (Crossbar, Screws, Wire Nuts)






Image: A view of the pendant light fixture, showing the canopy, downrods, and the clear glass shade, representing the main components.

Installation Guide

Before You Begin

1. Turn off electricity at the main fuse box or circuit breaker.
2. Ensure you have all necessary tools: screwdriver, wire strippers, electrical tape, and safety glasses.
3. Determine the desired hanging height and select the appropriate combination of downrods (one 6" and three 12" downrods are included). The fixture is sloped ceiling adaptable (0 to 90 degrees).

Mounting the Fixture

1. Attach the mounting crossbar to the outlet box using the provided screws.
2. Thread the fixture wires through the center hole of the crossbar.
3. Connect the downrods to the fixture body and the canopy, ensuring they are securely tightened.

Wiring Instructions

1. Connect the bare copper ground wire from the fixture to the green or bare copper ground wire from the outlet box using a wire nut.
2. Connect the white wire from the fixture to the white (neutral) wire from the outlet box using a wire nut.
3. Connect the black wire from the fixture to the black (hot) wire from the outlet box using a wire nut.
4. Carefully tuck all wires into the outlet box.

Attaching the Canopy and Glass Shade

1. Secure the canopy to the mounting crossbar with the provided screws, ensuring it sits flush against the ceiling.
2. Carefully attach the clear glass shade to the fixture body according to the design. Ensure it is stable and secure.
3. Install one E26 medium base bulb (not included) into the socket. Do not exceed 60 watts.

— | — | — 5 1/4"

11"



4 1/2"



Image: Dimensional diagram of the pendant light, indicating its 11-inch width and height, and 5 1/4-inch canopy.

Operating Your Pendant Light

Once installed, your Possini Euro Design Pendant Light Fixture operates via your standard wall switch (not included). The fixture is designed for simple on/off functionality.

Bulb Requirements

- **Bulb Type:** E26 Medium Base
- **Maximum Wattage:** 60 Watts
- **Bulb Not Included:** An Edison filament bulb is shown in product images for aesthetic purposes, but any compatible E26 bulb can be used.



Image: A detailed view of the light's clear glass shade and the E26 bulb socket, highlighting the bulb type.

Care and Maintenance

Proper care will ensure the longevity and appearance of your pendant light fixture.

Cleaning the Fixture

- Always disconnect power before cleaning.
- Wipe the metal parts with a soft, dry cloth. Do not use abrasive cleaners or polishes as they may damage the finish.
- For the glass shade, use a soft, damp cloth with a mild glass cleaner. Dry thoroughly to prevent water spots.

Bulb Replacement

- Ensure the fixture is turned off and has cooled completely before attempting to replace the bulb.
- Carefully unscrew the old bulb.
- Screw in a new E26 medium base bulb, ensuring it does not exceed 60 watts.

Troubleshooting

If you experience issues with your pendant light, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check circuit breaker or fuse box. Ensure wall switch is ON.
Light bulb is burnt out.	Replace bulb with a new E26 medium base bulb (max 60W).	
Loose wire connection.	Turn off power at breaker. Check all wire connections in the outlet box.	
Light flickers.	Loose bulb.	Tighten bulb securely.
Incompatible dimmer switch.	Ensure your dimmer switch is compatible with the bulb type used.	
Glass shade appears dirty or hazy.	Dust or residue buildup.	Clean with a soft, damp cloth and mild glass cleaner. Dry thoroughly.

If the problem persists after trying these solutions, please contact a qualified electrician or customer support.

Product Specifications

Specification	Detail
Model Number	23N40
Brand	Possini Euro Design
Dimensions (Overall)	11" Wide x 11" High
Canopy Dimensions	5 1/4" Wide x 2 1/2" High
Weight	4.2 lbs
Material	Metal, Glass
Finish	Warm Antique Gold
Shade Material	Clear Glass

Specification	Detail
Bulb Base	E26 Medium
Max Wattage	60 Watts
Voltage	120 Volts
Light Source Type	Incandescent (compatible)
Installation Type	Ceiling Mount (Pendant)
Sloped Ceiling Adaptable	Yes (0 to 90 degrees)
UL Listed	Yes
Included Downrods	One 6", Three 12"

Warranty Information

Specific warranty details for this product are not provided within this manual. For information regarding warranty coverage, terms, and conditions, please refer to the original product packaging or contact Possini Euro Design customer service directly. Proof of purchase may be required for any warranty claims.

Customer Support

If you have any questions, require technical assistance, or need to report missing/damaged parts, please contact the manufacturer, Lamps Plus, or the retailer from whom you purchased the product. Please have your model number (23N40) and purchase information ready when contacting support.

For more information, you may visit the [Possini Euro Design Store on Amazon](#).