Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WWOOR 8830

WWOOR Men's Quartz Stainless Steel Watch Model 8830 Instruction Manual

Model: 8830

Introduction

This manual provides detailed instructions for the proper setup, operation, and maintenance of your WWOOR Men's Quartz Stainless Steel Watch Model 8830. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Image: Front view of the WWOOR Men's Quartz Stainless Steel Watch Model 8830, showcasing its gold finish and classic dial.

Setup

Watch Band Adjustment

To ensure a comfortable fit, you may need to adjust the length of the watch band by removing or adding links. This process typically requires specialized tools such as a push pin, pliers, and a small hammer. If you are unsure, it is recommended to seek assistance from a professional jeweler.



Image: A diagram illustrating the process of removing links from the watch band using a push pin, pliers, and a hammer. It shows how to identify the pin direction and reattach the clasp.

Time and Date Setting

1. Pull the crown (the small knob on the side of the watch) out to the first position to set the date. Turn the crown clockwise or counter-clockwise until the correct date is displayed.
2. Pull the crown out to the second position to set the time. Turn the crown to move the hour and minute hands. To ensure correct AM/PM setting, advance the time past 12 o'clock; if the date changes, it is PM.
3. Once the time and date are set, push the crown back into its original position to start the watch and seal it against water.

Operating Instructions

Timekeeping

Your WWOOR watch is equipped with a Japanese-quartz movement, providing accurate timekeeping. The watch operates continuously once the crown is fully pushed in and the battery is functional.

Date Display

The watch features a date display window. The date automatically advances once every 24 hours. If the date changes between 10:50 PM and 0:00 AM, or between 9:00 AM and 6:00 PM, it is normal and can be manually adjusted as described in the 'Time and Date Setting' section.

Your browser does not support the video tag.

Video: A brief demonstration of the WWOOR watch, showcasing its design and functionality.

Maintenance

Water Resistance

This watch is water-resistant to 30 meters (100 feet). This means it can withstand splashes or brief immersion in water. **Do not pull out the crown while the watch is submerged in water.** It is not suitable for swimming, diving, or showering with hot water, as steam can penetrate the seals.

Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For stainless steel bands, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch uses one LR44 battery, which is included and has a service life of more than 1 year. When the watch stops or the timekeeping becomes inaccurate, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

Troubleshooting

- **Watch not running:** Ensure the crown is fully pushed in. If it still does not run, the battery may need replacement.
- **Date not changing correctly:** Manually adjust the date as described in the 'Time and Date Setting' section. Ensure the AM/PM is correctly set.
- **Condensation inside the watch:** This may indicate a breach in the water resistance. Avoid further contact with water and seek professional inspection.

Specifications

Feature	Detail
Item Model Number	8830
Movement	Japanese-Quartz
Water Resistance	30 Meters (100 Feet)
Case Material	Stainless Steel
Band Material	Stainless Steel
Clasp Type	Buckle
Battery Type	1 LR44 (included)
Package Dimensions	6.22 x 3.46 x 1.5 inches
Item Weight	3.81 ounces



Image: A detailed diagram illustrating the dimensions (band length, case thickness, case width) and weight of the WWOOR Men's Quartz Stainless Steel Watch Model 8830.

Warranty Information

Your WWOOR watch is covered by a 30-day satisfaction guarantee. If you are not satisfied with your purchase within 30 days, you may be eligible for a 100% refund or replacement. Please refer to your purchase documentation for specific terms and conditions.

Customer Support

For any questions, concerns, or assistance with your WWOOR watch, please contact the seller directly through the platform where the purchase was made. They will be able to provide further support and guidance.

© 2023 WWOOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B074SDP228

More documents and user manuals: **https://manuals.plus/**