BMZX 4335019362

BMZX 118-inch Extended Selfie Stick with Tripod and Bluetooth Remote User Manual

Model: 4335019362

Introduction

Thank you for choosing the BMZX 118-inch Extended Selfie Stick. This manual provides essential information for the safe and effective use of your new device. Please read these instructions carefully before operation and retain them for future reference.

Package Contents

Verify that all items are present in your package:

- 1 × BMZX Extended Selfie Stick Pole
- 1 × Bluetooth Wireless Remote Shutter
- 1 × Mini Tripod
- 1 × Universal Phone Holder



Image: The BMZX 118-inch Extended Selfie Stick, showing the main pole, detachable Bluetooth remote, and phone holder attachment.

Setup Guide

1. Attaching the Phone Holder or Camera Mount

1. Locate the universal 1/4 inch screw thread at the top of the selfie stick.
2. Screw the phone holder onto this thread until it is securely fastened. For action cameras like GoPro, use the provided adapter (if applicable) before attaching.
3. Place your smartphone into the phone holder. Ensure it is firmly gripped. The holder supports phones with widths between 56mm and 80mm (approximately 4.7"-7" screen size).

2. Attaching the Tripod

1. Locate the 1/4 inch screw thread at the bottom of the selfie stick handle.
2. Screw the mini tripod onto this thread until it is stable.

3. Extend the tripod legs for a stable base on flat surfaces.

3. Bluetooth Remote Pairing

1. Turn on the switch located on the side of the Bluetooth remote shutter. An indicator light will flash, signifying it is in pairing mode.
2. On your smartphone, navigate to your Bluetooth settings.
3. Search for available devices and select "AB Shutter3" to connect. The indicator light on the remote will stop flashing once successfully paired.
4. For iPhone users, press the iOS button on the remote to take photos. For Android users, press the Android button.



Image: Visual guide for pairing the Bluetooth remote shutter with a smartphone, showing the remote and a phone's Bluetooth settings.

Operation Instructions

1. Extending and Retracting the Selfie Stick

1. To extend: Gently pull each section of the pole outwards. The stick features 6 adjustable lengths, extending from 23 inches (58.4 cm) to a maximum of 118 inches (3 meters).
2. To retract: Push each section back into the main pole until it is fully collapsed to its folded size of 22 inches.
3. **Important:** Ensure each extended section is securely locked by twisting slightly to tighten. This prevents accidental retraction during use.



Image: A user's hands demonstrating the twisting motion to loosen and tighten the selfie stick's extendable sections. Also shown are compatible mounts for smartphones, DJI Osmo Action Cameras, and GoPro cameras.

2. Adjusting Phone/Camera Angle

1. The phone holder features a 180° rotation mechanism. Loosen the adjustment knob or joint near the phone holder.
2. Adjust the angle to your desired position for optimal photo or video capture.
3. Tighten the knob or joint to secure the angle.



Image: Close-up view highlighting the 1/4 inch threaded hole for tripod compatibility, the 180-degree adjustable phone mount, the non-slip handle with lanyard, and the removable mount for GoPro or other action cameras.

3. Using the Bluetooth Remote

Once paired, open your smartphone's camera application. Press the corresponding button on the Bluetooth remote (iOS or Android) to remotely trigger the shutter for photos or start/stop video recording.




Image: The BMZX selfie stick shown in various configurations: fully extended with a smartphone, with a GoPro camera, and with the tripod base for stable shots.

Maintenance

1. Cleaning

- Wipe the selfie stick with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- If used in wet conditions, ensure the stick is thoroughly dried before storage.

2. Storage

- Store the selfie stick in a cool, dry place away from direct sunlight.
- Retract the pole fully before storage to protect the extension mechanism.

3. Bluetooth Remote Battery Replacement

The Bluetooth remote uses a standard coin cell battery. If the remote stops responding or the indicator light does not illuminate, replace the battery. Refer to the remote's casing for specific battery type and replacement instructions.

TROUBLESHOOTING

1. Bluetooth Connection Issues

- **Remote not pairing:** Ensure the remote is turned on and within 30 feet of your phone. Check if the remote's battery needs replacement. Try turning Bluetooth off and on again on your phone.
- **Remote not triggering shutter:** Confirm the remote is successfully paired. Ensure your phone's camera app is open. Some camera apps may require specific settings for external remotes.

2. Selfie Stick Stability/Extension Issues

- **Pole not staying extended:** After extending each section, gently twist it to the right (clockwise) to tighten and lock it into place. This friction lock mechanism is crucial for stability. If the pole still slips, ensure it is not overloaded with heavy devices.
- **Wobbling when extended:** At maximum extension (118 inches), some slight wobble is normal due to the length. For maximum stability, especially with heavier devices, use the included tripod. Ensure all sections are fully tightened.



Image: The selfie stick displayed at its minimum (22 inches) and maximum (118 inches) lengths, alongside illustrations of compatible phone sizes and the 180-degree rotation capability of the phone clip.

SPECIFICATIONS

Feature	Detail
Model Number	4335019362
Extended Length	23 to 118 inches (58.4 cm to 3 meters)
Folded Length	22 inches

Feature	Detail
Item Weight	1.62 pounds (26 ounces)
Material	Aircraft Aluminum Rod, Anti-slip Rubber Grip
Phone Holder Compatibility	56mm-80mm width (approx. 4.7"-7" phones)
Camera Compatibility	GoPro Hero series, Ricoh Theta S/M15, compact cameras (1/4 inch thread)
Bluetooth Remote Range	Up to 30 feet
Bluetooth Remote Battery Life	Over 240 hours
UPC	761780407709

Warranty and Support

BMZX offers a 30-day hassle-free refund policy for this product. For any questions, technical assistance, or customer service inquiries, please contact BMZX customer support. Our professional after-sales customer service team is available to assist you.
Please refer to your purchase documentation or the BMZX official website for the most current contact information.